



## Manual version 8.3 ( $\geq$ V3.3.0)

**DISCLAIMER:** This software and hardware is provided "as is" without warranty of any kind, either express or implied, including, without limitation, any warranty of merchantability and fitness for a particular purpose. In no event shall the creators of this software be liable for any direct, special, incidental or consequential damages arising out of the use or inability to use the software. The creators and distributors of this software shall not be liable for any loss, damages or costs, arising out of, but not limited to, lost profits or revenue, loss of use of the software, loss of data or equipment, the costs of recovering software, data or equipment or claims by third parties, damage to equipment, or other similar costs.

For continuous product improvement and due to ongoing development, we reserve the right to alter specifications without notice.

**WARNING:** This hardware and software is protected by law and international treaties. Unauthorized reproduction or distribution of DYNertia3, or any portion of it, may result in severe civil and criminal penalties and will be prosecuted to the maximum extent possible under law.  
DYNertia3 software, hardware & firmware is copyright- Darren Todd 2022



## STOP !!!

**Please read the appropriate ‘Quick Start’ guide for your dyno type (Chassis or Engine & Inertia or ‘Open loop’ Brake) first.**

**Actual testing is outlined there!!!**

This ‘full’ manual contains much detail; by reading the ‘Quick Start’ guide first you will gain a basic understanding of the concepts and key points required.

There are sample files installed along with DYNertia3 software so you can connect the hardware and learn to use many of the features without needing to perform actual tests. It is much easier to study without the noise of a screaming engine!

All examples in this manual use ‘Metric’ units such as kph/Kw/Nm etc. DYNertia3 can be set in the software to ‘Imperial’ if you prefer mph/Hp/Ft Lb etc!

## Table of Contents

<b>Chapter 1: Introduction .....</b>	<b>9</b>
Introduction .....	10
Features .....	11
Overview- .....	11
Analysing Test Results-.....	11
Data Acquisition-.....	12
File Management-.....	13
Printing-.....	13
Additional Functions- .....	13
<b>Chapter 2: Hardware Installation .....</b>	<b>15</b>
Hardware Mounting.....	16
Mounting the DYNertia Sensor and Magnet .....	16
Alternate Sensors to the supplied one .....	17
Mounting the Electronic Control Unit .....	18
Hardware Wiring .....	19
Basic wiring .....	19
‘Linking’ Hardware to PC.....	20
<b>Chapter 3: Brake dyno setup .....</b>	<b>21</b>
Brake (Absorber) Style Dyno Setup .....	22
Basic concept .....	22
Variations .....	23
Types of testing used with brake (retarder/absorber) style dyno’s .....	23
Load cell calibration and wiring for Brake type .....	23
<b>Chapter 4: ‘Setup’ Menu Options .....</b>	<b>24</b>
Hardware- Setup Menu .....	25
Brake / Inertia Button .....	25
Chassis / Engine Button .....	25
Inertia Mass Constants .....	25
Roller Circumference .....	25
Tire Circumference.....	25
Mass RPM Limit .....	25
Sensor/Mass Ratio .....	26
Tacho / Speedometer .....	26
OBDII Adapter input for Engine RPM and vehicle speed.....	26
RPM Adapter input for Engine RPM .....	26
Brake Inertia Correction (Only in ‘BRAKE’ mode) .....	27
After Run Auto Braking/Vehicle Loading.....	27
Hardware Connections .....	28
Circumference Calculator.....	28
Moment Of Inertia Calculator .....	28
Software- Setup Menu .....	29
Graph Smoothness .....	29
Point by Point (Open Loop Brake Mode) .....	29
Inertia Mode Graph Smoothness .....	29
Passwords .....	29
Password (Program & Setup).....	29
Lambda / AFR .....	29
Preferred Lambda/AFR Channel.....	29
Custom Fuel – Stoic/AFR and Name .....	29
Graph .....	30
Auto Display of Last Run.....	30
Graph Torque Traces .....	30
Graph Trace ID’s.....	30
Auto Shift Traces Right .....	30

RPM / Speed Scales .....	30
Power / Torque Scales .....	30
<b>Run.....</b>	<b>30</b>
Run Screens – Chart Recorders .....	30
Run Duration.....	30
Use Actual run Min RPM .....	30
Run Summary .....	30
Live Slip Monitor .....	30
<b>Display.....</b>	<b>31</b>
Multiple Monitor Support.....	31
Hide Windows Desktop.....	31
Data Window Transparency .....	31
Screensaver:.....	31
<b>About .....</b>	<b>31</b>
Display of System Details.....	31
<b>System.....</b>	<b>32</b>
End of Each Run.....	32
DYNO Correction Systems .....	32
Run D3 Snapshot .....	32
Configuration Reset .....	32
<b>General .....</b>	<b>33</b>
Metric / Imperial .....	33
Media (Audio).....	33
Remote ‘Page Turner’ Actions .....	33
Data Consistency .....	33
Point by Point (Brake Mode) .....	34
<b>Ratios.....</b>	<b>35</b>
Last Ratio Set .....	35
Low Speed / RPM Operation .....	35
Set Ratio- Change Increment .....	35
<b>Run Comments .....</b>	<b>35</b>
Comment Editing.....	35
Comments added to each new Run .....	35
Company Name .....	35
<b>Outputs.....</b>	<b>35</b>
All Outputs (DYNertia and accessories) .....	35
Auxiliary Outputs (DYNertia).....	35
<b>File Storage Paths (Icon) .....</b>	<b>36</b>
Set DYNertia3 base file storage path .....	36
<b>User Details (Icon).....</b>	<b>36</b>
Set User Details .....	36
<b>Archive Storage Paths (Icon) .....</b>	<b>37</b>
Set DYNertia3 archive storage path .....	37
<b>Communications- Setup Menu .....</b>	<b>38</b>
Interface Port No. .....	38
Link Button.....	38
Manual Set Button .....	38
<b>DYNertia3 .....</b>	<b>38</b>
DYNertia Sensor Test.....	38
<b>Weather Watch .....</b>	<b>38</b>
Update Interval .....	38
<b>Load Controller.....</b>	<b>39</b>
Torque Sensor .....	39
<b>OBDII.....</b>	<b>39</b>
<b>Device Manager .....</b>	<b>39</b>
Open Windows Device Manager .....	39
<b>Printer .....</b>	<b>40</b>
<b>PRM/Speed Source .....</b>	<b>40</b>
<b>Sensor Configuration .....</b>	<b>40</b>
<b>Data Limits / Alarms .....</b>	<b>40</b>
<b>Losses Systems .....</b>	<b>40</b>

Main Graph Trace Colour (Visible only from 'Graph' screen) .....	40
Grid .....	40
Operator .....	40
<b>Chapter 5: RPM Input Options.....</b>	<b>41</b>
<b>Engine RPM, Purpose and Options.....</b>	<b>42</b>
<b>Why we may need engine RPM.....</b>	<b>42</b>
<b>Windows used for RPM setup (referred to in this chapter) .....</b>	<b>42</b>
<b>RPM input Options (7 Available!) .....</b>	<b>43</b>
<b>RPM Adapter input .....</b>	<b>45</b>
<b>Summary of your RPM options.....</b>	<b>47</b>
<b>General RPM input information .....</b>	<b>47</b>
<b>Chapter 6: Overview- 2 Main Windows .....</b>	<b>48</b>
<b>Two Main DYNertia3 Windows (DYNO / GRAPH).....</b>	<b>49</b>
<b>DYNO Window .....</b>	<b>50</b>
<b>Record Settings .....</b>	<b>50</b>
<b>Minimum Run RPM.....</b>	<b>50</b>
<b>Maximum Run RPM .....</b>	<b>50</b>
<b>Current Ratio.....</b>	<b>50</b>
<b>Mode .....</b>	<b>51</b>
<b>Status.....</b>	<b>51</b>
<b>DYNertia3 Hardware Lamps (DYN) .....</b>	<b>51</b>
<b>Run Control.....</b>	<b>52</b>
<b>Start Run Button.....</b>	<b>52</b>
<b>Correction Factors .....</b>	<b>53</b>
<b>User Comments Field .....</b>	<b>53</b>
<b>Output controls and Status .....</b>	<b>53</b>
<b>Dial Gauge Displays.....</b>	<b>54</b>
<b>Power &amp; Torque dials.....</b>	<b>54</b>
<b>RPM/Speed dial .....</b>	<b>54</b>
<b>Gauges Mode .....</b>	<b>54</b>
<b>Data Gauges ON Button .....</b>	<b>54</b>
<b>Speed to RPM (ratio setting) .....</b>	<b>54</b>
<b>Strip Charts .....</b>	<b>54</b>
<b>Data Dial Gauges .....</b>	<b>54</b>
<b>GRAPH Window.....</b>	<b>55</b>
<b>Tool Bar Button Functions .....</b>	<b>55</b>
<b>Exit .....</b>	<b>55</b>
<b>Print .....</b>	<b>55</b>
<b>RPM/Speed Mode .....</b>	<b>55</b>
<b>GRAPH/DYNO .....</b>	<b>55</b>
<b>Selecting Trace to Analyze .....</b>	<b>55</b>
<b>Selecting Trace to Display .....</b>	<b>55</b>
<b>Graph controls .....</b>	<b>56</b>
<b>Data displays .....</b>	<b>57</b>
<b>Run Time Gauges/Charts (Visible only from 'DYNO' Window) .....</b>	<b>58</b>
<b>RPM and Speed Scales .....</b>	<b>58</b>
<b>Chapter 7: Weather Corrections .....</b>	<b>59</b>
<b>Correction Factors .....</b>	<b>60</b>
<b>Viewing Weather Data .....</b>	<b>61</b>
<b>Chapter 8: Loading/Viewing Files .....</b>	<b>62</b>
<b>Loading of files into 'GRAPH' Window .....</b>	<b>63</b>
<b>Previewing (DYNertia3 File Explorer) and Selecting Files .....</b>	<b>63</b>
<b>DYNertia3 file Explorer .....</b>	<b>64</b>
<b>Creating / Deleting folders for tests .....</b>	<b>66</b>
<b>Reviewing Audio Files .....</b>	<b>67</b>
<b>Secondary GRAPH Window .....</b>	<b>68</b>

<b>Viewing Files ('GRAPH' Window) .....</b>	69
<b>Adjusting Graph appearance .....</b>	69
<b>Zooming .....</b>	69
<b>Clear Graph Trims .....</b>	69
<b>Clear Graph .....</b>	69
<b>Trace Visibility .....</b>	69
<b>Grid .....</b>	69
<b>Chapter 9: Trim, Merge &amp; Join Runs .....</b>	70
<b>Trim a Run.....</b>	71
<b>Merge Runs.....</b>	72
<b>Join Runs .....</b>	73
<b>Chapter 10: Test Notes- Add/Save .....</b>	74
<b>Adding Test Notes.....</b>	75
<b>'User' comments field .....</b>	75
<b>Accessing User Comments.....</b>	75
<b>Templates.....</b>	76
<b>Saving notes and applying to other tests .....</b>	76
<b>Chapter 11: Printing &amp; Exporting .....</b>	77
<b>Printing .....</b>	78
<b>General Printing .....</b>	78
<b>Print .....</b>	78
<b>Setup Printer .....</b>	78
<b>Offset Correction .....</b>	78
<b>Printing main Graph screens .....</b>	79
<b>Dyno Operator .....</b>	79
<b>Information for Printed Output.....</b>	79
<b>Print .....</b>	79
<b>Select Page .....</b>	79
<b>Customising your printout .....</b>	80
<b>User Details and Company Logo .....</b>	80
<b>Customer Disclaimer .....</b>	80
<b>Notes to print .....</b>	81
<b>General comments for printing.....</b>	81
<b>Produce comments on the main graph for printing .....</b>	81
<b>Exporting data .....</b>	82
<b>Select a Trace to export.....</b>	82
<b>Chapter 12: Live Data Viewing.....</b>	83
<b>Gauge Screens .....</b>	84
<b>Observing the engine data .....</b>	84
<b>Observing the Data Channels .....</b>	86
<b>Display Current AFR/Lambda .....</b>	87
<b>Chapter 13: Analysing Data ('View' Menu).....</b>	88
<b>Trace Info .....</b>	89
<b>Secondary Graph .....</b>	89
<b>Individual Trace Set .....</b>	90
<b>Compare .....</b>	91
<b>Torque Analysis .....</b>	92
<b>Losses .....</b>	93
<b>Lambda / AFR Deviation .....</b>	94
<b>Distance / Speed / Time / RPM Analysis .....</b>	95
<b>Slip / Tyre Growth.....</b>	96
<b>Run Duration Info .....</b>	97
<b>Point to Point Times .....</b>	98
<b>XY Graph .....</b>	99
<b>Run Data vs Time .....</b>	100

<b>Chapter 14: Inputs- Using .....</b>	<b>101</b>
Pin Allocations .....	102
General Input Notes .....	103
Important general information .....	103
Wiring inputs for best results .....	104
Connecting Sensors .....	105
General sensor connection (0-5V input shown) .....	105
Resistive sensor connection .....	106
Connection of a thermocouple amplifier (for K-type sensors).....	106
Air/fuel ratio meter connection (AEM 30-3000 unit as example).....	107
Connection of load cell for brake (absorber) style dyno's .....	107
RPM Adapter Input.....	108
General notes on wiring the RPM adapter input (secondary way of measuring RPM).....	108
Using a DTec 'RPM adapter' for the RPM adapter input .....	108
Basic connections for a DTec 'RPM adapter' to DYNertia's RPM Adapter input .....	109
Connections for a DTec 'RPM adapter' to suit spark plug wire sensing.....	109
Connections for a DTec 'RPM adapter' to suit coil 'switching' signals .....	109
Connections for a DTec 'RPM adapter' to suit coil 'drive' signals .....	110
Connections for a DTec 'RPM adapter' to suit 'VR' (inductive) sensors.....	110
Sensor Configuration .....	111
Configuring an input channel using pre-settings .....	111
Creating your own linear (2 points, straight line) sensor calibrations .....	112
Naming and calibrating of Lambda / AFR meter inputs .....	113
Creating your own non-linear sensor calibrations .....	113
Testing sensor configurations.....	115
Getting the best data.....	116
Channel Filtering .....	116
Reference Voltage Correction.....	116
Sensor Alarm Points .....	117
Sensor On / Off (Recording).....	117
Data Consistency .....	118
<b>Chapter 15: Load Cell Configuration.....</b>	<b>119</b>
Load Cell Connection .....	120
Wiring of the load cell (including pressure sensor style) .....	120
Load Cell Setup & Calibration .....	121
Sensor Calibration .....	121
Manual Sensor Calibration .....	123
Automatic Sensor Drift Cancellation.....	123
<b>Chapter 16: Outputs- Using .....</b>	<b>124</b>
Auxiliary Connections .....	125
Connecting outputs if required.....	125
Output functions .....	125
'Run' Output.....	125
'User' Output.....	125
'Brake' Output.....	126
<b>Chapter 17: Losses Correction.....</b>	<b>127</b>
'Losses' System .....	128
What are the effects of Mechanical Losses?.....	128
What does Measured Mechanical Loss Correction do? .....	128
Are these "Losses" worth worrying about? .....	128
Configuration Window .....	129
USER ESTIMATED Mechanical Loss Correction .....	131
MEASURED Mechanical Loss Correction.....	132
General setup for dyno Loss testing.....	133
How often should I run dyno losses correction? .....	133
Observing effect of Losses Correction.....	134

<b>Chapter 18: Maths Channels.....</b>	<b>135</b>
Concept .....	136
Sample expressions, simple .....	138
Testing an expression .....	138
Variables in detail.....	138
Creating and saving a math's expression .....	139
Applying an expression to a dyno file .....	139
'Exception' notifications .....	140
<b>Chapter 19: 'Utilities' Menu.....</b>	<b>141</b>
Send an email .....	142
Lambda $\leftrightarrow$ AFR Converter .....	142
RPM / Torque / Power Calculator.....	143
Metric / Imperial convertor for Torque / Power .....	143
Display current Weather Data .....	143
Display Current AFR/Lambda .....	144
RPM/Speed Stability.....	144
Data Diagnostics .....	145
<b>Chapter 20: Trouble Shooting &amp; FAQ's.....</b>	<b>146</b>
Trouble Shooting- Common Issues .....	147
Troubleshooting- Assessing results.....	150
Frequently Asked Questions (FAQ's) .....	152
<b>Chapter 21: Specifications.....</b>	<b>153</b>
Specifications .....	154
Notes .....	155
<b>Chapter 22: Additions &amp; Changes .....</b>	<b>156</b>
Software V3.4.x Changes & Errata .....	157

# **Chapter 1: Introduction**

**Overview and features!**

## Introduction

The DYNertia Dynamometer package allows for simple and inexpensive "Do It Yourself" construction / upgrade of an Inertia Dyno.

Perfect for anyone interested in engine / vehicle tuning, testing and modification whether it be car, bike or even model sized engines.

An Inertia type Dyno operates on the principle of calculating the Power required to accelerate a known mass, which is simply an additional 'flywheel' coupled to the engine or vehicle. The controller senses the velocity of the rotating mass and outputs this and other data to the DYNertia3 software. No expensive Load Cell is required and repeatability is excellent.

DYNertia can also operate as an 'open loop' brake dyno, here you must control the load manually, DYNertia does not have control over the brake i.e. you cannot enter an RPM and have DYNertia3 vary the load to maintain that RPM automatically. Brake type Dyno's use an absorber system (Hydraulic, Friction, Eddy Current etc) to load the engine and the resultant Torque is measured by a 'Load Cell'. In 'Brake' mode DYNertia3 uses this Torque input and RPM to calculate Power.

The DYNertia3 software package handles all of the functions required for Dyno control: configuration, saving Runs, correcting for atmospheric conditions, filtering, displaying data, printing, overlaying and analyzing multiple Runs.

A rotation sensor is included with the DYNertia3 Controller; you simply attach a magnet (supplied) to the Inertial Mass / Brake or drive system.

For Engine or Chassis Inertia Dyno's we also provide a comprehensive guide to assist in the design and construction of the Inertia Assembly. All you need in addition to this is the DYNertia package and a PC with a USB port.

Five analogue data channels and one digital input (secondary RPM input) are available for displayed and recording - these are completely flexible and can be used for sensors such as Air Fuel ratio, Exhaust Temperature, Pressure, Load Cell, secondary RPM etc. Two 'Math's' channels can be created from any of the existing data (create your own formulas), just think of the tuning possibilities!



## Features

### Overview-

Suitable for chassis and engine dyno designs, either direct or indirect drive to the inertia flywheel. Power measurement can also be taken from a 'load cell' for use on brake style dynos (e.g. water, eddy current, hydraulic, friction). DYNertia3 does not control the actual load on a brake style dyno, the load must be controlled manually (i.e. it's not closed loop).

Software provided handles all data management, analyzing and graphing required for your dyno project with powerful features yet a 'clean' interface. Both Metric and Imperial modes are provided, Power, Torque and setup parameters are changed from kph/Kw/Nm/°C to mph/Hp/Ft Lb/ °F etc.

Comprehensive Manual provided, also design & construction information is available for the mechanical dyno system, including an Excel spread sheet to assist with choosing and calculating the moment of inertia for your requirements.

Included magnetic sensor (hall effect) has an indicator for diagnostics. Integrated 'optical isolation' circuitry in the data acquisition systems helps limit ignition interference and provides PC protection.

As an inertia dyno, accuracy is only limited by mechanical system variation, internally each rotation is timed to a millionth of a second.

Ideal for portable applications (track days & exhibitions) as power is from the USB connection.

Compact, approximately 110L x 60W x 30H (mm) with a small remote sensor for easy adaptation to your design.

No ignition system adapters are needed for RPM sensing. It can determine engine RPM from shaft RPM by 'learning' their relationship (ratio). Up to 8 gears can be learnt and later selected for quick testing in any gear; the ratio can also be manually entered if no tachometer, simply based on number of sprocket teeth (e.g. for chain drive kart engine dynos).

If an engine RPM input (not otherwise required) from the engine is available, then this can not only be used as engine RPM but also means the difference between engine and shaft/flywheel RPM can be plotted to show clutch engagement RPM or reveal wheel slip on a chassis dyno.

Inertia value for up to 3 Inertia mass flywheels can be stored and easily selected for designs with adjustable Inertia mass to tailor to engine characteristics.

### Analysing Test Results-

Supports multiple monitors, if a second monitor is available then key Windows can be viewed separately to allow clear analysis, even if viewing and comparing many test results.

Overlay up to 10 Power and Torque graphs simultaneously, including the 'Last Run' which automatically appears after your Run is completed. Run trace color sets are user selectable, however 'Last Run' always graphed in red for quick identification.

Analyse and compare test results by easily 'hiding' any particular Run trace or quickly replacing with other saved Runs for comparison.

A reference Run trace can be locked so that it always stays on the screen for comparisons against other tests.

Up to 4 sets of Runs can be merged to create a brand new 'averaged' Run. Perfect for getting the most from analysis. The new generated file appears just like any other in DYNertia3. Comments are automatically attached that reveal the individual runs that it was generated from for future reference.

All 5 analogue channels are recorded with each Run for analysis and their value at the cursor are shown in a floating 'data box' (which can also be saved to 'clipboard'). DYNertia3 can overlay 2 chosen data channels with the existing Power and Torque traces for display or all of the data for any trace can be shown in a separate single Window for detailed analysis.

Select a graph trace; an onscreen cursor makes the dials (power, torque and RPM/speed) display exactly what was happening at that point in the test Run.

Advanced torque analysis is provided to graphically display 'area under the curve' and related statistics for comparing multiple traces.

## Analysing Test Results (cont.)

The percentage difference between a reference trace and the remaining traces can be shown graphically, for all data. Instantly see where each modification either improves or degrades performance compared to other runs. Great tool!

Lambda / AFR deviation is shown in a special Window that allows you to set a target value, it shows you where and by how much the real test results varied (essential for quick mixture tuning). Obviously an AFR meter must be connected!

Select any RPM/speed points and the time between them is shown for all Runs (up to 10), clearly reveals 'real world' acceleration improvements after modifications. Best performing Runs between all points are highlighted.

Full data table display of 'point by point' Power, Torque, RPM and Speed are produced for detailed study and can be exported directly into Microsoft Excel (with field headings included) or a text file (comma delimited ASCII, CSV.) can be generated, even the main graph view can be exported as a bitmap image ('.bmp') for further analysis and file sharing.

The relationship between distance traveled, time elapsed, Speed and RPM can be studied in a graphical analysis screen.

XY graph, choose any data to plot against another and display values at the cursor.

Math's 'Expressions' (formula) can be applied to any existing data to generate an additional 2 data channels. A powerful tool is provided to easily write, test and apply your concepts.

Click on the Run of interest to show all the data that relates to it. The test conditions, max readings, set up details or any of your personal notes that are saved along with each run can all be reviewed.

Full manual 'zoom' available on Power, Torque and RPM displays to display selected graph regions of interest.

Runs can be 'trimmed', the lower and upper speed section of graphs can removed if visually required (e.g. if tests start and finish RPM were inappropriately set) and the Run re-saved.

User selectable 'Trace Shift', the last 10 trace sets are always displayed (each new test trace 'shifts' the oldest one out of selection) - great when performing comparisons.

'Auto Load' your graph after a Run – can be selected to automatically switch to the graph display after each test Run or you can opt to do as many Runs as you like in quick succession and analyse as a graph later. A brief test summary is also immediately available after each test Run is completed.

Onscreen graph legend to rapidly identify Run trace set colors and filenames and a run summary is available to give the key data for all the selected runs in one concise table.

Data corrected for weather conditions with world standards (SAEJ607, SAEJ1349, DIN70020 or uncorrected). The environmental conditions and resultant correction factor are stored with each Run. Data can be manually entered or 'Weather Watch', automatic updating weather station is available as an option (USB to PC).

## Data Acquisition-

Data acquisition of 5 analogue input voltages is incorporated ('common' ground). This allows the monitoring of variables such as air fuel ratio, exhaust temperature etc.

Inputs are 0-5V but can easily be extended to 0-16V with external resistors.

Resistive sensors, such as standard automotive temperature sensors, can be easily connected with the addition of an external 'pull up' resistor.

A data logging function is provided allowing the 5 input channels (plus the digital RPM input) to be logged to the PC. The logging rate can be set and the data is saved (with field headings included) as a text file (.CSV) for later analysis in Microsoft Excel etc.

Input data can be viewed separately (can even be displayed on separate screen if dual monitors used) or is available whilst performing testing. Minimum and maximum alarms can be set to alert if sensors detect anything outside an acceptable level (lean mixtures, engine temperature overheat or oil pressure loss as examples).

The input channels are fully scalable, even for non-linear sensors. Many sensor choices are already pre-calibrated and DYNertia3 software doesn't just display the input voltage measured, a table for each input allows it to be calibrated and displayed in any units you choose (eg Lambda, air/fuel ratio, degrees, PSI etc).

For configuring non-linear sensors, such as automotive style temperature sensors, there is a tool provided that just requires 3 test points to be entered and it creates a full calibration table.

## Data Acquisition (cont.)

Simple screw type terminals on a removable terminal plug allow for quick and easy sensor wiring. A 5 Volt output to power auxiliary sensors is also present if required.

An additional digital channel is provided if you wish to have engine RPM directly measured (via a Hall sensor or DTec's 'RPM adapter'). This option can help reveal tyre slip/growth on a chassis dyno or centrifugal clutch engagement RPM. There is a dedicated analysis screen to examine slip/tyre growth.

## File Management-

Designed to perform testing quickly- common user settings are saved to reduce set up times and any personal notes you've entered in the provided form (general, vehicle, owner details etc) can be saved as a 'template' and applied to other runs to save re-entering the details, even copies the Run's set up details. Files can also be set to 'auto name', the file name simply increments with each test (and can carry over any personal notes), no need to even re-enter a name.

Advanced previewing function ('DYNertia3 File Explorer') shows graphs, summary details and the data table of all saved runs, this allows quick selection for loading into the main graph screen or for file management purposes. A cursor is even available to highlight points of interest on the graph and indicate that same location in the data table- no more browsing through cryptic file names!

User configurable directories- have as many separate directories to store your runs in as required and file protection can be applied to prevent individual files from being accidentally changed or overwritten if required.

## Printing-

Color print outs of your chosen graph or overlaid graphs (up to 5 printed on same graph) is only a mouse click away, complete with preview. A report page is also generated that has a summary of all the important test conditions, max readings, date, time, company logo, graph notes etc.

Printouts includes Run trace sets legends, colors and filenames, the graphs 'grid lines' can even be turned off!

Comments can be placed on the graphs to appear on the printouts.

Printing of specific areas of interest can be performed using the manual 'zoom' function.

## Additional Functions-

'Point by Point' testing mode for brake style dyno's allows recording of individual data points at the press of a button. These individual data sets are then combined to construct a conventional Run trace for easy analysis and comparisons.

For dyno competition entertainment, after a run maximum Power and Torque can be displayed in large format for crowds to easily see (result in both imperial and metric units).

Graphs are fully auto-scaled, Power, Torque and RPM scales are automatically configured for optimal display.

Flexible options for performing a test; a Run can be from 'start' command to 'stop' command or from 'start' command to zero power. A minimum speed can also be specified and data below this will be discarded, this eliminates any different start points of tests due to operator error.

All dial gauges have digital displays incorporated.

Gauges display 'real time' data during monitoring or setup. Ideal for steady state tuning with a brake type dyno! (only RPM is displayed 'real time' in Inertia mode)

Data 'Smoothing' that is applied to the Power traces is adjustable to ensure you don't miss out any detail but still end up with optimal appearing graphs.

There is a "Losses" function that can be used to measure and apply a correction to data for mechanical losses in your dyno system like friction and windage (typically very small) even or/and for driveline losses due to friction.

A 'system in motion' ("Run") output is available that is active as long as the flywheel is rotating, or a function is used that may result in rotation. This can directly control a relay to operate safety control systems/warnings if required or for automatic fan controls etc.

## Additional Functions (cont.)-

An 'Auto Brake' output is available that can directly operate a relay for an automatic brake for slowing the flywheel down if you wish, or an automatic cooling fan for cooling friction style brakes. The time it's active for after a test Run is adjustable in the software. The output can alternatively be operated manually in the software and will be active for either a short time or continuously.

A 'user controlled' output is available can directly operate a relay, it is manually turned on or off from the software and can be used for any general purpose function e.g. remotely turning on a cooling fan, pumps wheel clamps etc.

Tools to work out the moment of inertia of your dyno system, calibrate non linear sensors, convert air:fuel ratios to Lambda and for analysing relationships between Power / Torque / RPM are incorporated.

Keyboard 'shortcuts' assist with easy operation and an inexpensive and commercially available wireless keyboard or even a remote 'page turner' (the device often seen used for PowerPoint presentations) can be used as a remote control that can start/stop Runs, turn the gauges on/off and allow automatic file incrementing (no need to type in a new name). Very convenient if operating both the vehicle and the dyno single handedly.

## **Chapter 2: Hardware Installation**

**Hardware mounting**

**Alternate sensor options**

**Basic power wiring (see ‘Inputs- Using’ chapter for full details)**

**‘Linking’ hardware to the software**

## Hardware Mounting

### Mounting the DYNertia Sensor and Magnet

DYNertia times the rotational period of a component by sensing its position magnetically. The included sensors 'face' contains a magnet sensing 'Hall Effect' switch. The sensor detects the position of the magnet attached to the rotating dyno flywheel/load brake/shaft and processes to trigger the timing procedure.

**NOTE:** The rotation sensor system is the main RPM input used by DYNertia3 for Power calculation and therefore **must** always be setup for operation. If you choose to also use the engine ignition system (or other source) as a secondary RPM input then please read the chapter on 'RPM Input Options' in this manual regarding this optional input!

A small (10mm x 3mm with 4mm mounting hole) but very powerful 'rare earth' magnet is included with the kit. The magnet is small as this reduces the forces involved when rotating so it is easier to secure safely.

Do not mount the magnet at the perimeter of the dyno flywheel/shaft/sprocket etc. as the centrifugal forces will be highest; choose a location towards the centre area. The magnet is also very fragile and must be handled with care!


**NOTE:** The included sensor will only detect the 'South' Pole of a magnet, so the magnet must be have the South Pole (marked with red paint) facing the sensor!!



**Mounting by screwing/gluing flat to dyno flywheel-**

Dyno flywheel is drilled and tapped for 4mm screw (3.3mm drill size is usual for 4mm tapping). Short (min 6mm) screw inserted into magnet. Do not over tighten or magnet may crack!


Magnet epoxy glued and screwed to dyno flywheel with South Pole outwards.




The sensor face **must be positioned 1.5 - 2mm** from the magnets **South Pole** (or the head of the screw if one is used to secure magnet).

## Hardware Mounting (cont.)

A 16mm diameter hole is required to mount the sensor. Do not over tighten the lock nuts or they will be damaged. A small 'blob' of silicon sealant or similar is applied to the edge of the nuts to stop them loosening with vibration.



**Tip-** After the 'Linking' process (discussed later) the sensor operation can be checked via the button "DYNertia3 Sensor Test". The indicator and an audible noise can be used to confirm sensor operation during slow rotation. The indicator lamp/noise triggers for a short time as the magnet approaches the sensor (only on approach).



**KEY POINTS-** 1.5 – 2mm gap. Safe magnet mounting, South Pole (marked with red paint) of magnet facing towards the sensor!

### Alternate Sensors to the supplied one

DYNertia can accept other types of sensors if you prefer. The sensor input terminal is a digital input; it will not accept voltage from an inductive sensor (VR). The 'signal' terminal of DYNertia needs to be 'pulled' to ground when a target object is detected. Sensors that switch to ground like this are called 'open collector' style and include most industrial proximity sensors (too slow generally) and also the majority of automotive camshaft sensors ('Hall' type).

**NOTE:** If you are unsure please just contact us for help; we are not responsible if you damage the unit from incorrect connection!

**Hall sensors-** Hall sensors are 'switching' style sensors and are compatible, they are available to detect either magnet or metal 'target' objects. This may be a good choice if you wish to detect a rotating metal object rather than a magnet like the provided sensor does i.e. perhaps you have a protruding 'key' in a shafts key way. A common metal sensing sensor example (shown below) is the 'Honeywell 1GT101DC' sensor or most automotive camshaft sensors are good.




## Hardware Mounting (cont.)

### Mounting the Electronic Control Unit

Strong vibration may also destroy the sensor and control unit (as with all electronics) so it is important to consider mounting arrangements carefully.

**NOTE:** Engines with CDI ignitions, especially in conjunction with copper core spark plug leads and non-resistive spark plugs can generate large electrical interference for all electronics including PC's. It is very important to apply the following mounting and cable routing suggestions to avoid any problems!



It is very important to keep the PC, DYNertia and its cabling well away from large sources such as ignition systems-

- 1) Mount the sensor unit at the furthest distance (**'every inch counts'!**) from the engine as possible. Route all cables as far as possible away from the engine (and any electric motors such as cooling fans) and keep the controller and PC at a distance. Coil any spare cable up neatly at the PC. Keep the sensors lead away from the USB lead or any other wiring.

It's best to route cables inside a protective metal tubing or keep separated from the engine by mounting behind the earthed metal of the dyno frame or shields. Secure at the DYNertia control unit to prevent movement of the cables.

DYNertia3 software can even be operated by remote control if required (wireless keyboard or a PC 'page turner' as one option), tests can be started and stopped and new files even created (names incremented).

- 2) **Always** use resistive Spark plugs and suppressed Spark plug leads to prevent interference (at least during testing).

**Tip-** A suppressed spark plug lead from a car can be put in series with the existing spark plug to reduce interference.

This additional spark lead is essential on many go-kart engines as they have particularly 'noisy' ignition systems!

- 3) Follow the wiring advice in the "Inputs- Using" chapter on wiring if measuring from additional sensors.
- 4) Secure any leads close to the DYNertia control box. The aim is so that the leads are completely prevented from movement, as this will place stress on the connectors and wiring.

## Hardware Wiring

### Basic wiring

Dyno only needs the USB and the speed sensor connected for use.




### Example of wiring with some additional devices shown

**Note:** Until correct dyno operation is confirmed and some trial runs have actually been done –

- # Do not connect any sensors to input terminals
- # Do not connect anything to the “RPM Adapter” input, including the ‘RPM adapter’ (if you have one)

Please refer to the main DYNertia3 Manual (found under ‘Help’ menu) chapter called ‘Inputs- Using’ for full wiring details on connection of optional data acquisition devices or ‘RPM Adapter’.



## 'Linking' Hardware to PC

Do not run other programs when using DYNertia3, background processes could interfere.


- When you first run DYNertia3 you will be shown this Window. Press the “Continue OFFLINE” button, this is necessary as DYNertia3 software does not yet know what PC communication port your control units are connected to, it must be first ‘Linked’.

Once ‘Linked’ DYNertia3 will automatically find the hardware in future when it is connected, powered and the software is started. If you plug DYNertia hardware into another USB port you may need to re-link.

This Window will also appear whenever DYNertia3 is started and the control unit is not connected or ‘Linked’. Pressing the “Continue OFFLINE” button allows you to continue to use DYNertia3 software to view and analyse data ‘off-line’ (i.e. with no hardware connected to the PC).



- Plug the USB lead in, start DYNertia3 software, select the menu option “Setup” and then choose “Communication” and then press the “LINK” button to DYNertia3 to automatically configure the port interface. Then repeat for ‘Weather Watch’ if connected.



With the USB connected to DYNertia the status LED (next to the sensor connector) will blink twice at first to indicate microprocessor is initialising. After this the LED will illuminate to indicate power.

## Chapter 3: Brake dyno setup

**Setting up a brake (absorber) in addition to an Inertia style Dyno!**

**The following basic information regarding brake type dyno's  
is only relevant for an 'open loop' dyno system.**

**This system does not control a retarder in 'closed loop' i.e. it  
won't operate the absorber, only gather the data.**

## Brake (Absorber) Style Dyno Setup


### Basic concept

Brake (or absorber) style dyno's rely on a device to apply load to the engine. In a chassis dyno, this device absorbing the power (we will use the term 'brake' or 'retarder') is generally mounted on the end of the rollers shaft so its case could rotate as a load is applied if unrestrained. It is this rotational force that is measured to calculate the torque. Engine dyno have the brake either directly mounted to the engine or via a reduction drive (Eddy retarders have a limited max RPM)

The case is attached to a load cell sensor via a 'torque arm' that transfers the rotary motion into the linear one applied to the sensor.

The length of the arm acts as a lever, so this can be designed to suit the measuring range of your load cell and give appropriate sensitivity (or even made with several load cell attachment points for variability).

**Note:** We use the term "load cell" here for our 'torque sensor', but this can be an alternative style such as a hydraulic master cylinder and pressure sensor or even a mechanical spring and coil type 'potentiometer'.



If we know the force (in Nm allowing for the length of 'torque arm') applied to the load cell and the RPM of the shaft we can calculate power by the metric formula  $Kw = (\text{Nm} \times \text{RPM}) / 9549$ , this will be power at the wheels. By using a chassis dyno we can have a very convenient and quick way of testing modifications, unfortunately the effect of drivetrain losses and tire losses do have an impact, an engine dyno avoids many of these 'losses'.

See [www.DTec.net.au](http://www.DTec.net.au) website 'downloads' for information and design tools.

The DYNertia controller senses the speed of the brakes rotating shaft and outputs this data, along with the load cell information to the PC for analysis and storage.

DYNertia3 software package handles all the functions required of dyno acquisition: setting up, saving runs, correcting for atmospheric conditions, filtering, displaying data, printing, overlaying and analyzing multiple runs.

## Brake (Absorber) Style Dyno Setup (cont.)

**Open Loop systems-** You control the load manually, DYNertia3 does not have control over the brake.

**Closed Loop systems (not relevant for this system)-** You can enter an RPM/speed and have DYNertia3 vary the load to maintain that RPM automatically i.e. the load controller unit directly controls the brake and observes the result to allow continual adjustment.

**Note:** Basic DYNertia system alone does not control the actual brake/retarder load, this must be manually controlled. It has 'open loop' functionality i.e. you cannot enter an RPM and have DYNertia3 vary the load to maintain that RPM automatically.

In Brake mode, DYNertia3 uses Torque data from the load cell and roller RPM calculate Power. The measured Torque is corrected to engine RPM (calculated from the dyno's included sensor and ratio information or measured directly from the engine). If the ratios are set incorrect then the readings will be incorrect i.e. if you just use roller RPM on a chassis dyno then Torque will be shown as it appears at the roller only and not related to engine RPM. This is called 'Tractive Torque' (Torque at the tyre) and will be higher than engine Torque due to the gears multiplying effects. It is really the Torque delivered to the road and can be used as an effective tuning tool due to the increase in Torque resolution!

### Variations

As noted earlier, some brake style dyno use a hydraulic cylinder (like a vehicle 'master cylinder') as the 'load cell', by fitting a pressure sensor into the cylinder this provides the torque output. Alternatively some very old systems use a spring assembly to counter the brakes rotation and then measure the displacement of this with a linear potentiometer (position sensor).

Both can be interfaced into DYNertia!

Mechanical instability will cause poor quality data, some old friction style brake dyno's even have shock absorbers to dampen movement (those just mentioned with springs in their load measurement system).

It can be very difficult to allow steady rising of the RPM for a 'run' without a good control system for your load, friction brake systems are particularly difficult to operate smoothly and are often best operated for brief 'steady state' tuning ('Point by Point' mode is ideal). Excessive Inertia in your system can also cause difficulties on low power engines i.e. the inertia load can end up limiting the acceleration during a test and not the load absorber device.

### Types of testing used with brake (retarder/absorber) style dyno's

Two main tests can be performed with a brake style dyno, a 'ramp run' or a steady state 'point to point' test-

A 'steady state' test (or 'point to point' as we call it) is where the load is applied until the engine RPM reaches a desired set point (with a fixed throttle opening) and data is then recorded upon a button press. A graph is built up and displayed based on these recorded data points.

A 'ramp' test is performed by adjusting the brake load to allow the engine to accelerate through the RPM range whilst DYNertia3 graphs the Power using the load cell as a Torque input.

### Load cell calibration and wiring for Brake type

Please see the chapter on 'Load Cell Configuration' as the wiring and calibration procedures are explained there

## **Chapter 4: ‘Setup’ Menu Options**

**Hardware setup**

**Software setup**

**Communications setup**

**Sensor setup**

**Losses setup**


**Main Graph Appearance setup**

**Configuration reset**

# Chapter 4: ‘Setup’ Menu Options





## Hardware- Setup Menu



**Brake / Inertia Button:** Determines if you are using a brake (retarder/absorber) type dyno or an Inertia type dyno. If you select a brake style dyno then DYNertia3 will expect to see a ‘load cell’ input into channel 5 of the data acquisition connector. This will be used as the primary torque input for Power calculations rather than the inertia value.

**Chassis / Engine Button:** Determines if you are using a chassis or engine type dyno.



**Tip-** Helpful Tools!



**Inertia Mass Constants:** The dynos “Primary Mass” (the main dyno ‘flywheel’ and any significant rotating components) inertial value is entered here (see “MOI” button for a tool to help calculate if not already known). If the dyno design incorporates multiple selectable dyno flywheels then their values can be entered in “Second Mass” and “Third Mass” to allow quick selection in main Dyno screen.

These extra masses are added to the primary inertia value when selected in the ‘Dyno’ screens “Record Settings” box.



The entry screen for roller circumference is only revealed when a chassis dyno is selected.

The entry screen for tire circumference is only revealed when an engine dyno is selected.

**Roller Circumference:** Used for chassis dyno’s to allow speed in kph/mph to be displayed if required (see “CIRC” button for a tool to help calculate if not already known).

**Tire Circumference:** Optionally is used for engine dyno’s if you wish to display speed in kph/mph as oppose to just RPM. The road speed can be simulated as the dyno will now know what distance would be travelled for every turn of the drive shaft.


For an engine dyno, enter the distance in mm that the vehicle would travel per rotation of the shaft that the dyno speed sensor is mounted to, not necessarily the actual ‘tire circumference’

**Note:** Units will be metric or imperial based on your choice in menu “Setup/Software”.



**Mass RPM Limit:** You can apply an RPM limit alarm to your system if you wish i.e. if there is a maximum safe limit you wish for your mass/flywheel not to exceed. If DYNertia3 detects an over speed condition it will give very obvious alerts to the danger and force an end to your test session.


## Hardware- Setup Menu (cont.)



The entry screen for pulse generator will not normally be revealed (not for the standard dyno as provided).

**Sensor/Mass Ratio:** On some special purpose dyno applications it may be that there is extremely low rotation speed and therefore limited flywheel/roller timing data. This feature allows designs such as this to drive a sensor wheel via gearing (or friction contact) at a higher RPM and thus can have the sensor trigger magnet speed applied rather than the flywheel e.g. if the sensor magnet was spinning twice as fast as flywheel/roller then a value of 2 would be required. It is also used where the sensor is not actually mounted on the flywheel/roller but on another shaft that rotates at a different speed to the inertial mass.

**Note:** Trying to use this feature to allow triggering from multiple trigger targets on the flywheel/roller will result in poor data quality; it will need excessive filtering to smooth out the ‘jitter’ from tolerances between your trigger targets.



**Tacho / Speedometer:** The filtering speed determines the level of smoothing applied to the display. This has the effect of displaying values that are not so wildly changing due to small cyclic variations in engine firing and dyno mechanical tolerances.

**Tip-** Too large a ‘Smoothing’ numbers and disturbances that may be of interest can be hidden



**OBDII Adapter input for Engine RPM and vehicle speed:** If you have the optional OBDII interface (not available at time of this manual) then you can choose to have this data used for various functions rather than just the calculated RPM and speed (which is derived from the main flywheel/roller speed sensor).



**RPM Adapter input for Engine RPM:** If you have a suitable input adapter (such as DTec’s ‘RPM Adapter’) or sensor connected to DYNertia’s RPM Adapter input then you can choose to have this engine RPM value used for various functions rather than just the calculated RPM (which is derived from the main flywheel/roller speed sensor).

**NEVER** connect ignition system directly to the RPM Adapter input!

RPM Adapter input is required if ‘slip’ analysis is to be performed. ‘Slip’ is dyno RPM compared to engine RPM, this is handy for checking clutch engagement RPM or looking for loss of tyre traction on a chassis dyno.



It is important that if the RPM Adapter input is used then the number of pulses received that represents a single engine rotation must be entered. It can be fractional e.g. 4 strokes only fire every 0.5 rev (which is once every 2 revolutions!) so “0.5” would be entered (2 stroke = “1”)

**NOTE:** Read the chapter “RPM Input Options” chapter for full setup details and “Inputs-Using” chapter for connection!


## Hardware- Setup Menu (cont.)



**Brake Inertia Correction (Only in ‘BRAKE’ mode):** If you have a brake style dyno and are performing ‘ramp’ runs then the inertia of your dyno may be a considerable factor. If you select this option, and have the Inertia value correctly entered, then DYNertia3 will basically operate as both Inertia and brake dyno simultaneously i.e. it will calculate the power used to accelerate the mass as well as derive the power from the load cell.

**Note:** Excessive inertia built into a brake dyno (i.e. an inertia dyno with a brake added) will result in incorrect results as high inertia will mean the load cell will not be reading as the brake will have no control of the ramp rate until power overcomes the inertia effect, if at all!

### After Run Auto Braking/Vehicle Loading:




**Note:** The use of the “Brake” output depends on the dyno type you have setup.



The ‘Brake’ output terminal may be used to operate an automatic brake for slowing the flywheel down if you wish, operating a vehicle lift/jack to remove vehicle from rollers, an automatic cooling fan for friction style brakes.

The ‘Brake’ output terminal can go active from after a run is stopped and remain on for the time set in ‘After Run Auto Brake’. It can also be manually activated for a pre-set time (‘Pulsed Brake Timeout’) or toggled on/off at will.



Besides the automatic function upon ending a test, the brake output can alternatively be briefly operated (based on ‘Pulsed Brake Timeout’) by manually selecting the icon (visible on both GRAPH and DYNO screen) with a ‘Left’ click, this allows for setting up safely and also applying brief braking pulses

Alternatively a ‘Right’ click on the icon will hold the output on continuously until another ‘Right’ click is done again i.e. ‘Right’ click toggles the output state. If not allocated to a brake; this output would be perfect for remotely turning on a cooling fan etc.

**Note:** Further details for the complete output functions are outlined in the chapter “Outputs- Using”


# Chapter 4: 'Setup' Menu Options




## Hardware- Setup Menu (cont.)





**Hardware Connections:** An overview of terminal designations on the DYNertia hardware. Handy if your decals are not visible.



**Circumference Calculator:** Tool to help calculate your rollers circumference if you do not already know it. Units will be metric or imperial based on your choice in menu "Setup/Software" (Imperial or Metric). Pressing the "Circ" button will transfer the value into the "Roller Circumference" field in this 'Hardware' menu.



**Moment Of Inertia Calculator:** Tool to help you calculate the Moment of Inertia (MOI) of your dyno. If the dyno design incorporates multiple selectable flywheels then their values can be saved separately as a "Second Mass" and "Third Mass".



Once the values of components have been entered into the rows they can be saved (or loaded) for later use and reference.



Simply press one of the numbered buttons and the MOI value will be directly transferred into the "Inertial Mass Constants" field in this 'Hardware' menu.



'Eraser' button clears the filled in fields so new values can be entered.



From within the 'MOI' calculator you can press the icon of a weight to get a reference of density of metals as shown here.

Typical Material Density ( Approximate )	
Material	Density
Mild Steel	7.85 Grams / cm <sup>3</sup>
Stainless Steel	7.480 - 8.0 Grams/cm <sup>3</sup>
Cast Iron	7.207 Grams / cm <sup>3</sup>
Gray Cast Iron	7.3 Grams / cm <sup>3</sup>
Malleable Iron	7.2 Grams / cm <sup>3</sup>
Ductile Iron	7.1 Grams / cm <sup>3</sup>
Aluminum	2.712 Grams / cm <sup>3</sup>
Aluminum - 1100	2.72 Grams / cm <sup>3</sup>
Aluminum - 6061	2.72 Grams / cm <sup>3</sup>
Aluminum - 7050	2.8 Grams / cm <sup>3</sup>
Aluminum - 7178	2.83 Grams / cm <sup>3</sup>
Brass 60/40	8.52 Grams / cm <sup>3</sup>
Light alloy (Al)	2.56 - 2.8 Grams / cm <sup>3</sup>
Light alloy (Mg)	1.76 - 1.87 Grams / cm <sup>3</sup>
Titanium	4.5 Grams / cm <sup>3</sup>

# Chapter 4: ‘Setup’ Menu Options




## Software- Setup Menu

### Graph Smoothness

**Point by Point (Open Loop Brake Mode):** When testing on a brake style dyno (or using a brake on inertia dyno) and operating in ‘Point by Point’ testing mode we can choose how to join up the individually recorded data points to create a trace.

“Fitted Curve” provides a mathematically smoothed line that can be adjusted using the tension setting (how close the line comes to the data points).

“Linear” setting just joins the data points without smoothing; it is best used if data points are not too far outside expected values, perhaps due to recording some data when the dyno system had not yet stabilised at the fixed RPM.




**Inertia Mode Graph Smoothness:** When testing on an inertia dyno this filtering value determines the level of smoothing applied to the data.

This has the effect of displaying data that is not so wildly changing due to small cyclic variations in engine firing and dyno mechanical tolerances.

### Passwords

**Password (Program & Setup):** Option to enter a password to lock out access from either changing settings or running the DYNertia3 software.

Entering a password in the field will automatically enable the function to use this entered password every time DYNertia3 is started. To remove password protection you must delete (USE ‘BACKSPACE’ KEY) all text from the password field until you will see the word “Inactive” appear before you close down the “Software Setup” menu.




**Note:** If password is forgotten DTec will need to be contacted to allow program access, so don’t lose password!!!

### Lambda / AFR

**Preferred Lambda/AFR Channel:** Set to input channel your AFR meter is connected to, saves re-selecting in later analysis Windows.

**Custom Fuel – Stoic/AFR and Name:** If you are using a special fuel that is not in our standard list, then you can enter a custom AF ratio here. This is only required if you are using this fuel for analysis using AFR, it is not required for working in Lambda. See chapter “Inputs- Using” for details of ‘Current Lambda/AFR’ analysis Window.



# Chapter 4: 'Setup' Menu Options



## Software- Setup Menu (cont.)

### Graph

**Auto Display of Last Run:** When selected, DYNertia3 will automatically open the Graph Window and add the test Run just performed to the set of traces so you can view it immediately.

**Tip-** If testing many times before analysing traces then it's faster with this function off!

**Graph Torque Traces:** The axis of the graph are automatically scaled, if you prefer the torque traces to sit below the power traces then select (graph scales can still be altered manually and override this setting). Feature is just a visual preference, traditional dyno graphs have the torque scaled lower when displayed.

**Graph Trace ID's:** Appends the min and max power to the test run names (visible on Main and Secondary graphs).

**Auto Shift Traces Right:** Setting 'Auto Shift' means that each time a new 'Run' is performed that it's loaded as the 'last run trace' and the previous last Run becomes trace number 1, trace 1 moves to trace 2, 2 moves to 3, 3 moves to 4 and 4 is removed from selection. This feature allows for the graph to always contain the latest Runs. There is the additional option to leave trace set 4 as a reference trace. You can choose to 'Exempt Trace Set 4'. This means that trace 4 will remain as loaded and not be shifted off the screen.

**RPM / Speed Scales:** If the data gathered is slightly above/ below the start or end graph range it will be interpolated for better graph appearance.

**Power / Torque Scales:** The axis of the graph are automatically scaled, the units used are 'neat' increments (e.g. 90Kw, 100Kw etc). If you are testing very small power engines then it may make analysis easier if fractional scales are used (e.g. 4.34Kw, 5.5Kw etc)

### Run

**Run Screens – Chart Recorders:** Determines after a test when the chart recorder data is frozen to allow viewing.

**Run Duration Calculated until:** Run time duration displayed in the data will start at the press of the "start run" button (or F12) and end at these two options, either 'stop' pressed (or F12) or zero Power detected.



**Use Actual run Min RPM:** The trace will use the actual minimum RPM seen, and not the start RPM as set on the "DYNO" screen in the 'Record Settings' field.

**Tip-** Normally leave this un-ticked for a better looking Run trace, avoids having irrelevant data on the graph i.e. RPM showing that is even below when the actual test began



**Run Summary:** Selecting "large Summary" will produce a large summary screen showing both imperial and metric data after a Run. Screen is designed for use in public displays such as 'dyno competitions'.

**Live Slip Monitor:** Warning when chassis dyno slip (measured engine RPM vs RPM calculated from roller) exceeds difference.



# Chapter 4: ‘Setup’ Menu Options




## Software- Setup Menu (cont.)

### Display


**Multiple Monitor Support:** DYNertia3 can display its data across two monitors, this allows comfortably analysing large amounts of data. You can select what monitor displays the main Graph Window or other selected Windows.

**Hide Windows Desktop:** Resets Windows ‘desktop’ for an attractive ‘backdrop’ when DYNertia3 is running. This can be used for applications where the PC screen size/resolution cannot be set to exclude the background.

**Note:** DYNertia3 is a fixed sized Window and cannot be enlarged (‘maximised’) to fill the whole screen, set the screen resolution for best appearance (Program Window size is 1024 x 768).




**Data Window Transparency:** Sets the transparency level of the ‘floating’ data box that is used in several analysis screens & also the main Graph Window. ‘Transparent’ menu then controls the function from within the data box! The ‘floating’ data box shown is usually displayed by ‘Right’ clicking on the Right hand scales of a graph or screen



**Screensaver:** Disables screen saver to prevent it from interfering with DYNertia3 software, for example if it turns on and you are in the vehicle ready to test, you may need to get out and reset (e.g. if you had no keyboard in the vehicle).

### About

**Display of System Details:** Displays Firmware version, hardware version, copyright information and what options are enabled.



# Chapter 4: ‘Setup’ Menu Options




## Software- Setup Menu (cont.)

### System


**End of Each Run:** This enforces saving of the test results.

**DYNO Correction Systems:** This allows tests to be corrected to a standard set of atmospheric conditions for consistency as the environmental test conditions change. Correction to world standards SAEJ607, SAEJ1349, DIN70020 or uncorrected can be applied. SAE J607 is chosen by default as it is in widespread use. See chapter “Weather Corrections” for details.



**Run D3 Snapshot:** This is only used for trouble shooting. It generates a package for DTec support; it allows us to view your settings and other data that will help us reproduce any faults you may have. It is much easier/quicker than trying to guide you on what files to manually copy and email!

It requires (and will prompt) you have a user name and email address entered in user details screen, in menu “Setup/Software”. You can press the option to directly email or otherwise you can save, transfer and email the file from another PC.




**Configuration Reset:** Resets all current settings and returns software to default configuration. You will be warned before the reset and given the option to continue.

It does not delete any test files etc, it just restores settings.

Before the reset you will be asked if you would like a file to be created that has all the current settings written down. This will be saved in the DYNertia3 folder (it is named “SETTINGS.txt”) and this file will also be made available to you for reading or saving.

This file can be used to retrieve any settings you may wish to manually re-enter, such as Inertia value, circumference etc.




## Software- Setup Menu (cont.)

### General

**Metric / Imperial:** Selects the units used by DYNertia3, kph/Kw/Nm/°C to mph/Hp/Ft Lb/ °F etc. Mixed units are not presently available (exception is the large Run summary screen below!).

**Media (Audio):** Enables an audio input via the PC’s microphone. This can be used to simply save a commentary during a test or to record the actual engine noise. For further details see chapter “Overview- 2 Main screens” for details of controls on Dyno Window and also chapter “Loading/Viewing files” regarding “reviewing Audio files”.



**Remote ‘Page Turner’ Actions:** Allows the allocation of tasks to the PC’s ‘page up’ and ‘page down buttons’, this also allows an inexpensive and commercially available remote keyboard or ‘page turner’ (the device often seen used for PowerPoint presentations) to become a remote control. Very convenient if operating the vehicle and the dyno single handed, also allows the PC to be kept away from the interference of the engines ignition system.



Your PC’s ‘page up’ and ‘page down’ buttons can be set to allow-

- Start/stop runs
- Save data when doing ‘Point by Point’ testing (brake style dyno’s)
- Fine RPM/speed increase (closed loop systems)
- Coarse RPM/speed increase (closed loop systems)
- Save
- Close
- Automatic file incrementing (no need to type in a new name).

Other functions are altered when enabled so to reduce the need for any unnecessary key presses, for example screens that appear after a run are displayed for a small time and then automatically close.

**Data Consistency:** Sets the warning that occurs when traces are loaded that were recorded with different sensor calibrations to those in use.


‘Clicking’ on the illuminated “!” warning icon will reveal a screen that will show the inconsistencies and allow you to determine if an issue or even allow you to alter the scaling if this is the only issue. This ‘Data Consistency’ screen appears also in the chapter ‘Inputs- Using’ under ‘Data Consistency’ and will be detailed fully there.

# Chapter 4: 'Setup' Menu Options



## Software- Setup Menu (cont.)

### General (cont.)



**Point by Point (Brake Mode):** In the menu option 'Setup/Hardware' the choice 'Brake' mode must be selected. This field is relevant if you are manually loading the engine via a brake device (friction, magnetic, water etc).

Ticking the box allows 'steady state' testing with a brake style dyno using 'Step testing' (or 'Point by Point' as we call it)-

Recording data in 'steady state' mode rather than performing a traditional dyno 'Run' (ramp test): In this mode tests are built up by recording data at various test points. The data is then used to construct a graph and even data from multiple test sessions can be 'joined' to form one test.

**Tip-** This mode of testing is often the best option for those with limited performing brakes added to their inertia dyno's. Particularly friction brakes, as these can only hold the load for a very small period of time. The test data can be recorded each time a target load/speed point is held and a Run graph will be built up from these individual recordings.



When you press the "Start Run" button (or F12) on the 'Dyno' screen a new button called "Save Current Readings" is now revealed!

**Note:** Traces made from 'Point by Point' will show "Err" when viewing Run duration information as this is irrelevant.

You can now run the engine and apply the dyno load to hold at any suitable RPM. When stable press the 'Save Current Reading' button to store that data.

Test at any RPM, in any order e.g. you can be at any RPM without worrying about if it is greater or less than the last recording and there is no time limit as to when you take each reading.


Every time you press the button the new data is saved.

It is normal practice to test at set RPM intervals ('steps') but this is not essential



When you press "Stop Run" button (or F12) a graph trace will be created from your saved data points and this can be viewed like any other test Run trace.

Each time the data is saved a counter will display this in the 'Record Settings' status field



# Chapter 4: ‘Setup’ Menu Options




## Software- Setup Menu (cont.)

### Ratios

**Last Ratio Set:** Setting allows for the ‘Record Settings’ field called “Current Ratio” to automatically select the last ratio that was ‘taught’ or manually set as the one to use for RPM.

**Tip-** Having this ticked prevents you from setting a new ratio and then forgetting to actual select it for use. The only time you might de-select is if you are setting up a whole range of ratios in one go rather than a single on you wish to use.




**Low Speed / RPM Operation:** Allows for very slow speed operation in regards to speed that the system determines it is not operating and zero’s all gauges. If in low speed it will take several seconds (approx. 4 – 8 sec) of no rotation before the system considers that motion has stopped and to reset the gauges etc. to zero.

**Set Ratio- Change Increment:** Adjusts the step sizes used in the ‘Speed to RPM’ screen to adjust a set ratio value i.e. to ‘nudge’ the value for fine tuning if matching DYNertia3 RPM to vehicles tacho etc.

### Run Comments

**Comment Editing:** Allows you to alter the comments of an existing file after testing has been performed i.e. during review.




**Comments added to each new Run:** Allows testing comments you have made to be automatically transferred to the next test. This function is designed for quick testing i.e. you are doing multiple tests of the same modification. Without this each new test has all its comments cleared.

**Note:** Does not apply to the operator and company name, these are pulled in from the user details (over page).

**Company Name:** Company name can be automatically added to all test comments. Details are entered with the ‘Set User detail’ button at top of software setup window (icon of house and man).

### Outputs

**All Outputs (DYNertia and accessories):** Outputs (Brake and User) can be set to turn off upon exit. This ensures devices connected to the auxiliary output terminals (see chapter “Outputs- Using”) can be left in a suitable state upon exiting the software.



**Note:** ‘Run’ output (active on rotation) is not controlled via the software so is only turned off with no rotation or if DYNertia USB is removed.

**Auxiliary Outputs (DYNertia):** The ‘User’ auxiliary output can be set to turn on at each Run, the “OUT” icon on GRAPH and DYNO Windows turns a green colour to reflect active output operation.


**Note:** Further details for the complete output functions are outlined in the chapter “Outputs- Using”

# Chapter 4: 'Setup' Menu Options




## Software- Setup Menu (cont.)

### File Storage Paths (Icon)



**Set DYNertia3 base file storage path:** By default DYNertia3 creates a certain structure of where it stores your test Runs and other saved data. Under 'C' drive is created a main folder (Base path) that other folders are stored under. You can use any folder you like (either created in Windows Explorer or perhaps an existing Folder of previous tests) as long as it is located under this 'Base path', as shown in black in the information Window seen here.



When you select a Folder on the Left Hand side and it is confirmed as 'correct' by the green indicator then that will be used by DYNertia3 for saving files into.

**Tip-** The default setup paths should be left alone unless you have a specific reason for renaming or changing the file structure.


### User Details (Icon)



**Set User Details:** Data and your company logo image used here appear on the printouts. The logo can be inserted by pressing the "ADD" button or if you do not wish to use a logo, press "X" button.

The logo should be a Bitmap (BMP) and have an aspect ratio of 2:1 to prevent distortion.

A link to a 'Customer Disclaimer' document can also be configured here. As legal requirements in countries varies we have not provided a disclaimer. When setup, this disclaimer can be printed under the menu option "File/Print/Customer Disclaimer".



## Software- Setup Menu (cont.)

### Archive Storage Paths (Icon)





**Set DYNertia3 archive storage path:** DYNertia3 can be set to archive your files automatically (archiving can also be done at any time from menu “File/Archive now”.

This screen allows you to select a time period, in days, that will automatically save the files from one location to another location


DYNertia3 will scan all files in the selected root folder and any subfolders underneath it for relevant files. Saved run files and any files you have created (many Windows allow you to save information to a file)

It can be configured to just save all files including old ones or to just save the new ones based on date reduces storage space)



**Tip-** Information at the top of the Window shows when the last archive was created and when the next one is due.

## Communications- Setup Menu




**Interface Port No.:** DYNertia3 software needs to know which USB PC port the hardware has been allocated to. Unfortunately, when installing particular USB devices, modern PC's allocate them to almost any communication port number and will even change this depending on what USB socket is being plugged into. See “Link” below.

**Link Button:** The easiest way to set the “Port No.” is to plug in the hardware and press the “Link” Hardware button. It will step through all of the port options and try to establish communication with the hardware, when found, the port setting is automatically saved and should remain valid for the USB socket you have plugged into, if you use another socket you may need to search again.

**Manual Set Button:** If you know the port that is allocated you can manually set the number.

### DYNertia3



**DYNertia3 Sensor Test:** Designed as a quick check that the sensor is working correctly and DYNertia3 is receiving the signal. The indicator and an audible noise can be used to confirm sensor operation during rotation. The indicator lamp/noise triggers for a short time as the magnet approaches the sensor (only on approach).

**Note:** The test will not work at high speed (lamp won't flash); it is only a setup test at low very RPM.

### Weather Watch



Weather Watch is an optional USB device that will allow weather data (temperature, pressure and humidity) to be automatically imported into DYNertia3 rather than manually entering from a third party weather station.

**Update Interval:** Sets how often the weather data is imported into DYNertia3 to update the correction values.

**Note:** See chapter “Weather Corrections” for full details on ‘Weather Watch’ weather station.

**Tip-** The menu option “Utilities/Current Weather Data” allows you to view the live data from the optional ‘Weather Watch’ station including RAD (Relative Air Density).

## Communications- Setup Menu (cont.)

### Load Controller

Not relevant for this dyno type.


### Torque Sensor

Linking of the digital load cell amplifier for brake type dyno (not available at time of this manual)

### OBDII

Linking of the OBDII diagnostic port reader (not available at time of this manual)

### Device Manager





**Open Windows Device Manager:** A short cut to open the Microsoft Windows function that can allow you to see what PC port has been allocated to the DYNetia equipment.

The Windows Device Manager is a very helpful tool to trouble shoot problems with the PC not communicating to DYNetia components.


When the USB lead is connected to the PC we need to see a Port (COM & LPT) called “USB Serial Port (COM x)” or there is an issue with the installation of the USB ‘driver’ software or the USB connection.

This port name should appear even if DYNetia is not powered up (though you cannot actually ‘Link’ DYNetia to PC without it being powered).

Disconnecting and reconnecting the USB lead whilst observing this screen below should show the port being removed from the list and then being added again.




**Tip-** The devices that are linked are shown on the main ‘DYNO’ screen




## Printer

See chapter “Printing and exporting” for full details.



**Note:** The option to use ‘RPM Input’ is only visible if in the menu option ‘Setup/Hardware’ it is enabled and configured.



**Note:** OBDII diagnostic port reader is not available at time of this manual.

## Sensor Configuration

See chapter “Inputs- Using” for full details, load cell calibration is also found in this menu choice.

## Data Limits / Alarms

See chapter “Inputs- Using” for full details.

## Losses Systems

Refer to chapter ‘Losses Systems’ for detailed information.

## Main Graph Trace Colour (Visible only from ‘Graph’ screen)



You can select a new colour for any of the traces individually here.

You can select any display colour from the pallet to associate with selected trace number, it will be stored permanently.

**Tip-** The colours chosen are also used for printing (on a white background), so keep this in mind and avoid very light colours if printing is planned.

## Grid

Set if the main graph is to have a grid displayed as background behind the graph traces.

## Operator

Allows entry of the operators name, this can be transferred with the comments (see “Setup Software” chapter) and will also appear on the printouts.


# **Chapter 5: RPM Input Options**

**Why engine RPM may be required**

**Screens used to configure RPM**

**Options for obtaining Engine RPM**

# Chapter 5: RPM Input Options



## Engine RPM, Purpose and Options

### Why we may need engine RPM

Power is a function of speed and torque. When power is measured at the dyno roller or shaft it is the same as at the engine (ignoring the actually quite large losses). Any gearing will multiple the torque, but will also reduce the RPM and therefore power remains the same. So once we have the power, if we wish to display torque of the engine we need to know the engine RPM so we can then ‘derive’ it to remove the effect of gearing.

The need for engine RPM (either calculated via ratio or measured), not just dyno RPM from shaft speed sensor is -

**Inertia dyno-** Engine RPM is needed to calculate engine torque. Power is directly calculated from dyno flywheel acceleration rate and therefore does not need engine RPM. If no engine RPM is available then the torque displayed will be at the actual dyno shaft/roller/flywheel, but power will be the same as at the engine!

**Brake dyno-** Engine RPM is needed to calculate engine torque. The ‘load cell’ input directly measures torque and at the dyno shaft/roller, the RPM is also measured here, we can then calculate power at that location. If no engine RPM is available then the torque displayed will be at the actual dyno shaft/roller, but power will be the same as at the engine!

**Either type-** Engine RPM via a ratio (in conjunction with being directly measured) is required for the ‘Slip’ (speed difference) to be displayed correctly if used. The exception is a direct drive engine dyno.

**Note:** The term “engine” power or torque is ‘loosely’ used here; it is ignoring the very real drivetrain losses etc.

### Windows used for RPM setup (referred to in this chapter)

The following pages will refer to this ‘RPM Source’ selection window; it can be accessed via several methods. The menu option ‘Setup/RPM Speed Source’ is one method.




From the DYNO Window, icon bottom right of torque dial. ‘RPM Source’ indicator shows if the RPM source is from the ‘RPM adapter’ (spark plug icon) or speed sensor (roller icon). Pressing on this symbol will open the selection menu to allow quickly changing.



If you have the ‘Speed to RPM’ window open (shown below) then pressing the ‘Source’ icon will also open the selection menu.




There will also be reference to a ‘Speed to RPM’ button, this is found on the main DYNO Window. This button opens the Window below used to quickly set gear ratios if required.



**Tip-** It is also possible to give any ratios a name of your choice. This can be useful if it is an engine dyno and you regularly change engines that use different gearing or you may save ratios for common bikes on a chassis dyno etc.

**Tip-** When “Speed to RPM” pressed, running a test is prevented and the RPM/speed Gauge will read RPM only as viewing the RPM may be required in the setup process!

‘Record Settings’ field will be referred to in some RPM options as the “Current Ratio” must be appropriately set for any RPM option chosen. Visible on the main ‘DYNO’ Window.



# Chapter 5: RPM Input Options



## RPM input Options (7 Available!)


To avoid the need to attach engine RPM sensors (difficult on some engines), many options allow us to derive engine RPM from the drive ratio between the engine and the dyno RPM (as measured by DYNertia sensor at its location).

### Option 1- No RPM used-

You can select DYNertia3 to run in ‘Speed’ mode (Kph/Mph instead of RPM as an axis), this requires no engine RPM input but the Torque shown will be at the roller (Power shown is at engine though). This is for very quick testing on a chassis dyno as it requires no setup at all.



**RPM/speed Mode:** Switches the dyno from displaying RPM as the graph X-axis to speed. Roller circumference must be correctly entered in the menu option “Setup/Hardware”. Button is on Top Left side of either ‘DYN’ or ‘GRAPH’ Window.



### Option 2- Shaft RPM-

For a ‘direct drive’ engine dyno; in the ‘Record Settings’ panel for “Current Ratio” select “Shaft RPM”.



If the dyno brake/flywheel shaft turns at the same speed as the engine then shaft RPM is the same as engine RPM. DYNertia3 will then know that its measured shaft speed can be assumed to be the engine RPM.

### Option 3- Ratio Teach-

If DYNertia3 knows the drive ratio between the engine and the dyno it can calculate actual engine RPM from the dyno RPM (as measured by its sensor). This option will require that the engine has a tacho already fitted.

**Tip-** If vehicle has no tacho fitted, but you have an ‘RPM Adapter’, you can use this automatic teaching function but instead of a fixed target you can use the RPM signal from the ‘RPM Adapter’. See “Option 6” for details.

Ensure the “Use Default RPM/Speed System” is selected as the RPM source.



Run the vehicle until the tacho matches the ‘Engine Target RPM’ in your test gear (4000 RPM in this example shown) alter this set point if RPM not suitable, then simply press a ‘Compute Ratio’ button of choice. The calculated ratio will now appear in the field above the button.

That’s it! DYNertia3 now knows the engine RPM for any vehicle speed in the gear just used. You can ‘teach’ other gears also if you want to do testing in multiple gears (up to 8). We recommend you use “Compute Ratio 4” for 4th gear etc.

# Chapter 5: RPM Input Options




## Option 4- Manual Ratio Entry-

If DYNertia3 knows the drive ratio between the engine and the dyno it can calculate actual engine RPM from the dyno RPM (as measured by its sensor). This option will require you to know the drive ratio being used, this is usually not practical for a chassis dyno as tyre size, roller size, gear box and final drive ratio must all be known and calculated. If testing engines without gearboxes (e.g. kart) then this is a very good option.

e.g. For an engine dyno: Ratio = Number of dyno flywheel gear teeth divided by number of teeth on engine drive gear.

Ensure the “Use Default RPM/Speed System” is selected as the RPM source.

Manually enter a ratio into ‘User Ratio’ **or** any of the 8 ‘Compute Ratio’ fields, then press Enter key.




You can enter data for other gears also if you want to do testing in multiple gears (up to 8). We recommend you use “Compute Ratio 3” for 3rd gear etc.

Ensure you select the correct set ratio in the ‘Record Settings’ panel for “Current Ratio”, choose “User” if you have used the ‘User Ratio’ field (or any of the 8 ratios if these were used).

## Option 5- Manual RPM to Speed Entry-

If DYNertia3 knows the speed the vehicle does at a certain engine RPM then on a chassis dyno it can then calculate engine RPM from the dyno speed (as measured by its sensor).



Manually enter an RPM and speed separated by a “=” sign, enter into ‘User Ratio’ or any of the 8 ‘Compute Ratio’ fields, then press Enter key. The example above was used as this vehicle does 1550RPM at 100kph in 5<sup>th</sup> gear.

You can enter data for other gears also if you want to do testing in multiple gears (up to 8). We recommend you use “Compute Ratio 5” for 5th gear etc.

# Chapter 5: RPM Input Options



## RPM Adapter input


Using the 'RPM Adapter' input with DYNertia opens up other options for RPM input as it directly measures engine RPM. If engine has no tacho fitted, but you have an 'RPM Adapter' you can use it to automatically 'teach' a ratio. This uses the RPM adapter as a temporary tacho only ('Option 6' below).

It can also be used as a direct source of the RPM, this is useful if the vehicle has a torque convertor effecting torque at the shaft/roller ('Option 7' below).

**Note:** Even if used for Engine RPM a drive ratio is still required for the 'Slip' (speed difference) to be displayed correctly if used.

**NEVER** connect ignition system directly to DYNertia, power it from a separate battery to DYNertia's and wire as shown. Please read "Inputs- Using" chapter of this manual to see details of engine connection options.

**Tip-** It is best to do initial dyno setup testing before using a direct Engine RPM source; this avoids any error due to miss-wiring or electrical interference.




## Option 6- Alternative RPM Source for Ratio Teach (Not Continuous RPM Measurement)-

If the optional 'RPM Adapter' input source is configured then pressing a 'Compute Ratio' button of your choice allows DYNertia3 to automatically calculate the ratio between engine RPM (from 'RPM Adapter' input) and the dyno RPM. No need to hold at a target RPM, just hold engine steady at any RPM in the test gear you wish to 'teach' the ratio of.

**Note:** 'RPM Adapter' input can be used as the only RPM source for all functions (gauge displays, graph scales, min/max record settings and correcting shaft/roller torque readings to the engine). However, using the RPM adapter just to temporarily obtain a ratio which is then used to calculate the engine RPM smoothes the effect of engine power pulse fluctuations and gives more stable torque readings.

This 'mixed' method of RPM measuring is the best option if you are using the RPM Adapter input.



To ensure the 'RPM Input' source can be selected" Check Box is checked in menu option 'Setup/Hardware'.



Select the "Use DYNertia's RPM Input" source using the menu option 'Setup/RPM Speed Source' or by pressing the icon bottom right of torque dial. Pressing on this symbol will open the selection menu.




If you have the 'Speed to RPM' window open (shown below) then pressing the 'Source' icon will also open the selection menu.

PTO

# Chapter 5: RPM Input Options



## Option 6- (cont.)



No need to hold at a target RPM, just hold engine steady at any RPM in the test gear you wish to ‘teach’ the ratio of and press a ‘Compute Ratio’ button of your choice.

**Note:** After using the source of alternative RPM to teach a ratio you now select the source “Use Default RPM/Speed System” to use this new ratio. Ensure this new ratio is chosen in the ‘DYNO’ screens “Record Settings” field!

**Tip-** This is a great method if you have an unstable RPM adapter input as once ‘taught’ this ratio is used to derive the engine RPM (not the RPM Adapter). You can even disconnect adapter from the engine, which now also removes a potential source of interference into DYNertia.




## Option 7- Alternative RPM Source

This uses the optional ‘RPM Adapter’ input source as the sole engine RPM source for all functions (gauge displays, graph scales, min/max record settings and correcting shaft/roller torque readings to the engine).

To ensure the ‘RPM Input’ source can be selected the check box “RPM Input” is checked in menu option ‘Setup/Hardware’.

Also, you need to set the ‘Pulses per Revolution’, this allows the software to work out the true engine RPM from the frequency of the pulses e.g. a 4-stroke engine typically fires a spark only once every 2 revolutions so ‘0.5’ would be the entry. A 2-stroke fires every revolution so ‘1’ would be the entry.



Select the “Use DYNertia’s RPM Input” source using the menu option ‘Setup/RPM Speed Source’ or by pressing the icon bottom right of torque dial. Pressing on this symbol will open the selection menu.



If you have the ‘Speed to RPM’ window open (shown below) then pressing the ‘Source’ icon will also open the selection menu.

**Note:** It is vital to have a perfect RPM Adapter input signal at all RPM for ‘Option 7’, if unsure then refer to previous section on using the RPM adapter for automatic ratio teaching (‘one off’ use) and use ‘Option 6’.

**Note:** Setting a drive ratio is still required for the ‘Slip’ (speed difference) to be displayed correctly if used.

## Summary of your RPM options

Your options (previously detailed) depend on the dyno design-

- **Engine dyno, dyno flywheel/brake coupled directly to the engine (1 flywheel rotation = 1 engine rotation)**  
# Option 2 is best.

No setting required, instead select "Shaft RPM" in the 'Record Settings' panel for "Current Ratio".

- **Engine dyno, dyno flywheel/brake driven via gearing (1 flywheel rotation = x engine rotations)**  
# Option 3,4,6,7 can be used. Option 4 is very easy and very accurate (assuming clutch is engaged).

Set "User Ratio" based on the gearing (eg. Number of dyno flywheel driven gear teeth divided by number of teeth on engine drive gear). Select "User" in the 'Record Settings' panel for "Current Ratio".

If ratio unknown and the engine has a tacho or you have an 'RPM Adapter' input connected then another option is to simply use the 'teaching' options 3 or 6.

- **Chassis dyno (1 roller rotation = x engine rotations)**

# Option 1,3,4,5,6,7 can be used. Option 1 is easiest (no RPM scale though), 3 is fast (but assumes constant test gear).

DYNertia3 can be 'taught' the relationship (ratio) of dyno roller to engine, up to 8 gears can be learnt and later selected in the 'Record Settings' panel for "Current Ratio", allows for very quick testing of the vehicle in any gear.

Enter an appropriate RPM as "Engine Target RPM", choose a test gear, hold the engine RPM at the RPM number you entered and when steady press the 'Compute Ratio' button of choice.

If you have the 'RPM adapter' input connected then DYNertia3 can read RPM from the engine directly or be 'taught' a drive ratio to relate engine RPM to dyno RPM (RPM at the dyno's sensor location). For this make sure you choose correct settings in the "Setup/Hardware" menu. Press a 'Compute Ratio' of your choice and the ratio will be calculated regardless of current engine RPM i.e. there is no need to set any RPM to hold the engine at! Just hold the engine RPM relatively steady at any RPM for good results.

## General RPM input information

It is important to understand that DYNertia3 can calculate engine RPM for its operations from it's included sensor. If the vehicle has gears and you are testing in a different gear to the selected ratio then the tacho will read incorrectly!

If you don't set a ratio i.e. let the RPM used be roller RPM (select 'roller RPM' in 'Record Settings' panel). This will result in the Torque figure being 'tractive effort' (at the wheels) and not engine torque. This can be very interesting as it's the actual power getting to the ground (for given dyno design) !

**Note:** 'Slip' calculations can't operate with engines fitted with CVT transmissions or automatics that can't be locked into a set gear for testing, this is due to them having a continually changing drive ratio between engine and dyno flywheel. The change in engine RPM vs dyno flywheel RPM would be shown as slip, even though this is not the case (may be of interest anyway for development).

**Note:** Ramp testing on Brake type chassis dyno is best done using speed/sec and not RPM/sec, this is due to the system needing a drive ratio to be set and maintained. Gear shifts or torque convertor slip will render it inaccurate due to the fact that the dyno control system is controlling the roller RPM (a precision closed control loop) i.e. engine RPM must be converted to roller RPM by the software to set the ramp rate, it can't do this if the drive ratio changes.

**Tip-** If you know you'll only be testing in one gear then only bother teaching that particular gear.

**Tip-** You can even name your 'taught' ratios for easy selection e.g. you may often test engine types with different sprocket sizes, just pre-set the ratios and name after the engine type etc.

**Tip-** The small arrows next to the ratio buttons allow 'nudging' the value for fine tuning if matching DYNertia3 RPM to vehicles tacho etc. ("Setup/Software" sets step)



# **Chapter 6: Overview- 2 Main Windows**

## **2 Main Windows of DYertia3**

**Features visible on the ‘DYNO’ & ‘GRAPH’ Windows**

**Scaling the Gauges and Charts during testing (‘runtime’)**

# Chapter 6: Overview- 2 Main Windows




## Two Main DYNertia3 Windows (DYNO / GRAPH)

Press the “**DYNO**” / “**GRAPH**” button to change between the 2 main Windows of DYNertia3.


The ‘**DYNO**’ Window is used to select and create files, enter the weather details, record vehicle test data, ‘teach’ gear ratios, view RPM/speed and control the testing.

**Note:** This Window is only visible when the control unit is connected, powered and ‘Linked’.



**Note:** The Row of gauges (input channel data) shown along the bottom of the screen are visible with a single monitor. With dual monitors this data is displayed on the second monitor instead and replaced with the test ‘comments’ field (also found in ‘View’ menu).

The ‘**GRAPH**’ Window displays the Power and Torque as traces that can be overlaid and analysed. Traces from a test Run can be selected, loaded from file and compared.



**Note:** The Most menu options can only be selected from this GRAPH screen (they are ‘greyed’ out in DYNO screen)



**Note:** The RPM/Speed button makes the software use either units of RPM or speed (e.g. kph) for the controls, displays and graphs.

**Note:** When test Runs are visible on the graph we refer to them as ‘traces’.



**Note:** The DYNertia3 Window does not size itself to the PC screen, if you wish you can adjust your PC screen resolution to best suit (Program Window size is 1024 x 768)

# Chapter 6: Overview- 2 Main Windows



## DYNO Window

### Record Settings



**Minimum Run RPM:** Is what you want to start the test at- This sets the point that will be used to start graphing data when testing. It is usually set just above the slowest speed that you can hold steady on the dyno before you accelerate for a ‘run’. If set too high your graph will simply be missing data below this speed and if set too low then unsightly readings may be visible at the start of your graph due to the engine ‘surging’ against the dyno flywheel load as you prepare to accelerate (inertia dyno). If you have DYNertia3 set to end a test when negative power is detected then a low setting may also cause a test to end early, this could occur if you decelerate accidentally at low RPM whilst getting ready to accelerate for a test.

**Maximum Run RPM:** Is what you want to end the test at- This sets the point that will determine at what point the graphing screen ‘trims’ off the trace, it does not determine when the actual dyno ‘run’ is over (i.e. it will ignore the data after the set maximum). It is usually set just below your maximum planned RPM. If set too low your graph will simply be missing some high speed data and if set too high then unsightly spacing may be visible at the end of your graph.

**Note:** Either RPM or speed is used depending on the operating mode set. To change the dynos mode use the ‘mode’ tool bar button (icon of ‘gauge’, Top Left of active screen); RPM or speed settings are both stored independently.



**Tip-** Clicking on the text “Maximum” or “Minimum” will allow direct fast direct entry of the values.

**Current Ratio:** The selection here is used by DYNertia3 to work out (derive) engine RPM by relating it to dyno RPM from the speed sensor and this will depend on the gear being used during testing on chassis dynos.


Set the vehicle gear you wish to test in or select “Shaft RPM” if the dyno is directly coupled to the engine (1 flywheel rotation = 1 engine rotation). There is also a “User” option for selecting a fixed ratio, this is used for dynos were the dyno shaft is indirectly driven by the engine via gearing. Ratio data is set with the “Speed to RPM” button (middle RH side of screen above).

**Note:** Details about setting ratios are covered in the chapter “RPM Input Options”

Incorrect setting of ratios will result in engine Torque being displayed incorrectly as it is calculated from Power using engine RPM, Power figures will be unaffected as they are based on flywheel mass RPM (inertia dyno) or load cell & roller RPM (brake dyno).

## DYNO Window (cont.)

### Record Settings (cont.)



**Mode:** If multiple flywheels are used (up to 3) then selecting the number will update the inertia value used in the power calculations, this allows for quicker operation than re-entering the new inertia value each time dyno flywheels are changed/engaged. The inertia values are set in the menu option “setup/hardware”.



If Dyno type selected is a ‘Brake’ (in the ‘setup/Hardware’ menu) then this fact is shown here instead of the rollers shown above for ‘Inertia’ mode.



**Status:** Displays if “Recording” DYNertia3 is gathering data from a Run, “Ready” when waiting for a Run, “Gauges” if ‘Gauges on’ or “Calibrate” if ‘Speed to RPM’ button are pressed (this indicates that the tacho/speedo dial gauge is operational for reference but an actual test Run cannot be performed in these modes)



**DYNertia3 Hardware Lamps (DYN):** Lamp is green when associated DYNertia3 hardware has been detected and communication established, red if not. If this is the case, firstly check that the unit is plugged into the computer correctly and powered up then confirm that the “Setup/Communication” menu has the correct port configuration.

**Weather Watch Lamp (WW):** Lamp is green when the optional ‘Weather Watch’ (automatic weather station) hardware is connected into the PC’s USB port, has been detected and communication established, red if not. The lamp will ‘blink’ as it updates the weather data.

**Load Control System Lamp (LC):** Not relevant for this dyno type.

**Torque Sensor (TS):** Lamp is green when the optional ‘Digital Load Cell Amplifier’ hardware is connected, has been detected and communication established red if not. Not available at time of this manual.


**OBDII Scanner (OBDII):** Lamp is green when the optional ‘OBDII Scanner’ hardware is connected, has been detected and communication established red if not. Not available at time of this manual.

# Chapter 6: Overview- 2 Main Windows



## DYNO Window (cont.)

### Run Control



**Start Run Button:** Starts and stops DYNertia3 recording data from a test Run. This can also be done by using a 'page turner' or the shortcut keys allocated to this (menu 'Setup/Software'). During a run the indicator lamp labelled "RUNNING" will flash repeatedly.




The buttons symbol will change from a dial to a set of keys and the text to "LOCKED" when running a test is prohibited, this happens when 'Speed to RPM' button is active. A locked symbol will also show that a selected file is protected and can't be altered or overwritten (locked in the menu option "View/File explorer" using the 'key' icon)

If the DYNertia3 is in Brake 'Point to Point' mode (Setup/Software) then this buttons symbol will alter, Please see chapter "Setup Menus" for details of this mode.



## DYNO Window (cont.)



**Note:** Comments field shown here will be replaced by a row of gauges if single monitor screen is used. Pressing the “Gauges” button will expose this ‘comments field’.

### Correction Factors

The current weather conditions- temp, relative humidity and absolute barometric pressure can be used so that environmental corrections can be applied to the data. Refer to the chapter “Weather Correction”.

### User Comments Field

Any notes and data you wish to record (eg. engine data, customer details and modifications) can be entered here to store with the test. Refer to the chapter “Test Notes- Add/Save”.

### Output controls and Status



Brake and User controlled outputs. Refer to the chapter “Outputs- Using”.



Recording audio files is done by pressing this ‘Mic Input’ button on the ‘GRAPH’ or ‘DYNO’ screen (turns microphone on/off) to record during the duration of the run. Enabled in menu “Setup/Software”

An audio file (.wav) will be saved along with the completed run file. Files will be visible along with the normal ‘run’ files in ‘File Explorer’. ‘Clicking’ on the audio files name will open a small screen allowing the file to be played. This can be used to simply save a commentary during a test or to record the actual engine noise.



‘Losses’ system status. A tool that measures and applies a correction for dyno system losses (friction, windage etc) and also for vehicle driveline losses. Refer to chapter ‘Losses correction’. Pressing on this symbol will open the menu to allow quickly changing.



‘Dyno Mode’ indicator, shows if ‘Brake’ or ‘Inertia’ type dyno has been selected in menu choice “Setup/Hardware”.



‘RPM Source’ indicator shows if the RPM source is from the ‘RPM adapter’ (spark plug icon) or speed sensor (roller icon) as set in the menu “Setup/Hardware”. Pressing on this symbol will open the menu to allow quickly changing.

# Chapter 6: Overview- 2 Main Windows



## DYNO Window (cont.)


### Dial Gauge Displays

Left hand dials are active for viewing when the “Gauges” or “Speed to RPM” button is pressed, also during a ‘Run’. The range of the gauges is set in the ‘Scales’ menu or by clicking on the dials.

#### Power & Torque dials:

**Note:** Power and Torque gauges only operate if dyno is a ‘brake’ type dyno, as setup in “Setup/Hardware”.

**RPM/Speed dial:** Dials display either RPM or speed depending on the operating mode set by the ‘mode’ button (icon of a ‘gauge’, Top Left of active screen).



**Tip-** The RPM dials source will depend on the settings in “Setup/Hardware” regarding the ‘RPM Adapter’ input, see “RPM Input options” chapter of manual for full details.

### Gauges Mode



**Data Gauges ON Button:** Reveals the data acquisition dials, strip charts (shown above) and enables the dial displays to display live information (i.e. not just to be used for analysing graph traces).

This function is used for ‘steady state’ tuning when using a load cell, monitoring engines whilst testing or for setting up an engine to confirm that DYNertia3 is receiving accurate data and that all settings are correct, especially the gear ratio settings (i.e. that the ratio of dyno speed to engine speed is correct and RPM/speed reads correct). This mode can also be used to calibrate vehicle speedometers.

**Note:** Rotation of the flywheel is required for these dials/charts to display data! To view data without rotation use the menu choice ‘Utilities/Data Diagnostics’ instead.

### Speed to RPM (ratio setting)



This button reveals a window used to quickly set gear ratios if required for RPM input setup. Refer to the chapter “RPM Input Options”

**Strip Charts:** Scales come from the settings in the menu option ‘Scales’ and charts can be paused by pressing the button ‘Pause Charts’ at the bottom.

**Note:** The RPM/speed chart is active whenever the ‘Gauges’ button is active but the Power and Torque charts (like their corresponding dial gauges) only operate if dyno is setup as a ‘brake’ style dyno in ‘Setup/Hardware’.

**Data Dial Gauges:** All 5 data channels are displayed, but channel 5 is unavailable if the dyno is set as a ‘brake’ style dyno in ‘Setup/Hardware’, as in this mode the load cell must be connected to this channel!

Names displayed above the dials come from the channel names in menu option ‘Setup/Sensor Configuration’ and scales are also obtained from these menu settings.

Every gauge has a programmable alarm feature that can be set under menu “Setup/Data Limits Alarms”. When triggered the ‘ALARM’ lamp display turns red or orange.

# Chapter 6: Overview- 2 Main Windows



## GRAPH Window


### Tool Bar Button Functions



**Exit:** Saves and exits DYNertia3.

**Print:** Opens the printing menu, same as the menu option "File/Print".

**RPM/Speed Mode:** Switches the dyno from displaying RPM as the graph X-axis to speed, also alters the RPM/Speed dial gauge. Speed is applicable for a chassis dyno when the roller circumference has been correctly entered in the menu option "Setup/Hardware".



**GRAPH/DYNO:** Switches between the Dyno Window and the Graph Window. Switching automatically to this Graphing Window after a test can be chosen in the menu option "Setup/Software/Auto Display Graph of Last Run".


### Selecting Trace to Analyze



Each button selects the data trace on the graph to be analysed (L = Last run). The chosen trace is the one that will have its values displayed by the dial gauges as the cursor 'cross hairs' are positioned along it.

**Tip-** Cursor colour matches the colour of the trace selected.

### Selecting Trace to Display



To 'hide' a trace 'click' on its tick box  To change its colour 'click' on the coloured bar. To view associated data and notes 'click' on the "?" button.

# To actually load a 'Run' trace to view, click on the trace number button (Left Hand of each panel, in this case trace "3") and the 'File Explorer' screen will open to the files location to allow previewing and selecting (by Left and then Right Clicking on it) of any stored Run file. See chapter "Loading and Viewing Files"

The "?" button for each trace will display the main test data in summary and any recorded notes can be viewed and edited by selecting the appropriate tab.



Trace Set 2 - Information (View Only) : TL1000 retarded 7 degrees test 1					
<b>DYNertia</b>					
Ambient Temperature	15 C	Date	13/05/09	Max Power	85.28262
Barometric Pressure	1009 mB	Time	5:22:48 PM	Max Torque	96.22089
Relative Humidity	62 %	Duration	5.186838 Secs	Max RPM	10637.68
Correction Factor	1.014582 %	Gear	Ratio 4	Max Speed	217.1804
Correction - SAE J1349		Ratio	2.982933:		
<a href="#">Engine 1</a> <a href="#">Engine 2</a> <a href="#">Transmission</a> <a href="#">Tyres</a> <a href="#">Customer</a> <a href="#">General</a> <a href="#">Run</a>					

If you click on the Power and Torque coloured header section (pink in this example) you can select any display colour from the pallet to associate with this trace number, it will be stored permanently.

**Tip-** The colours chosen are also used for printing (on a white background), so keep this in mind and avoid very light colours if printing is planned.

# Chapter 6: Overview- 2 Main Windows




## GRAPH Window (cont.)

### Graph controls

The horizontal graphs X-scale is either RPM or speed depending on the operating mode set by the 'mode' button (icon of 'gauge', Top Left of screen).

Based on whichever data trace you have selected (buttons under RPM/speed dial) you can Click on the screen to produce a measurement cursor ('cross hairs') that can be moved to any spot by Clicking or dragging the 'Slide control' at the bottom of the screen. The relevant measurement information will be displayed on the dial gauges.

"◀ ▶" buttons (lower Left & Right corners) allows the trimming (or 'zooming in') of the trace image by moving the graph start and finish points, this can also remove any unwanted trace sections, particularly useful for ensuring the printed image appears as you wish.




**Tip-** To permanently trim Run traces there is a function under the menu choice "File/Trim Runs".


"▲ ▼" buttons (lower Left & Right corners) allows the trimming (or 'zooming in') of the trace image by altering the graph Power and Torque scales, this can also remove any unwanted trace sections, particularly useful for ensuring the printed image appears as you wish.

**Tip-** The scales will initially be selected from the graph scale settings you have chosen (start and finish RPM/speed).

"?" button (lower Left corner) will open a panel that shows key summary data for all of the loaded traces. Operating "Mode" (Inertia or Brake) that the dyno was set in during testing is also shown here.




**Tip-** 'Double clicking' on any row will bring up a full information screen on that trace



The "Comments" button in lower Right corner opens the recorded notes that can be viewed and edited for the selected trace, chosen using the 'Trace Select' buttons in lower LH corner of the GRAPH screen.

## GRAPH Window (cont.)

### Data displays



Traces for the input data channels 1 & 2 (labelled CH1 and CH2) appear overlaid on the graph, they can be turned off in the menu option "View/Trace Visibility" if required.



**Tip-** Positioning the mouse over the "CH1" and "CH2" scale labels will reveal whatever channel description is being used i.e. "CH1" may be configured as Lambda so "Lambda" will be displayed.

A 'floating' data values box can be activated on the graph to show the values of all data channels at the point marked by the graph's cursor.

The data box is turned on/off with a mouse 'click' over the right hand graph scale.



'Clipboard' menu allows you to 'paste' the data displayed in the data box onto the Windows 'clipboard', this means you can paste it into any text program you like, such as 'Word' or 'Notepad'. Ideal if you want a permanent record of all the data that is displayed at the cursor location on the graph. Along with the data are copied details of the displayed traces.

Due to the quantity of data, allocated channel names are not displayed. To view allocated Channel names and know what data is being shown in the box, position your mouse over the channels digits and text will appear i.e. it might say "Case temp" or whatever name you have allocated to the channel/sensor.

88	888.88	888
88	888.88	888
88	888.88	888

**Tip-** The data value box's transparency (activated from its menu) level can be adjusted in the menu option "Setup/Software/Display" so that it does not obscure the view behind it. The box can be freely dragged by its border to any screen position ('click and drag' the box's edge).

## Run Time Gauges/Charts (Visible only from 'DYNO' Window)

### RPM and Speed Scales


The "Scales" menu (visible only from DYNO window) sets the max scale for the RPM/speed dial gauge only when displaying in 'real time'; when the 'Speed to RPM' or 'Gauges' buttons are pressed and during testing. Chart speed is also configured here.

Will show units of speed or RPM depending on mode setting in main Windows ('dial' icon)

**Note:** When the Gauges are used for analysing graphs (showing the value at the cursor) their scale is automatically selected based on the scales used in the GRAPH Window, not this setting.

Torque gauge maximum value will also affect the Power gauge as this is automatically scaled (based on the RPM value entered)

**Note:** The Torque and Power settings are only visible when in 'Brake mode' as this is the only mode 'real time' Power/Torque gauges operate in during a run.



**Tip-** Clicking on the gauges dials will also open up this 'Scales' menu option.

# **Chapter 7: Weather Corrections**

**Weather corrections**


**'Weather Watch' weather station**

**Viewing weather data**

# Chapter 7: Weather Corrections



## Correction Factors




The current weather conditions- temp, relative humidity and absolute barometric pressure can be used so that corrections can be applied to the data. This allows tests to be corrected to a standard set of atmospheric conditions and allows consistency as the environmental test conditions change. If manually applying (eg. from a third party weather station) then it's important to keep an eye on your weather station whilst running tests, you will be surprised how quickly conditions change!

An optional accessory USB device called 'Weather Watch' is available that automatically interfaces with DYNertia3 and updates the readings at regular intervals. Refer to this manual under 'Menu options- "Setup/Communications" for details on connecting (known as 'Linking').

**NOTE:** Barometric pressure figure used should be 'absolute' and not 'corrected'. Corrected is given in the typical news weather report. We want the actual measured pressure at the Dyno and not one corrected to sea level.

Correction to world standards SAEJ607, SAEJ1349, DIN70020 or uncorrected can be applied via the menu option "setup/software/System". The correction factor being applied, weather data entered and the selected correction standard are recorded automatically with each test for reference. SAE J607 is chosen by default as it is in widespread use.



## WARNING


DYNertia2 will not allow correction to exceed +15%. RUN is Disabled

If weather data causes excessive correction then a warning will appear and runs will be prohibited until values entered reduce the correction factor within range.

## Viewing Weather Data


Allows the viewing of the weather data from the optional DTec 'Weather Watch' automatic weather station. Ensure it is connected and configured to a PC USB port via "Setup/Communication".

In the menu option "Utilities/Current Weather Data" you can view the live data from the optional 'Weather Watch' station including RAD (Relative Air Density).



The chart speed can be adjusted to suit your monitoring requirements with the 'Chart Speed' control.

**Tip-** The Relative Air Density (RAD) is also displayed for tuning purposes and can be recorded as a reference. Please see the 'Weather Watch' documentation for more information on RAD and other 'stand alone' tuning features.



The 'RAD Reference' button saves the current RAD at the time it is pressed so any changes, and therefore air/fuel mixture changes, are easily noted.

# **Chapter 8: Loading/Viewing Files**

**Loading files into the Graph Window**

**'File Explorer' Window**

**Secondary Graph Window**

**Basic Viewing of files on Graph Window**

## Loading of files into ‘GRAPH’ Window

### Previewing (DYNertia3 File Explorer) and Selecting Files

Loading files into the GRAPH Window is a key function. It is only loaded files that can be then selected and analysed in the other Windows of DYNertia3. The Main GRAPH Window is itself also a convenient screen to overlay and compare test results.


If you have just performed a test then this ‘Graph’ Window will appear automatically if menu ‘Setup/Software’ “Auto display of last run” is selected (default setting). The last test Run you did will appear as a red trace (not shown here) and any others already ‘loaded’ will be shown as various alternate coloured traces.

**Tip-** DYNertia3 already has some test Runs in a folder called ‘Samples’, use these to practice loading and viewing files and to learn the software operation.



**NOTE:** It is only ‘loaded’ files that can be then selected and analysed in the other screens of DYNertia3

‘DYNertia3 File Explorer’ is used to pick a storage Folder of choice and when each file within it is selected (one Left ‘Click’) its data table, general notes, key data and preview graph are shown.



Traces to view and analyse are ‘loaded’ onto the Graph screen by using the coloured boxes beneath the graph. There is one for each of the 5 traces (10 counting secondary screen traces) that can be viewed.

To load a new trace into the graph for viewing or to change an existing one ‘Click’ on a trace number (button numbered “3” in this example above), this will open our ‘DYNertia3 File Explorer’ screen where we can select a run to be shown as trace ‘3’.

Single ‘Right Click’ on a file of interest and it will be loaded as the new ‘trace set’ back in the main graph screen! (Left Click first to highlight, shown next page)


‘DYNertia3 File explorer’ can also be opened from the ‘DYNO’ screen (button as shown to right), from the menu option ‘View/DYNertia File Explorer’ or by pressing ‘ctrl + F’ buttons as a shortcut.

# Chapter 8: Loading / Viewing Files



## DYNertia3 file Explorer

In 'DYNertia3 File Explorer' you can pick a directory Folder of choice and when each file is selected (one Left 'Click') its data table, general notes, key data and preview graph are shown.



Preview files by selecting and viewing the sample graph and data table; if the graph is Clicked on then the values at the cursor will be also highlighted in pink in the data table (to the nearest data set) and vice versa.

# 'Right Click' on a selected file of interest and it will be loaded as the new 'trace set' back in the main graph screen.



If you are selecting a Folder that you wish to use to save runs into, or that's contents will need to view for naming test Runs into, then press the 'File Storage' icon (top Left) and it will become the default file path for saving new files into and will open whenever DYNertia3 File Explorer is opened.

**Note:** It is important when selecting or creating a Folder to save runs into that this button is used. It will be these Folders contents that are shown in the main Dyno screen!

**Tip-** Maximum data values, test time, date and notes stored in the 'general' section of the comments are also indicated in DYNertia3 File Explorer's top header panel.



**Locking Files:** The 'key' symbol button will lock or unlock a file so that accidental overwriting can be prevented i.e. You won't be able to pick that file and re-save a test run over the top of it or modify comments. A locked file is indicated by a red box "File Locked", unlocked by green box "File Unlocked" when selected.




**File Type:** Symbols show if data is a continuous trace or was built up in 'Point by Point' testing mode as is usually done when 'steady state' testing on a brake style dyno.





**Losses Correction Status:** Shows if losses correction was applied to the test results. See chapter "Losses correction".

# Chapter 8: Loading / Viewing Files



## DYNertia3 File Explorer (cont.)



**Maths Channels:** Opens screen to generate and apply mathematical functions to generate extra data channels. This function will be explained fully in the chapter "Maths Channels".



**Find All:** Is a screen to help search and locate any test Run files on your computer.

When you select a Folder it will display all files that have the extension "DYN2" or "DYN3" as these are your saved test Runs.



**Tip-** 'Click' on a file name to view associated comments.



If you are selecting a Folder that you wish to use to save runs into, or that's contents will need to view for naming test Runs into, then press the 'File Storage' icon (top Left) and it will become the default file path for saving new files into and will open whenever DYNertia3 File Explorer is opened.




**Trace Information:** Shows all of the information relating to the highlighted test Run.



# Chapter 8: Loading / Viewing Files



## Creating / Deleting folders for tests



Next to the Folder list is a black arrow "►", 'Clicking' on this will open a menu that allows you to create or delete new Folders easily.



Once you type in a Folder name, press the button shown to create the Folder and also set it as default. It will then be used to save files into and view when explorer is opened.



Pressing this will create the Folder but not set it as the default. Used if you are just creating Folders in preparation, but not yet using.



Pressing will delete a selected file. You will be warned if it is in use i.e. already selected in a graph screen.



Pressing will delete a selected Folder.


**Tip-** You can create, delete, move and alter file names in 'Windows Explorer' just as with any Windows program. Changing file names and locations whilst in use or selected will cause DYNertia3 to obviously produce error messages (it can't find them any more). You will need to re-select your files of choice from their new location. Do not rename the actual 'default' Folder being used by DYNertia3, an error will occur!

# Chapter 8: Loading / Viewing Files



## Reviewing Audio Files


Audio files can be used to save a commentary during a test or to record the actual engine noise.



If the 'Media' option in the menu choice "Setup/Software/General" is enabled then there will be audio files (.wav) visible along with the normal 'run' files (.DYN3) in 'DYNertia3 File Explorer' (assuming you have some audio tracks recorded).

Recording audio files is done by pressing the 'Mic Input' button on the 'Graph' or 'Dyno' screen (turns microphone on/off) to record during the duration of the run. An audio file (.wav) will be saved along with the completed run file. This can be used to save a commentary during a test or to record the actual engine noise.


'Clicking' on the audio files name will open a small Window allowing the file to be played and reviewed.




The controls are standard audio symbols with the exception of the middle 'Loop' button that sets a repeat play function.

The section of recording can be narrowed down by using the 'Mark In and Mark Out' controls, these determine the start and finish time of the recording that is actually played back.

## Secondary GRAPH Window



To allow the viewing and Analysing of up to 10 trace sets there can be opened a second Graph screen. This appears very similar to the main Graph screen but has limited menu options as it is for selecting, viewing and printing, not controlling dyno functions.



This second Graph screen can display 5 traces; it is ideally suited to PC's with dual monitors connected as can then reside on the second screen

It is loaded with files the same way the main screen is, via a 'Click' on a trace number (numbered buttons beside each coloured band).

All controls and menu functions are the same as the main Graph screen so will not be covered here.

# Chapter 8: Loading / Viewing Files



## Viewing Files ('GRAPH' Window)

### Adjusting Graph appearance

The main GRAPH Window is convenient for quickly comparing runs and is a powerful analysis tool in its own right!

**Note:** Refer to manual section "Overview- 2 Main Screens" for information on GRAPH screen controls.

**Note:** Also refer to manual section "Trim, Join & Merge Runs" for important information on manipulating traces!



### Zooming

The scales are automatically set of the highest data values. To 'zoom' in or 'trim' the graph use the "◀ ▶ ▲ ▼" buttons in the lower graph corners.

### Clear Graph Trims

Menu "View/Clear Graph Trims" clears all of the manual adjustments (Zoom) made to the graph scales and returns to the automatic scale selection.


**Tip-** There is a menu option "File/Trim a Run" that creates and saves a new file using whatever start and stop RPM points you choose. This is good to permanently remove any unwanted sections of a trace that may occur due to poor setting of the 'Run Minimum & Maximum' speeds!



Traces to view and analyse are 'loaded' onto the GRAPH screen by using the coloured boxes beneath the graph. Un-checking a traces Check Box will hide it from view, it does not remove it. Check it and it becomes visible again. Handy when the graph screen is getting cluttered or for printing only selected traces.


### Clear Graph

To remove traces off the screen (un-load them) press your keyboards 'Shift' and 'Delete' button (or menu option "View/Clear Graph"). Files are not harmed; they are just not selected for viewing



### Trace Visibility

Individual data can be removed from view on the graph using the "View/Trace Visibility" menu.



### Grid

Found in menu "Setup/Grid", allows the grid lines to be removed from the graph, this effects printing also as what is on the screen is what is printed.

**Tip-** 'The export functions found under the 'File' menu also give you the freedom to export to Microsoft's 'Excel', this opens up infinite possibilities to graph and analyse the data as required.

## **Chapter 9: Trim, Merge & Join Runs**

**Trim- change start and end points**

**Merge- create an average of 2 runs**



**Join- merge data points into a single trace**

## Trim a Run

Trimming a Run cuts off any RPM points above and below the RPM range selected. This is used to remove permanently any sections of your Run trace you do not wish to have, particularly if your RPM start and finish points were not set ideally and you have a 'messy' looking trace or have a large part of the RPM scale not used.

The new trimmed Run trace will be saved under a name of your choice as a whole new file!


1. Choose the trace number set you wish to trim with the selection buttons
2. Set the Min and Max RPM you wish to have remaining in your data
3. Press the "Trim" button and you will be prompted to name the file and choose a location to save.



**Tip-** For fast setting of the RPM points use the "+1000" buttons, this will increment the adjustments by 1000 RPM at a time.


## Merge Runs

Multiple Runs can be ‘merged’ together to form a new ‘averaged’ Run. This function is particularly useful when multiple Runs have been performed and only slight variations exist, you may wish to create an average of these to smooth out the variations. Many testers do multiple Runs after any modification to ensure consistency, merging compliments this practice perfectly.



A merged Run will be based on up to 4 visible traces (2, 3, or 4). It is required that trace set “1” be loaded and visible as this is used as the ‘master’ when DYNertia3 generates the new data (any of your recorded comments will copy from this to the new file). The files merged will be all of the ones visible on the Graph Window. The new averaged Run will be loaded as the ‘last run’ trace automatically. After the new averaged Run is created you will be asked if you want to hide the other graph Runs so only the new one remains visible.

**Tip-** The menu option “View/Clear Graphs” (or ‘Delete’) can be used to clear all of the graph traces so you can pick entirely new ones to merge if you wish.



**Note:** ‘Point by Point’ Runs (those done in brake mode by storing individual data sets) cannot be merged. They can however be joined, that is to combine all data into 1 set. This is done with the in the menu option “File/Join Runs”

The new ‘averaged’ Run will appear as a complete data file and is treated just like any other Run. The General comments field of the new files notes will automatically have appended a list of the files that it was generated from.

There are different methods used to indicate that a file is the result of merging multiple Runs, depending on the screen-



An “!” symbol will appear next to the run when a ‘graph summary’ is viewed and ‘DYNertia3 File explorer’ has a note on top of the preview graph.



For indication purposes the weather correction data from the chosen runs is also averaged into the new weather fields as is the actual correction figure generated by them.

**Tip-** It is not suggested to merge runs that have been performed under different weather correction standards i.e. don’t merge SAEJ607 runs with DIN 70020 etc. as the result will be meaningless for analysis, as will be the result if the original runs vary greatly from each other.

## Join Runs

Multiple ‘Point by Point’ tests can be ‘joined’ together to form a new ‘combined’ test. This function is particularly useful when multiple data sets have been recorded in certain RPM ranges and you wish to combine all of the data into a single common set. Many testers do small lots of testing at particular points of interest, joining compliments this practice perfectly.

A ‘joined’ Run will be based on up to 4 visible traces (2, 3, or 4). It is required that trace set “1” be loaded and visible as this is used as the ‘master’ when DYNertia3 generates the new data (any of your recorded comments will copy from this to the new file). The files merged will be all of the ones visible on the Graph Window. The new trace will be loaded as the ‘last run’ trace automatically. After the new joined Run is created you will be asked if you want to hide the other graph Runs so only the new one remains visible.



**Tip-** The menu option “View/Clear Graphs” (or ‘Delete’) can be used to clear all of the graph traces so you can pick entirely new ones to join if you wish.

**Note:** Only ‘Point by Point’ Runs (those done in brake mode by storing individual data sets) can be joined. The screen image above shows a red indicator that one of the traces was not ‘Point by Point’!

The new ‘joined’ Run will appear as a complete data file and is treated just like any other run. The General comments field of the new files notes will automatically have appended a list of the files that it was generated from.

If there are ‘gaps’ between the data sets you will be warned, but joining will still continue. This is to let you know that the data doesn’t overlap e.g. there may be a big gap between RPM finish of one trace and RPM start of another, therefore the trace may have a ‘Hole’ in the data.

When joining data sets with overlap of RPM points (as is best to avoid ‘gaps’) precedence is given to the lowest numbered trace e.g. if 1 and 2 are joined the overlapping points from 2 will be disregarded.

There are different methods used to indicate that a file is the result of joining multiple data sets, depending on the screen-



An “!” symbol will appear next to the run when a ‘graph summary’ is viewed and ‘File explorer’ has a note on top of the preview graph.

For indication purposes the weather correction data from the chosen Runs is also averaged into the new weather fields as is the actual correction figure generated by them.

**Tip-** It is not suggested to merge runs that have been performed under different weather correction standards i.e. don’t merge SAEJ607 runs with DIN 70020 etc. as the result will be meaningless for analysis, as will be the result if the original runs vary greatly from each other.

# **Chapter 10: Test Notes- Add/Save**

**Adding notes to tests**

**Save/attach notes to other test files**


# Chapter 10: Test Notes- Add/Save




## Adding Test Notes

### 'User' comments field


Any notes and data you wish to record (eg. engine data, customer details and modifications) can be entered here, there are pre-defined fields and a general notes area. The information is stored along with the test data when the Run is performed and can be reviewed and even altered when a saved file is loaded.



**Accessing User Comments:** There are several ways to access the comments fields depending on what screen you are in and if dual monitors are in use.




Notes can be quickly entered before testing by using the comments field. This may not be visible with a single monitor as it is replaced by a row of gauges. Press the 'Gauges' button to toggle the view.



In the lower Right hand corner of the GRAPH screen is the button to open the comments for the selected run. They can be viewed and edited.

**Note:** To select the trace of interest use the buttons below the dials on the Left hand of GRAPH screen.



The menu option "View/Comments (Selected Run)" will open the comments fields for the selected run.

**Tip:** You can lock any file to protect it from accidental change in the menu option "View/File Explorer" ('key' icon). If a chosen file is already locked when selected, the "Start Run" button changes to "Locked" (image of a set of keys).

# Chapter 10: Test Notes- Add/Save




## Templates

### Saving notes and applying to other tests

If you have entered details into the comments field below (from the DYNO screen) and you want to apply them to other tests without having to retype your notes, then save it as a 'Template' with the 'Save' button in the top Right corner.



The applied information can be further added to or altered at any time.



To apply it to any other files use the 'Load' button.

**Tip-** A 'Template' of the information can be created and saved without having an actual test file open.

When the template is saved or attached it will transfer some dyno settings also (gear ratio, weather correction standard used, min start RPM and the test gear), this is to speed up retesting on vehicles/engines by simply attaching a previous made template if you wish. Templates are saved as special files ("."DIT").




When applying a saved template to a file, a choice of what data entries you wish to attach will become available e.g. you may be testing the same vehicle as previously but wish to only add new general comments due to modifications.

Tick the appropriate box's and press the 'load' button to apply.

**Tip-** In menu "Setup/Software/Run Comments" you can select to have '**Comments added to each new run**', this allows comments you have made to be automatically transferred to the next test. This function is designed for quick testing i.e. you are doing multiple tests of the same modification. Without this each new test has all its comments cleared.

**Note:** Does not apply to the operator and company name, these are pulled in from the user details.



# **Chapter 11: Printing & Exporting**

**Printing screens**

**Adding comments to print**

**Exporting data**

## Printing

### General Printing



Many Screens allow you to print. Generally the printout is ‘what you see is what you get’, which means it is important to set up the screens appearance first to produce the best results.

A common error is not setting up the X-axis (RPM-Speed) to avoid too low or too high a scale, especially if the test start and stop conditions were poorly setup in the “record settings field” when testing.

You can alter the trace images on the main GRAPH Window using the **▲▼▶◀** symbols, the scale set here is often carried over into other analyser screens. Graphs traces can be permanently ‘Trimmed’ (‘File’ menu) to also adjust the appearance




**Print:** Button initiates the printing and gives any options available for a particular Window you wish to print from. This can include the choice of pages to preview if appropriate (detailed graphs and data printout has multiple pages).



**Setup Printer:** Menu option “Setup/Printer” opens a window that allows you to Select a printer to use, add a new printer or correct offset.


A separate print ‘help’ menu is also revealed and this should be read!



**Tip-** You can print to a PDF writer if you wish to save the image as a PDF document rather than print directly. There are many free writers available (one is loaded with DYNrtia3 called ‘PDFill’)



**Offset Correction:** A trial print on A4 should be done first, If not aligned properly then this button will allow for the image to be shifted on the page when printed; most printers have a positioning error to some extent. When aligning, the image will not alter its position on the screen, only on the actual page printed.




# Chapter 11: Printing & Exporting




## Printing main Graph screens


Printing the images from the main GRAPH Window is done from the usual print icon.



**Graph only option**




**Summary Graph and data**



**Detailed graph and data**

**Tip-** Printing follows the format of the main Graph Window, scales and traces selected there are as printed.



Printing from the main Graph Window reveals a preview Window that has several buttons as explained below. The preview Window will change based on the printout type selected.



**Dyno Operator:** The name of operator can appear on the printout if desired.



**Information for Printed Output:** Information entered here appears on the 2<sup>nd</sup> printed page (information summary page).



**Print:** Button will print the pages.




**Select Page:** Multiple pages are available for printing, a graph page that gets its image from the main Graph Window, summary page and detailed information pages that shows key data from the selected traces on the graph.

# Chapter 11: Printing & Exporting



## Customising your printout


The logo in the printouts can be user defined. It must be a 'BMP' image, it should have a 2:1 aspect ratio to appear undistorted when viewed. In the menu "Setup/Software" is a button that opens the user details form as below-



**User Details and Company Logo:** Data and your logo image used here appears on the printouts. The logo can be inserted by pressing the "Add" button or if you do not wish to use a logo, press "X" button.

The user details appear on the detailed and summary printouts.

**Customer Disclaimer:** A disclaimer notice can be saved and printed for issuing to the customer prior to dyno testing. It is up to the user to produce a legally binding disclaimer in line with their local regulations.



When the print button is pressed a form opens to allow vehicle information to be entered and this will be added to printouts.




The name of operator can appear on the printout, if desired, by pressing the user button when shown.



The detailed printout option allows greater information to be displayed; it appears on the 2<sup>nd</sup> page and is entered by using the comments button.

In some screens this button will open a general comments form that will generate notes that can be placed on the actual graph, see "Notes To Print" section for details.



## Notes to print

### General comments for printing

Several screens allow the addition of single notes superimposed for printing. The main Graph Window has its own menu.




**Produce graph comment for printing:** Type in your comment, press 'text' button and when you click on the graph the text will appear. Use the eraser button to delete the text comment or to redo for placing again. The arrow button returns without making a change.



### Produce comments on the main graph for printing

Choosing this menu option will open the Window below. Type in your comments, press text and when you click on the graph the text will appear. Use the eraser button to delete the text comment or to redo for placing again.




**Note:** Clearing the graph traces will clear the comments (menu 'View/Clear Graphs' or pressing 'Shift' and 'Delete' key)

# Chapter 11: Printing & Exporting



## Exporting data

Data tables can be exported into Microsoft Excel directly (with or without field headings included) or a general delimited text file (CSV) can be generated (exported files follow either Metric or imperial depending on the current operating mode). Alternatively the main graph image can be exported as a bitmap image ('.bmp') for further analysis and file sharing.



	A	B	C	D	E	F	G	H	I	J	K	L	M
1	KPH	Engine RPM	kW	Nm	Lambda	Exhaust Temp	Case Temp	Air Temp	Torque	Slip %	Maths 1	Maths 2	Loss kW
2	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##
3	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##
4	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##
5	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##
6	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##
7	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##
8	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##	#####.##



**Select a Trace to export:** Any of the 10 traces loaded into the main GRAPH Window can be selected.



You can set the RPM increments with the controls (eg every 100 rpm increment) and with this button you can choose to include the actual first and last RPM point along with the RPM incremented points.



You can add field headings to the top of the data columns for meaningful reference when viewing.

Below is shown a 'Bitmap' export of a main Graph Window.



## **Chapter 12: Live Data Viewing**

**Screens for monitoring data live during testing**

**Note:** Not all screens are visible with a single monitor and not all data is relevant to all systems e.g. no live power if in Inertia dyno mode

# Chapter 12: Live Data Viewing





## Gauge Screens

### Observing the engine data

The available windows to view data depend on the fitment of a second monitor.

If a multiple monitors are fitted then there will be a dropdown list of possible display Windows for the second monitor.

**Note:** Press the 'GAUGES' button to turn second display on and off.




Due to limited screen space, with only a single monitor the data is displayed as shown to the Left.

There are chart recorders and gauges for RPM, torque and power, whilst the 4 data channels are displayed on a second set of gauges with alarm limits.

**Note:** Some displays are not relevant with inertia dyno testing i.e. live display of Power and Torque is not possible.

Below is a preview of the Windows available on a second monitor.




This 'Graph' screen is the main one used on a brake style dyno whilst testing. It draws the curve as the test progresses.



**Tip-** "Show Data" button under RH scale reveals digital readout of data at the cursor.


Large clearly visible 'Dashboard' allows easy steady state tuning observations.



# Chapter 12: Live Data Viewing




## Observing the engine data (cont.)




'Tuning' screen allows display of the data with emphasis on input channels.

The alarms and limits ("Setup/Data Alarm Limits") are applied and a bar graph shows deviation from a target (deviation is also selected in "Setup/Data Alarm Limits")



'Large Text' displays selected data in digital format.



There are 'Single' and 'Dual' chart recorders available to select from also.

# Chapter 12: Live Data Viewing



## Observing the Data Channels

The 'Data Channel' viewing and logging Window should not be overlooked for viewing live data in certain cases, though generally it is designed for sensor configuration and calibration.

**Note:** Window is found in the menu "Utilities", not these Gauges selections.

Approx. Aquire Interval (mS) **200**

Data logging to the PC is also available and data is continually written (CSV format) at the intervals set.



To record (log) data a file must be first named by pressing the 'Disc' icon.



You can choose to save 'header' names to the columns of logged data.



Logging data is started by this button.




Log files can be easily previewed with this 'Monitor' button.

The data shown can be in the actual units calibrated for the channels (i.e. channel 1 may be calibrated to show Lambda from a lambda meter), optionally by pressing the "In mV" button the 'raw' mV readings measured are displayed, this is prior to any sensor calibration being applied.

A red "Err" reading means the input voltage or RPM is outside the input range (0 - 5000mV or less than 250RPM) or if a sensor alarm/limit is applied.

**Note:** Torque is automatically selected for channel 5 if you are in 'Brake' mode (only channel used for a load cell!).



**Tip-** This screen is ideal for calibrating sensors as you can use the "In mV" button to display the 'raw' mV readings (0-5000mV).

**Note:** DYnertia internally reads mV from 0-5000, If you add resistors to divide the input voltage down to suit this range (i.e. allowing a 15V range) you are just dividing the input by 3 before it is measured. The 'raw' values will be still in the 0-5000 range eg. 9V input would be 3000mV raw.

# Chapter 12: Live Data Viewing



## Display Current AFR/Lambda

If a Lambda meter (Air Fuel Ratio- AFR) is connected to an input channel then it can be displayed in this indication Window ('Utilities' menu) for high visibility during tuning.



**Note:** Window is found in the menu "Utilities", not these Gauges selections.

The width of the acceptable operating band is set in the "Window" control field. The centre location of the operating band is adjusted with the 'slider' control (shown set at 1 in the images below).

It is important to set the input channel selection button that has the Lambda meter connected (usually channel 1 is used)

**Note:** Both Lambda and AFR units are used; therefore the 'stoichiometric' point of the fuel must be known (so DYNertia3 can calculate AFR from Lambda and visa versa). Choose the fuel from the drop down list or add your own custom ratio by pressing the "C" button (this can also be selected under menu choice 'Setup/Software/Lambda AFR').

DYNertia3 will pick up if you have calibrated your input channel in units of Lambda or AFR by checking if the words appear in the selected sensor name under menu option 'Setup/Sensor Configuration' "Lambda" or "AFR" are the terms it searches for (note the space either side). Knowing this allows DYNertia3 to apply the appropriate calculation to give you both units of Lambda and AFR regardless of your sensor configuration.



If the Lambda reading goes outside the acceptable 'Set Point' range then the gauge surroundings change to a very noticeable red colour to alert that a problem exists.

**Tip-** Filtering (smoothing) values applied to the data can be altered set in the menu 'Setup/Sensor Calibration'.

# Chapter 13: Analysing Data ('View' Menu)

**Analysis tools for getting the most from your recorded data**

# Chapter 13: Analysing Data ('View' Menu)



## Trace Info

Opens a Window that shows the key summary data for all of the loaded traces.

Main Graph Screen							
Source	FileName	Min RPM	Max RPM	Max Power	Max Torque	Correction	Mode
Last Run	No Trace Set Loaded	N/A	N/A	N/A	N/A	N/A	N/A
Trace Set 1	TL1000 Run 001	3000	9840.13	83.3128 kW	98.0789 Nm	1.007258 %	Inertia
Trace Set 2	Merged run 2.002 and 003	3000	9838.56	83.1644 kW	97.5512 Nm	1.007258 %	Inertia
Trace Set 3	TL1000 Run 002	3000	10095.85	83.7097 kW	97.5284 Nm	1.007258 %	Inertia
Trace Set 4	TL1000 Run 003	3000	9786.512	82.4708 kW	97.1527 Nm	1.007258 %	Inertia

Secondary Graph Screen							
Source	FileName	Min RPM	Max RPM	Max Power	Max Torque	Correction	Mode
Trace Set 5	No Trace Set Loaded	N/A	N/A	N/A	N/A	N/A	N/A
Trace Set 6	Merged run 001 and 002	3000	9838.56	83.1644 kW	97.5512 Nm	1.007258 %	Inertia
Trace Set 7	Merged run 002 and 003	3000	9838.56	83.1644 kW	97.5512 Nm	1.007258 %	Inertia
Trace Set 8	No Trace Set Loaded	N/A	N/A	N/A	N/A	N/A	N/A
Trace Set 9	No Trace Set Loaded	N/A	N/A	N/A	N/A	N/A	N/A

**Tip-** "?" button in the lower Left corner of a viewed graph is the shortcut.

Double 'Click' on any trace set listed to open up the detailed 'Trace Information' screen shown below.

DYNertia3 Selected Trace - Information

Filename : C:\DYNertia3 Run Files\Samples\TL1000 Sample Run 3.DYN3

Gear / Ratio Configuration

Ratio Used : 2.7812:1 Ratio 1	Date / Run : 2014/03/20
Gear Ratio 1 : 2.7812:1	Time of Run : 10:38:49 AM
Gear Ratio 2 : 1:1	DYNertia Version : File Type : DYN3 - DBV : 3.0.0
Gear Ratio 3 : 1:1	Ambient Correction
Gear Ratio 4 : 1:1	Temperature : 24 Degrees C
Gear Ratio 5 : 1:1	Pressure ( millBar ) : 986
Gear Ratio 6 : 1:1	Relative Humidity ( % ) : 59
Gear Ratio 7 : 1:1	Correction Factor ( % ) : 1.024253 RAD % : 93.7012
Gear Ratio 8 : 1:1	Correction Mode : Correction - SAE J1349
User Ratio ( 9 ) : 1:1	

Data Configuration

Data 1 Title : Lambda	Data 1 Scale Min : 0.61	Data Ch1 ON : <input checked="" type="checkbox"/>
Data 1 Sensor : Tech Edge 3A1/3A2 Lambda	Data 1 Scale Max : 1.29	Data Ch2 ON : <input type="checkbox"/>
Data 2 Title : Exh Temp	Data 2 Scale Min : 0	Data Ch3 ON : <input type="checkbox"/>
Data 2 Sensor : 0-1500 C DTec ThermAMP	Data 2 Scale Max : 1500	Data Ch4 ON : <input type="checkbox"/>
Data 3 Title : Case Temp	Data 3 Scale Min : 0	Data Ch5 ON : <input type="checkbox"/>
Data 3 Sensor : 0-1500 C DTec ThermAMP	Data 3 Scale Max : 1500	
Data 4 Title : Air Temp	Data 4 Scale Min : -11.04	
Data 4 Sensor : File:Bosch 026 C (1K pullup to 5V).csv	Data 4 Scale Max : 114.25	
Data 5 Title : Batt V	Data 5 Scale Min : 0	
Data 5 Sensor : 0 - 15 V	Data 5 Scale Max : 14.78	

Maths Configuration

Math 1 Title : Maths 1	Math 1 Scale Min : 0	Maths 1 : None
Math 1 Desc. : No Calculation	Math 1 Scale Max : 5000	Maths 2 : None
Math 2 Title : Maths 2	Math 2 Scale Min : 0	
Math 2 Desc. : No Calculation	Math 2 Scale Max : 5000	

General Configuration / Settings

Date of Run :	2014/03/20
Time of Run :	10:38:49 AM
DYNertia Version :	File Type : DYN3 - DBV : 3.0.0

Run Summary

Run Duration :	2.985404 Seconds
Max. RPM :	8991.759
Max. Speed :	196.8928 KPH
Min. RPM :	4524.269 RPM
Min. Speed :	99.06802 KPH
Max. Power :	86.75687 kW
Max. Torque :	105.6407 Nm
Inertia :	4.9 Kg/M^2
Loss Correction :	No Losses Correction
Loss File :	N/A

Mode

Inertia Mode      Continuous

General Comments

TL1000 Sample Run 3 - No losses systems activated  
Single Inertial Mass with a disc brake fitted  
Run Performed in 4th Gear

Expressions used for Maths 1 and Maths 2

Maths 1 : None  
Maths 2 : None

## Secondary Graph

To allow up to 10 traces to be analysed a secondary Window can be enabled, especially useful if you have dual monitors fitted and enabled as it can be displayed there. This Window allows selection and control of traces, just as the main Graph Window does.



# Chapter 13: Analysing Data ('View' Menu)



## Individual Trace Set

Shows all of the available data for a single chosen Run.

Individual data channels for the chosen Run can be turned on/off ('eye' visibility buttons in the menu bar) and the trace being viewed can be from any of those loaded and selected into the main dyno 'GRAPH' screens. Only available Runs and their active data channels will have the buttons highlighted for operation!



'Floating' data value box is activated by a 'Click' in the Right hand scale margin to turn on/off. Cursors are used to help analyse the information, position the mouse and 'Click' on the graph. The cursor can also be 'Dragged' by holding the mouse button down whilst moving over the graph.

**Tip-** The data value box's transparency level can be adjusted in the menu option "Setup/Software" so that it does not obscure the view behind it. The box can be freely dragged by its border to any screen position ('Click and drag' the box's edge).

Clipboard menu allows you to 'paste' the data displayed in the data box onto the Windows 'clipboard', this means you can paste it into any text program you like, such as Word or Notepad. Ideal if you want a permanent record of all the data that is displayed at the cursor location on the graph. Along with the data are copied details of the displayed traces.

Scale on Left side is power (as all other units are on Right axis).



**Select a Trace to view:** Any of the 10 traces loaded into the main GRAPH Window can be selected.

**Tip-** The cursors horizontal bar can be used as a guide to read of values from the Left axis if required (if 'floating box' is not being used for example)

**Tip-** The RPM scale is taken from the main graph screen, so trimming the main graph (e.g. using the corner arrows) will vary what is seen in this screen.




**Information:** This button will reveal a summary table (Trace Info) of the data associated with the trace set currently being viewed.

General Configuration / Settings		Run Summary	
Run Duration:	2.385404 Seconds	Max. RPM:	8991.79
Date/Run:	2014/03/20	Max. Speed:	196.8926 KPH
Time/Run:	10:38:49 AM	Min. Speed:	4524.269 RPM
DYertia Version:	[File Type : DYN3 - DBV : 3.0.0]	Min. Power:	99.06802 KPH
Ambient Correction	Temperature : 24 Degrees C	Max. Power:	86.75687 kW
Pressure (mbar):	986	Max. Torque:	105.6407 Nm
Relative Humidity (%):	59	Inertia:	4.9 Kg/M^2
Correction Factor (%):	1.024253	Loss Correction:	No Losses Correction
User Ratio (S):	1:1	Mode:	N/A
Correction Mode:	Correction - SAE J1349	General Comments	
Data Configuration	TL1000 Sample Run 3 - No losses systems activated Single Inertia Mass with a disc brake fitted Run Performed in 4th Gear		
Data 1 Title:	Lambda	Data 1 Scale Min:	[0.61]
Data 1 Sensor:	Tech Edge 3A1/3A2 Lambda	Data 1 Scale Max:	[1.29]
Data 2 Title:	Exh Temp	Data 2 Scale Min:	[0]
Data 2 Sensor:	[0-1500 C] D-Tec ThemAMP	Data 2 Scale Max:	[1500]
Data 3 Title:	Case Temp	Data 3 Scale Min:	[0]
Data 3 Sensor:	[0-1500 C] D-Tec ThemAMP	Data 3 Scale Max:	[1500]
Data 4 Title:	Air Temp	Data 4 Scale Min:	[-11.04]
Data 4 Sensor:	[File:Brech_026.C [TK pullup to 5V].csv]	Data 4 Scale Max:	[114.25]
Data 5 Title:	Batt V	Data 5 Scale Min:	[0]
Data 5 Sensor:	[0 - 15 V]	Data 5 Scale Max:	[14.78]
Maths Configuration	Math 1 Title: Maths 1 Math 1 Desc: No Calculation Math 2 Title: Maths 2 Math 2 Desc: No Calculation		
Math 1 Title:	Maths 1	Math 1 Scale Min:	[0]
Math 1 Desc:	No Calculation	Math 1 Scale Max:	[5000]
Math 2 Title:	Maths 2	Math 2 Scale Min:	[0]
Math 2 Desc:	No Calculation	Math 2 Scale Max:	[5000]

## Compare

Compares the percentage of difference between all selected Run traces (any data set) and highlights variations.


Individual data channels for the chosen traces can be turned on/off ('eye' visibility buttons in the menu bar) and the trace being viewed can be from any of those loaded and selected into the main dyno 'GRAPH' Window. Only available traces and their active data channels will have the buttons highlighted for operation!



### Reference Trace



The reference trace is the one that all others are compared to. The difference percentages displayed in the data box's in the right hand side are relative to this selected trace.




**Select Traces to compare:** Choose to view the traces loaded in the Main dyno 'GRAPH' Window or those loaded in the Secondary Graph Window.

**Tip-** The RPM scale is taken from the main GRAPH Window, so trimming the main graph (e.g. using the corner arrows) will vary what is seen in this screen.

## Torque Analysis

A powerful tool that reveals the area under the Torque curve, average Torque, maximum Torque, RPM that developed maximum Power and Torque.



The RPM points that are calculated between can be easily adjusted in the menu bar. This allows for quickly trimming down the Runs to compare certain key areas.



The 'Markers' button activates markers (vertical lines) on the screens show the peak RPM for maximum Power and Torque.


**Note:** The 'Curve Area' is a mathematical calculation and has no standard unit of measurement (it is derived from RPM and Torque data).

# Chapter 13: Analysing Data ('View' Menu)




## Losses

Losses system is a DYNertia3 software feature. It is a tool that measures and applies a correction for dyno system losses (friction, windage etc) and also for vehicle driveline losses, it allows analysis of this data also in the Windows shown below.



**Note:** Please see the chapter "Losses Corrections" for details




# Chapter 13: Analysing Data ('View' Menu)



## Lambda / AFR Deviation

Reveals the deviation of a trace's mixture from a target value for tuning air fuel ratio (AFR)




Clicking on the Window will reveal a cursor; actual Lambda deviation and RPM at that point is displayed in the menu bar.

The span (scale range) shown and the target value can be easily set using the ▼▲ buttons.



Units of Lambda or AFR can be selected. Selecting AFR will alter the scale range to suit a sensor calibrated as AFR and not Lambda i.e. ensure the sensor input is correctly setup for either Lambda or AFR units, depending on what you wish to use (see chapter "Inputs- Using")



**Select input channel:** The channel that the Lambda meter is connected to can be freely selected, though by default the preference setting in 'Setup/Software/Lambda AFR' is used.



**Select a Trace to view:** Any of the 10 traces loaded into the main Graph Windows can be selected.




**Individual Trace view:** The trace selected will be shown in the 'Individual Trace' Window for a detailed look at all of the data and what the consequences of the mixture deviation may have been at the cursor point.

**Tip-** See also the manual chapter 'Inputs- Using' for the 'Current Lambda / AFR' live tuning Window information.

## Distance / Speed / Time / RPM Analysis

This Window allows the relationship between these variables to be easily examined. As the test Run is carried out at any point we can see the distance actually covered by the vehicle (providing we have set up an appropriate tyre circumference), the current speed, engine RPM and time it has taken to reach this point.



Clicking on the screen brings up a cursor and the data at this point is displayed on the dial gauges.



The cursor can be positioned and "P1" button pressed, move cursor again and press "P2" button, the data at both points is displayed on the Right hand side along with the difference calculated.



This reminds the user that trace starts at the start of the recorded Run, which is not from stand still i.e. it represents a rolling start and zero distance is marked at the start of the Run (in the case above the bike was already travelling at 66KPH at the start)




The graph can be trimmed by manually entering an accumulated distance to end the scale at e.g. in the example above we could enter a value less than 574 meters if we wished!



**Select a Trace to view:** Any of the 10 traces loaded into the main Graph Windows can be selected.

## Slip / Tyre Growth

Shows the percentage of difference of a trace's RPM (measured from DYNertia's speed sensor but using the drive ratio to correct to engine RPM) to that of the secondary RPM source, if used. This Window was designed to show problems with clutch slip, loss of tyre traction and also the engagement points of centrifugal clutches.



The graph above clearly shows major 'slip' at one point, this is due to the engines clutch releasing under power (certainly explained a dip in the Power curve seen also when testing!)

**Note:** The 'RPM Adapter' input and drive ratios must be setup, it is this 'RPM adapter' engine RPM that is compared to the calculated RPM (from dyno speed and ratio) to measure slip.

**Note:** 'Slip' calculations can't operate with engines fitted with CVT transmissions or automatics that can't be locked into a set gear for testing, this is due to them having a continually changing drive ratio between engine RPM and dyno RPM.

It is normal to see a variation from 0%, there will always be a small amount of slip, particularly on a chassis dyno. There will also be mathematical 'rounding' errors, ignition timing variations and measurement errors (e.g. if your ratio setup is poor) that can cause a deviation.

Clicking on the screen will reveal a cursor; actual RPM and slip values at that point are shown in the menu bar.'



**Select a Trace to view:** Any of the 10 traces loaded into the main Graph Windows can be selected.

“◀▶” buttons (lower Left & Right corners) allows the trimming (or ‘zooming in’) of the trace image by moving the graph start and finish points, this can also remove any unwanted trace sections, particularly useful for ensuring the printed image appears as you wish.

“▲▼” buttons (Left) allows the trimming (or ‘zooming in’) of the trace image by altering the graph percentage scales.


“▲▼” buttons (Right) allows the offsetting of the trace image by altering the graph percentage scales offset from zero.



**Individual Trace view:** The trace selected will be shown in the 'Individual Trace' screen for a detailed look at all of the data and what the consequences of the slip may have been at the cursor point.

## Run Duration Info

Opens a Window that allows the entry of any two speed or RPM points and displays the time between them.



**Tip-** "Err" displays when there is no selected trace to display i.e. above trace 5,8,9 and last run were not loaded on the main Graph Window so the data is missing!

Enter any start and finish RPM point or Speed point if you are running in 'Speed' mode, press "Calculate" to update the figures.



**Select Speed or RPM:** Choose the units to time.

Great for showing changes in acceleration rate between tests (i.e. 100 – 200 kph times).


**Tip-** The two values will initially be selected from the graph scale settings you have chosen (Run start and finish RPM/speed).

## Point to Point Times

Opens a Window that compares multiple Runs and highlights which performed best (or worst) between any RPM or speed points that you choose. The chosen traces are those selected in the GRAPH Screen. Manually enter any RPM or speed points that you wish to analyse between.

**Green** highlights the trace that had the shortest acceleration time between your chosen points.

**Red** highlights the trace that had the longest acceleration time between your chosen points.



**Tip-** "Err" displays when there is no selected trace to display i.e. above trace 5,8,9 and last run were not loaded on the main GRAPH Window so the data is missing!



The RPM or speed mode is automatically selected depending on what mode you are currently running the dyno in (selected on the main screens with the 'dial' icon)



The minimum and maximum coloured selections can be turned on or off to help visibility. When both are off the trace data is all white and not coloured.




Your range settings can be saved or loaded for future reference.

## XY Graph

Flexible tool allows plotting of data of choice against another to reveal trends. As the chosen channels can even be 'maths' channels there is no limit to the applications. Particularly suited to stable data (e.g. Point by Point recordings)

Drop down selection boxes in the menu bar allow for a choice from any data channel 1 to 5, maths channels, Speed, RPM, Torque, Power, drive line losses (if enabled) and slip.



Clicking on the Window will reveal a cursor; actual values at the X and Y points are displayed in the menu bar.



**Select a Trace to view:** Any of the 10 traces loaded into the main Graph Windows can be selected.




**Individual Trace view:** The trace selected will be shown in the 'Individual Trace' Window for a detailed look at all of the data.

# Chapter 13: Analysing Data ('View' Menu)



## Run Data vs Time

Allows plotting of data over time.



**Select a Trace to view:** Any of the 10 traces loaded into the main Graph Windows can be selected.




**Information:** This button will reveal a summary table (Trace Info) of the data associated with the trace set currently being viewed.

## **Chapter 14: Inputs- Using**

**How to connect DYNertia to various input sensors!**

**How to configure and calibrate input channels!**

## Pin Allocations



### 12 PIN Data Acquisition Connector (optional use) – Left to Right


<b>5V output:</b>	For supplying sensors with a stable regulated supply/reference voltage if required. '0V' terminals provide the ground return.
<b>Exp1:</b>	Expansion connection for future accessories and functions.
<b>Exp2:</b>	Expansion connection for future accessories and functions.
<b>Exp3:</b>	Expansion connection for future accessories and functions.
<b>0V Ground:</b>	Reference ground for any inputs being measured (linked to all '0V' terminals internally).
<b>0V Ground:</b>	Reference ground for any inputs being measured (linked to all '0V' terminals internally).
<b>Channel 1 input:</b>	Analogue input for general purpose data acquisition, selectable range (15V Max)
<b>Channel 2 input:</b>	Analogue input for general purpose data acquisition, selectable range (15V Max)
<b>Channel 3 input:</b>	Analogue input for general purpose data acquisition, selectable range (15V Max)
<b>Channel 4 input:</b>	Analogue input for general purpose data acquisition, selectable range (15V Max)
<b>Channel 5 input:</b>	Analogue input for general purpose data acquisition, selectable range (15V Max) Must be connected to any 'load cell' input if a brake style dyno is being used.
<b>RPM Adapt. input:</b>	This is for connecting to an 'RPM adapter' or additional RPM sensor. It is a digital input and <b>must never</b> be directly connected to an ignition system. It needs to be 'pulled' to ground and measures the frequency that this occurs. Please see the appropriate diagram!

## General Input Notes

### Important general information

**Engines running CDI ignition, copper core plug leads and/or non-resistive spark plugs emit massive radiated interference. This may cause unstable readings or interfere with DYNertia's operation (PC communication may fault). We suggest you follow the wiring information carefully, particularly in regards to keeping all wiring as far as possible from the ignition system!**

Input channels measure 0-5V. To measure higher voltages use external resistors to reduce (divide) the voltage down.



### Example-

Using a 10K Ohm and 4.7K Ohm external resistor allows measuring of close to 16V by reducing this voltage down to the range DYNertia can measure.

Using a 10K Ohm and a 5K Ohm (made by two 10K Ohm in parallel) resistors gives an exact divide by 3 ratio so 15V in gives 5V out.

**Note:** Whatever resistors you use if measuring higher voltages or sensors you use you will need to check the settings in the 'Setup' menu under 'Sensor Configuration' to let DYNertia3 know the voltage range, display units and calibration details if required. This is covered at the end of this chapter.

The 5V sensor supply is sourced from the PC's USB port so avoid excessive loading. Most sensors you will power from the 5V supply will draw only very small current; however faulty sensors or shorted wiring must be avoided.


## Wiring inputs for best results

Screw type terminals must be tight or contact will be troublesome. To avoid loose connections, especially when wiring is frequently changed, we suggest fitting crimp ferrules (called 'bootlace ferrules') to the wire ends.

DYNertia's 0-5V, 10 bit resolution allows voltage steps as small as 5mV to be measured but in practice its signal noise that limits this measurable voltage.

There are certain precautions that can be taken to maximise the performance and minimize the effects of interference-

- Use a separate Power supply battery for 'RPM Adapter' if used so it can remain isolated from DYNertia
- It is best to avoid linking into the vehicle/engine if at all possible, run sensors from an isolated supply source such as a battery or DYNertia's 5V terminal. Sharing the vehicle ground/power is a major source of measurement noise and this should always be considered when performing data acquisition during vehicle testing.
- Run all wiring well clear of any large current carrying wires (e.g. electric fans), mains leads and particularly as far as possible from high voltage sources such as ignition systems and secure well.
- Connect all grounds to a common point (star ground) as this will reduce voltage differences between sensors and the measuring system.




- Quality 'Shielded' wiring can be used to help prevent interference from effecting sensor readings. If there are issues getting good data or for critical measurements this should be considered. Only one end of the shield (or screen as it is also called) is connected, this should ideally be directly earthed at the 0V terminal of DYNertia or it may be worth trying a chassis ground if beneficial.
- View the data input readings in the menu option "Utilities/Data Diagnostics" after wiring to check the readings before continuing with testing.

## Connecting Sensors

### General sensor connection (0-5V input shown)

The Inputs can measure any voltage within range (0-5V Max). This voltage may be from a sensor such as pressure, temperature, position etc. or even just a straight voltage such as monitoring battery voltage. You will need to check the settings in the 'Setup' menu under 'Sensor Configuration' to let DYNertia3 know the voltage range, display units and calibration details if required. This is covered at the end of this chapter.




**Note:** If using a 12V sensor then it will need to be powered externally.

## Resistive sensor connection


Inexpensive resistive sensors (resistance changes with temperature) can easily be connected but require an external 'Pullup' resistor to be fitted, this is typically 1K Ohm.

Many sensors such as those from Bosch or Delco are pre-calibrated in DYNertia3 software. Check the settings in the 'Setup' menu under 'Sensor Configuration'; this is covered at the end of this chapter.



## Connection of a thermocouple amplifier (for K-type sensors)

Thermocouples only produce tiny voltages so these are greatly amplified before use. This means they are very sensitive to electrical noise also being amplified and DYNertia takes measures to prevent this, but care is still needed to get quality data. Avoid running near ignition system wiring and it is greatly preferable to use 'isolated' sensors, these do not contact the earth (ground) of the vehicle and therefore connect only to the amplifier directly. Particular problems could arise when using 'spark plug washer' type sensor probes, additionally if they are grounded and not isolated type.



**Note:** 5V supply will limit output of this Reveltronics unit shown to 3.2V or 800°C. For higher temperatures a greater supply voltage will be needed for the amplifier. Check the in the 'Setup' menu under 'Sensor Configuration' that the correct configuration is used (it produces 4mV/ °C).

# Chapter 14: Inputs- Using




## Air/fuel ratio meter connection (AEM 30-3000 unit as example)

DYNertia can interface with any Air Fuel Ratio (AFR) meter that has an analogue output, as most do. The meter itself should be powered directly from a battery as they draw considerable current to operate the oxygen sensor heater element (keep an eye on battery voltage as they can flatten batteries quickly!)


Many common AFR meters are already pre-calibrated in DYNertia3 software; you just choose the correct one in the 'Setup' menu under 'Sensor Configuration' to let DYNertia3 know. If not, then you can easily create your own settings as long as you know from the manufacturer what output voltage equals what AFR/Lambda mixture, this is covered at end of chapter.

**Note:** Some AFR meters have 'differential outputs' (i.e. 2 isolated outputs not connected to the meters power supply ground) so the negative output must be connected to a DYNertia ground (0V). Some AFR meters just have a single output wire to connect; their output is referenced to the meters power supply ground.



## Connection of load cell for brake (absorber) style dyno's

Only input **channel 5** can be used as torque input from a load cell (preset in software). If the input is greater than 5V then set the voltage range switch to 0-15V. The sensor must be calibrated properly, see 'Load Controller' in this manual and check the settings in the 'Setup' menu under 'Sensor Configuration'; this is covered at the end of this chapter.



**Note:** load cells produce only tiny voltage changes so will need an additional amplifier (transmitter) to create a usable voltage output. DTec sell a unit that incorporates additional filtering for improved performance on dyno applications.


## RPM Adapter Input

### General notes on wiring the RPM adapter input (secondary way of measuring RPM)


'RPM Adapter' input is for an optional direct engine RPM input (main RPM input is via DYNertia's sensor) and requires switching (pulsing) to ground so DYNertia can determine the RPM.

**NOTE: DO NOT** directly connect to an ignition system due to the high voltages involved. An 'RPM Adapter' unit must be used to turn any high voltages or analogue voltages from a VR sensor (like an ABS wheel speed sensor) into suitable pulses.

Hall sensors are 'switching' style sensors and can be directly connected to the 'RPM Adapter' input as these provide the correct signal characteristics. They are available to sense from a rotating iron object (such as the common 'Honeywell 1GT101DC' sensor shown below) or magnets.



### Using a DTec 'RPM adapter' for the RPM adapter input



The DTec 'RPM adapter' is designed to turn signals from many different sources into a suitable signal for connecting to digital devices such as DYNertia's 'RPM Adapter' input.


It can be connected to the ignition coil switching terminal (inductive and CDI systems), VR sensors (also known as 'inductive') that generate an AC voltage (like ABS wheel speed sensors), digital coil drive signals (such as on 'coil on plug' systems) or it can even pick up RPM by placing a wire alongside the spark plug lead.

There is a Hi voltage input (up to 600V) and a low voltage input (up to 120V). The low voltage input provides good sensitivity for VR sensors and digital coil drive signals, the high voltage is designed for direct connection to the coils switching circuit (coil primary circuit, not secondary spark plug voltage).

The unit provides full isolation to the device connected to it i.e. the internal 'switching' circuit that connects to DYNertia is isolated from the inputs for protection (full optical isolation).

When probing an unknown system use the Hi voltage input first and watch the tacho display (Setup/Sensor Calibration>Show Data Stream) for a suitable reading. Inputs have been designed to be almost indestructible to allow for this 'try and see' approach. Just **do not allow spark plug voltage to enter the unit**, this is potentially tens of thousands of volts and will cause damage.


# Chapter 14: Inputs- Using



## Basic connections for a DTec 'RPM adapter' to DYNertia's RPM Adapter input

'RPM Adapter' requires a 12VDC (9V to 18V) power supply at all times to operate. This can be from the vehicles battery or another source. The adapters power supply ground (0V) will also need to be connected to the vehicles for some applications (see upcoming diagrams).

Using a separate power supply battery for 'RPM Adapter' allows it to remain isolated from DYNertia and helps prevent ignition interference from entering the DYNertia system.




**NOTE: Use a separate power supply source for 'RPM adapter' unit to avoid interference issues!**

**We strongly suggest fitting an additional suppressed spark plug lead for testing as this is a major source of interference in many systems!**

## Connections for a DTec 'RPM adapter' to suit spark plug wire sensing


Adjusting the sensing wires length along the spark plug lead can increase the sensitivity if not reliably triggering.

The Lo voltage input of the adapter can often just be laid in parallel along a spark plug wire lead to receive a pulse. The adapters ground (0V) is connected to the engine case ground (sometimes it's OK without this ground!). Connect the Lo voltage input to a wire that is firmly taped or cable tied along the spark plug lead, it should closely contact the lead and not move around. About 50mm or longer is fine, if it is too short it may not give a reliable input signal. **Be careful not to let the wire receive a 'shock' from the high voltage to the plug as this will cause serious damage to the adapter!**




## Connections for a DTec 'RPM adapter' to suit coil 'switching' signals

The Hi voltage input of the adapter can be connected to the switching side of the coil (coil primary, often labeled "."). This terminal has a high voltage (400v) present when the coil fires. CDI and magneto systems can often be connected to the 'kill switch', as this is often the coil switching wire (it's grounded to stop the engine in these systems). Connect the adapters ground (0v) to the vehicles ground and the Hi voltage input to the coils switched wire!



## Connections for a DTec 'RPM adapter' to suit coil 'drive' signals


Many ignition systems that use a 'coil on plug' have a small signal from the ECU to fire the coils built in electronics. There are also many systems that use an external transistor ('igniter' or 'module') that also use this principle. The adapter can get an rpm signal from this 'trigger' wire. Connect the adapters ground (0v) to the vehicles ground and the Lo voltage input to the coils trigger wire!



## Connections for a DTec 'RPM adapter' to suit 'VR' (inductive) sensors

We suggest an inexpensive ABS wheel speed sensor be used and triggered by a rotating engine component (e.g. a bolt head) as this may prove much more convenient than connecting to the wide variety of ignition systems in use.


VR sensors (**V**ariable **R**eluctance, also known as 'inductive' sensors) are readily available, they are used commonly for ABS wheel speed sensors and crank angle sensors. They generate an AC voltage as an iron object moves past. Connect one wire to the adapters ground (0v) and the other to the Lo voltage input!



# Chapter 14: Inputs- Using



## Sensor Configuration



This allows the application of a sensor calibration to the input voltages that DYNertia is reading. The inputs can be read as plain voltages (0- 5000 mV) if you wish, but generally an input voltage is easier to read if meaningful units are applied e.g. The input from an air/fuel ratio meter should be shown in Lambda units rather than just millivolts (mV).

**Note:** All sensor configuration in DYNertia3 involves the software relating an input voltage in mV (1 millivolt = 1000<sup>th</sup> of a volt or 0.001V) to an output of some unit!

**Note:** DYNertia internally reads mV from 0-5000 (0-5V), If you select an input voltage switch setting of 0-15V you are dividing the input by 3 before it is measured. The 'raw' values will be still in the 0-5000 range e.g. 9V input would be 3000mV raw.

### Configuring an input channel using pre-settings

There are already a large amount of pre-set configurations in the list, not just DTec sensors, but common automotive ones including pre-sets for simple voltage range configurations e.g. 0-15V or 0-5V.

Sensor Name	File	mV 1	Val 1	mV 2	Val 2	Unit
0 - 15 V		0	0	5000	14.78	V
0 - 5 V		0	0	5000	5	V
0-1500 C DTec ThermAMP (set range 0-15V)		0	0	5000	1500	C
0-1500 F DTec ThermAMP (set range 0-15V)		0	32	5000	2732	F
0-500 C DTec ThermAMP (set range 0-5V)		0	0	5000	500	C
0-500 F DTec ThermAMP (set range 0-5V)		0	32	5000	932	F
Bosch LA2 AFR (14.7:1 Stoic.)		500	7.35	1520	22.39	
Bosch LA2 Lambda		500	0.5	1520	1.52	
DTec WB1 AFR (14.7:1 Stoic.)		0	10	5000	20	
DTec WB1 Lambda		0	0.68	5000	1.36	
DTec WB2 AFR (14.7:1 Stoic.)		0	7.35	5000	29.4	
DTec WB2 Lambda		0	0.5	5000	2.0	
DYNertia MAP Sensor ( Bar )		500	0.5	4500	4	Bar
DYNertia MAP Sensor ( KPA )		500	50	4500	400	kPa
DYNertia MAP Sensor ( PSIA )		500	7	4500	60	PSIA
Dynojet WB2 AFR (14.7:1 Stoic.)		0	10	5000	18	
Dynojet WB2 Lambda		0	0.68	5000	1.22	
File:Bosch 026 C (1K pullup to 5V).csv						C
File:Bosch 026 F (1K pullup to 5V).csv						F
File:Delco Air C (1K pullup to 5V).csv						C
File:Delco Air F (1K pullup to 5V).csv						F
File:DTec Fast 3250 C (1K pullup to 5V).csv						C
File:DTec Fast 3250 F (1K pullup to 5V).csv						F
Innovate LC-1 AFR (14.7:1 Stoic.)		0	7.35	5000	22.39	
Innovate LC-1 Lambda		0	0.5	5000	1.52	
Innovate LC-2 AFR (14.7:1 Stoic.)		0	7.35	5000	22.9	
Innovate LC-2 Lambda		0	0.5	5000	1.52	
Innovate LM2 AFR (14.7:1 Stoic.)		0	7.35	5000	22.39	
Innovate LM2 Lambda		0	0.5	5000	1.52	
Innovate ST12 AFR (14.7:1 Stoic.)		0	7.35	5000	22.39	

- Enter a meaningful name in the "Channel Name" field.
- Select the sensor from the drop-down '▼' list next to "Selected Sensor", that's it, all done!



To optionally view the calibrations graphically press this button. This allows you to confirm your settings quickly. Clicking on the visible graph will show the values at the cursor.

Although there are many pre-set calibrations provided, it is also easy to create your own (see next page)!


# Chapter 14: Inputs- Using




## Creating your own linear (2 points, straight line) sensor calibrations



1. Click on the “+” Icon to add a new sensor




2. Double click in the ‘Sensor Name’ field (It will say “New Sensor” by default) and give your sensor a meaningful description e.g. for our example let’s say “Hi pressure sensor (psi)”, “psi” is added so we know we are calibrating it in ‘psi’ units. We could add the same sensor into the list again and use different units e.g. ‘bar’ if required.



3. Enter the minimum sensor input voltage in mV and the corresponding sensor reading value to that voltage (e.g. 200 mV may be 400 psi of pressure from a particular sensor).
4. Enter the maximum sensor input voltage in mV and the corresponding sensor reading value to that voltage (e.g. 3800mV may be 1000 psi of pressure from the sensor).
5. Add the units you want displayed in the relevant screens, in this example “PSI”, as shown below.

**Note:** To actually view the mV reading that DYNertia is measuring for a given sensor input use the ‘Data Channels’ analyser screen. This is found under the menu “Utilities/Data Diagnostics”. This screen is explained later in this chapter and is an important tool to use for getting your calibration data prior to entering values.



You can also edit existing sensor names and data directly from the sensor list as above



If a sensor is highlighted in the list it can also be deleted using this button.

**Tip-** Sensor calibrations are listed alphabetically, if you wish to position one at the top of the list then name it accordingly!

**Note:** Data and Settings are saved and channels configured when the Window is closed.

## Naming and calibrating of Lambda / AFR meter inputs

Under the menu option ‘Utilities’ is a tuning screen called ‘Current Lambda/AFR’. This screen actually gathers information from the naming of the AFR sensors about the calibration units you have configured it in (either AFR or Lambda).

DYNertia3 will pick up if you have calibrated your input channel in units of Lambda or AFR by checking if the words appear in the selected sensor name under menu option ‘Setup/Sensor Configuration’, “Lambda” or “AFR” are the terms it searches for (note the space either side). Knowing this allows DYNertia3 to apply the appropriate calculation to display to you either in units of Lambda or AFR regardless of your sensor configuration.

Example- “My mixture meter Lambda” or “My mixture meter AFR” determines the units used (Lambda or AFR)

If you want to display AFR as Lambda, then it is the units you would calibrate in e.g. so 2800mV is Lambda 1.  
If you want to display AFR as AFR, then it is the units you would calibrate in e.g. so 2800mV is 14.7 (for petrol).

## Creating your own non-linear sensor calibrations

Certain sensors such as typical resistive temperature sensors are non-linear. These obviously require more than just two data points for calibration, so DYNertia3 allows for the use of ‘look-up’ data tables to be used and incorporates a powerful tool to assist configuration/calibration.



Pressing this opens the “Sensor Calibration Designer” as discussed below. This is the tool we will use to help create a full calibration data table with only a few test points.



**Warning-** This button/tool is only to help those with electronics background designing custom sensor applications! It assists with calculating ‘voltage dividers’ i.e. if an input voltage needs to be reduced. It is not required for standard sensor configurations.

In the ‘Sensor Calibration Designer’ tool, data points that you have measured and enter are saved as a ‘definition file’, this is not the full calibration table, it is just a record of your data. This file can be saved and later loaded if you wish to change it (perhaps you wish to add some extra test points). The full ‘calibration file’ is automatically created from this ‘definition file’ and includes an output value for every single mV of input voltage. Calibration files are a ‘.CSV’ type so you can create them with Excel or other tools if you wish.

### Example, calibrating an unknown ‘non-linear’ sensor-

You have an unknown resistive temperature sensor you wish to use with DYNertia, perhaps it is already installed in the engine and you see no need to replace it.

1. Connect the two sensor wires as per connection diagram and switch the channels ‘Pullup’ switch on (as it is resistive and requires a ‘Pullup’ to convert resistance to voltage)
2. Using the ‘Data channels’ analyser screen (menu choice “Utilities/Data Diagnosis”) you can view the ‘raw’ (as measured, no scaling) input voltage for the channel by pressing the “In mV” button.
3. Dip the sensor in ice water and write down the mV reading shown (say 4275mV = 0°C)
4. Heat the sensor to a mid range and write down the mV reading and water temperature (say 2270mV = 50 °C)
5. Boil the sensor in water and write down the mV reading (say 782mV = 100 °C)



6. Open the ‘Sensor Calibration Designer’ tool in the ‘Sensor Configuration’ Window; enter the recorded temperatures against the mV reading in the column area on the Left Hand side as seen below.


**Tip-** More points of data are better. Choose test temperatures near the normal operating range of the sensor for the greatest accuracy.

# Chapter 14: Inputs- Using



## Creating your own non-linear sensor calibrations (cont.)


The Right Hand output data is automatically updated when the Left Hand sensor data is entered. It is this output data that will become the actual calibration data when saved.



7. Save your 'Definition File' (your entered data) now for later reference or modification ('Disc' icon).



8. Press the 'Curve Fit' button and adjust to best suit the data using ▲▼. A smooth line best follows the natural sensor characteristic.




9. Save the actual 'Calibration File' that has been generated (as seen in Right Hand columns). Name it meaningfully (e.g. "Custom Temp deg C") as this file name is used as the calibration description, as you will see in the next steps.

**Note:** Save the files in the default folder location called 'Custom Cal' so software knows where to look!



10. Return to 'Sensor Configuration' Window and Click on the "+" Icon to add a new sensor

11. In the 'File' column you can Click to reveal a button that opens a windows screen, this allows you to locate and select your 'Calibration File'. The name you gave the file will be automatically used as the sensor name and the word "File" added so it can be seen that it is a full calibration table and not just linear (2 points).




That's it! Your new 'non-linear' sensor will appear in the 'Sensor Name' list. You can allocate it to a channel now.

# Chapter 14: Inputs- Using



## Testing sensor configurations


Please use the 'Data Channels' analyser Window to test that the channels are configured correctly and operating as expected before use.



**Note:** Window is found in the menu "Utilities/Data Diagnostics", not 'Sensor Configuration'

**Note:** See chapter "Live Data Viewing for further details.

**Tip-** This screen is ideal for calibrating sensors, as in our example for non-linear sensors you can also use the "In mV" button to display the 'raw' mV readings (0-5000mV), this is prior to any sensor calibration being applied.



In mV

You can check the naming of channels and that they function. Pressing the "In mV" button allows us to read the voltage coming into DYNertia directly ('raw' with no calibrations applied).

This is what is used to gather the data for calibration i.e. you will take this reading and note it against a particular pressure, temperature, position, voltage etc when performing a calibration.

**Note:** DYNertia internally reads mV from 0-5000, If you select a switch setting of 0-15V range you are dividing the input by 3 before it is measured. The 'raw' values will be still in the 0-5000 range eg. 9V input would be 3000mV raw.

## Getting the best data

Calibrating an individual sensor is the ideal way to get the best data. Every sensor has some tolerance (surprising large for many) and even DYNertia will have some variance in input impedance.


By directly noting the 'raw' mV reading and using this as for your data you are compensating for most of the variables that effect accuracy. You may notice the 0-15V range in the sensor list has actually 5000mV= "14.78"V and not 15.00V, this is as the 15V range switch does not exactly divide by 3. This is a good example of improving accuracy by calibration.

**Tip-** The 0-5V range selection will give the highest performance as the resolution is greater, as is the input impedance.

**Channel Filtering:** Each channel has its own filtering setting. Excessive filtering should be avoided as it can hide data that may be of interest. Only use what is required for sufficiently smooth graphs/displays!




This is particularly important for Channel 5 as a load cell may be connected here. This has a major effect on the appearance of the graphs in brake dyno mode.



**Tip-** Filtering of the main graph, not the individual channels as discussed here, is done in menu option "Setup/Software/Graph Smoothness"

Only use what is needed to create suitable graphs, set correctly it will filter out some of the 'spikes' discussed here. It cannot make up for poor data from sensor faults and large amounts of interference.

**Reference Voltage Correction:** A tiny voltage error may be present in DYNertia's internal 5 Volt supply, this option is available to correct for this variation. This adjustment is rarely required as the 5 Volt is very precise. Simply measure the voltage between the ground and 5V output terminals on the data acquisition connector and enter the measured voltage.




**Tip-** This voltage can be also used to correct for sensor errors (if applicable to all channels), but this is really best done by modifying the sensor configuration table to 'trim' the result.

# Chapter 14: Inputs- Using



## Sensor Alarm Points



Input sensors can have alarm and limit conditions attached that will turn the warning lamps either red or orange upon triggering. This can be used for detecting damaging conditions like overheating or even used to signify when conditions are acceptable for repeatable testing i.e. when engine temperature is within a certain range.

**Note:** When viewing the data via 'Data Channels' Window the alarms only apply if 'unprocessed mV' is not selected to be displayed.

The alarm lamps appear on most display screen during testing and monitoring.


Settings also apply when viewing via the monitoring dials on the main Dyno screen ('Gauges' button is selected or performing a run).

As shown below, the alarm lamps will be either orange or red depending on the input exceeds a 'limit' or a full 'alarm' value.



Settings can be optionally saved or loaded from file.


This may be useful if you have made settings for particular engine types you frequently test.



The Alarm lamps here are shown in all 3 states-  
Lambda has exceeded 'limit' value.  
Case Temp has exceeded alarm value.  
Other data is within range.



Setting a deviation value changes the way the bar graphs display in the "Tuning Gauges" screen (only visible with dual monitors configured). It places a marker at the value entered and the band shows the value as it moves either side of the marker, as oppose to the band starting from the Left hand side.



## Sensor On / Off (Recording)



This option in 'Sensor Configuration' allows the data acquisition channels to be easily turned on or off so as they do not record when testing.


# Chapter 14: Inputs- Using



## Data Consistency

This Window shown below reveals an overview of the data channels and their scaling. If there is an inconsistency detected between the calibrations from different selected Run traces then it will be highlighted here as to which trace and channel has been recorded with a different sensor calibration (compared to the lowest number trace).

For multiple overlaid traces to be meaningful then obviously they must all have been recorded with the same calibrations applied. If you choose traces to compare that have been recorded under different calibrations (i.e. if channel 1 is calibrated in Lambda for one test and temperature for another test) then you will be warned and an icon will appear on the graph screen to indicate this. If you view the overlaid data after being informed of the inconsistency you must bear this in mind!



The extent of the warning can be altered in the menu option "Setup/Software/General", the two warnings are shown to the right below.

**DYNertia3 Main Graphs - Data Channel Overview**



Data 1 to 5 Consistent   Maths 1 & 2 Consistent

**MAIN GRAPHS**

To minimise confusion, Minimum and Maximum Data settings should be identical for each Trace Set. (i.e. same Sensor function and Scaling for each channel)

Changing the Minimum and Maximum settings changes the way the data is displayed NOT the actual underlying data. (click a Cell to edit)

	Last Run	Trace Set 1	Trace Set 2	Trace Set 3	Trace Set 4
<b>Sensor 1 Name</b>	Lambda	Lambda	Lambda	Channel 1	Lambda
<b>Data 1 Min</b>	0.61	0.61	0.61	0.61	0.61
<b>Data 1 Max</b>	1.29	1.29	1.29	1.29	1.29
<b>Sensor 2 Name</b>	Exhaust Temp	Exhaust Temp	Exhaust Temp	Channel 2	Exhaust Temp
<b>Data 2 Min</b>	0	0	0	0	0
<b>Data 2 Max</b>	1500	1500	1500	5000	1500
<b>Sensor 3 Name</b>	Case Temp	Case Temp	Case Temp	Channel 3	Case Temp
<b>Data 3 Min</b>	0	0	0	0	0
<b>Data 3 Max</b>	227	227	227	5000	227
<b>Sensor 4 Name</b>	Air Temp	Air Temp	Air Temp	Channel 4	Air Temp
<b>Data 4 Min</b>	0	0	0	0	0
<b>Data 4 Max</b>	200	200	200	200	200
<b>Sensor 5 Name</b>	Torque	Torque	Torque	Channel 5	Torque
<b>Data 5 Min</b>	0	0	0	0	0
<b>Data 5 Max</b>	49.03	49.03	49.03	49.03	49.03
<b>Maths 1 Name</b>	Maths 1	Maths 1	Maths 1	Maths 1	Maths 1
<b>Math 1 Min</b>	0	0	0	0	0
<b>Math 1 Max</b>	5000	5000	5000	5000	5000
<b>Maths 2 Name</b>	Maths 2	Maths 2	Maths 2	Maths 2	Maths 2
<b>Math 2 Min</b>	0	0	0	0	0
<b>Math 2 Max</b>	5000	5000	5000	5000	5000



The red boxes here indicate areas of data inconsistencies, the scaling can be altered here to align the values so when overlaying they are consistent.

'Clicking' in the colour box's allows you to enter a new value and change the scaling problem.

When inconsistent data is viewed, the scales actually shown to the Right of the main graph screen (CH1, CH2) will be based on the trace set loaded into the lowest position (e.g. last trace recorded is highest priority, then trace 1, then 2 etc)

**Tip-** For consistency it is a good habit to use sensor calibrations that span the same range, for example if using different coolant temp sensor types then calibrate them all from, say 0 - 200 degrees (regardless of type), that way when data from the different tests is overlaid or merged it will still be valid!

# **Chapter 15: Load Cell Configuration**

**Load Cell Wiring**

**Load Cell Configuration**

**Load Cell Calibration**

**Information regarding optional load cell wiring/calibration is relevant only if used as an ‘open loop’ brake dyno system.**

**Refer to the chapter ‘Brake Dyno Setup’ for general details on brake dyno setup.**

## Load Cell Connection

### Wiring of the load cell (including pressure sensor style)

Only input **channel 5** can be used as Torque input from a load cell (preset in software when ‘brake’ type dyno is selected). If the input is greater than 5V then use external resistors to reduce the voltage range (see chapter ‘Inputs-Using’ for details).

Load cells produce only tiny voltage changes so will need an additional amplifier (transmitter) to create a usable voltage output.


The sensor must be calibrated properly and this is done via the guided menu steps that will be shown later that assist in adjusting the load cell amplifier.

**Note:** If a hydraulic load cell with pressure sensor is used, this will connect into Channel 5 of DYNertia in place of the load cell amplifier output. This will require a manual setup as there is no amplifier to adjust so the guided calibration will not be of value.

For manual setup please see ‘Manual Sensor Calibration’ in this chapter and referring to chapter on ‘Inputs-Using’.

Please refer to the manual of your Load Cell amplifier and Load cell for further details, colours and connections.

**Note:** With a DTec load cell amplifier use the “V Out filtered” output connection to connect to DYNertia.



Load cell to amplifier connections will depend on your chosen load cell and amplifier. Generally the following is a guide:

**Red** = excitation +ve, **Black** = excitation -ve

**Green** = signal -ve, **White** = signal +ve

**Tip-** If you wish to reverse the operation of the load cell (perhaps you will operate brake system in the reverse direction) then you can wire in a simple switch to reverse either the load cells excitation wires or output signal wires.

**Note:** Applying load to the sensor in the operating direction should make the load cell amplifiers output voltage rise!

# Chapter 15: Load Cell Configuration




## Load Cell Setup & Calibration


Calibration is performed by noting the voltage from the load cell at rest (this is zero Nm) and then apply a known weight to the Torque arm so that this represents the Torque level you wish to measure

This also involves setting up the load cell amplifier so that the voltage output range is also effectively used. A guided menu process can be used as outlined below. Manual entry of the data can be also made by recording it in the 'Sensor Configuration' and entering the data in Nm at 0mV and 5000mV (see next section for details if required).

### Sensor Calibration





Within the menu 'Setup/Sensor Configuration' is this button (load cell icon) that opens the sensor calibration screens shown.



**Note:** This guided calibration procedure allows for automatic 'zeroing' of the load cell during use (it leaves a small 100mV offset voltage so DYNertia3 software can read a negative load if required). If you wish you can turn off, deselect "Automatically correct torque sensor for zero torque drift" in menu 'setup'/sensor configuration'


**Note:** The slider next to channel 5 will adjust the filtering to the load cell and affects the smoothness of your graph!

Step 1: explains setting the load cell amplifier so that it reads zero with no load (actually a small 100mV offset is automatically set with this guided calibration sequence)



Adjust the amplifiers 'Offset' (zero or null) until the digits turn green as shown on the Right then press 'Next Step' button.

# Chapter 15: Load Cell Configuration




Step 2: requires applying a known weight and entering the data. Then the load cell amplifiers 'Span' (gain) is adjusted till the digits turn green.

Software calculates the target figure based on full scale being equal to the load cells rating and the target being a portion of this based on the test weight you use.

**Note:** When calibrating, accuracy will suffer if a test weight is used that is too low a percentage of the load cells maximum scale, use a high a weight as practical.


You can add an extension to or lever above the load cell mounting arm (called a 'calibration arm' in the industry) so less actual weight is needed during calibration (i.e. it acts as a lever to apply more effective weight onto the load cell), but factor this in so you only enter the actual weight applied to the load cell.



Step 3: asks to repeat the process to confirm. This is because with a load cell amplifier adjusting Span will effect Offset and vice versa.

**Note:** Please see your DTec Load Cell Amplifier technical sheet if you are having trouble adjusting the settings within range.

You can also alter your load cells entered rating figure slightly if required to get the adjustments within range.



Step 4: asks you to press the 'Save Calibration' button.

It then loads the data into the sensor configuration screen under a sensor called "Load Cell".

It will automatically set the voltage that represents no load and also set the torque that is represented by 5000mV

**Tip-** Press the "i" button you can see the data that will be used by the software.

You can check the data if you like by using-  
 $\text{Torque} = \text{load (weight in Kg applied} \times 9.80665) \times \text{length of torque arm in meter's}$

# Chapter 15: Load Cell Configuration




## Manual Sensor Calibration

If you have an alternative torque sensor to a load cell or you otherwise just wish to perform a non-guided calibration then it is possible to manually enter the sensor calibration data, just as you would for any other sensors.

**Note:** See chapter "Inputs- Using" for details on this process. Make sure the sensor is allocated to Channel 5 as this is the only torque input used.

Calibrating your system adjusting (amplifier 'Offset' {zero or null}) so that 0Nm is 100mV will allow the 'Automatic Sensor Drift Cancellation' mentioned below to still operate, even though a 'guided' calibration procedure was not used. If not using the automatic drift cancellation then you can ignore setting up for a 100mV offset.



**Note:** The sensor input in DYNertia must be calibrated in metric Newton meters (Nm).

Calibration is performed by noting the voltage from the load cell at rest (this is zero Nm) and then apply a known weight to the load cell so that this represents the torque level you wish to measure (you can add an extension to the arm so less weight is needed if required during this calibration). Take the voltage reading from the sensor when the weight is applied and enter this into the sensor calibration table along with the calculated torque (as below).

**Torque = load (weight in Kg applied x 9.80665) x length of torque arm in meter's**

Therefore, if I had 0.5 meter arm (centre of dyno bearing to arms end above load cell) and apply 30kg onto the load cell I am applying a torque of  $30 \times 9.80665 \times 0.5 = 147.1$  Nm at the shaft.


So, if I had 10mV at no load (0 Nm) and 2000mV (2V) with my calibration weight applied (147.1 Nm) then these are my two calibration points I need-

$$mV1=10, Val1= 0 \text{ and } mV2=2000, Val2=147.1$$

## Automatic Sensor Drift Cancellation

To allow automatic drift cancellation the guided calibration process leaves a small offset voltage at 0Nm (approximately 100mV). DYNertia cannot read negative values so by having a small offset it allows the software to sense when the load cell/system drift is negative (less than 0Nm) and to compensate for it.

If you wish you can turn on/off, use "Automatically correct torque sensor for zero torque drift" in menu 'setup'/sensor configuration'. It defaults to 'on' after a guided calibration procedure.



# **Chapter 16: Outputs- Using**


**How to connect auxiliary outputs!**

**How to use auxiliary outputs!**

## Auxiliary Connections

### Connecting outputs if required

DYNertia has included the ability to control additional equipment. The auxiliary outputs 'sink' and 'source' (switch between 5V when ON and 0V when OFF state) when active. A convenient ground (0V) terminal is provided to simplify wiring.




**Note:** DYNertia outputs can sink/source 20mA, therefore this must be used to drive a 'solid state' relay or transistor etc. NOT a standard relay directly!


### Output functions

**'Run' Output:** Is on when the dyno shaft is rotating above approximately 7.5 RPM or for as long as a Run or function that involves dyno rotation is being performed. This can be used for safety control warning systems or automatic fan controls etc.

**'User' Output:** Controlled output is available that is manually turned on or off from the software ('Left' click "OUT" icon on both GRAPH and DYNO Windows) and can be used for any general purpose function e.g. remotely turning on a cooling fan, pumps wheel clamps etc. In menu option "Setup/Software" it can be set to activate at start/end of a test Run, press the "OUT" icon to turn off if set to only turn on at the test start.



**Note:** 'Right' click on "OUT" icon reveals additional functions not relevant for this dyno type.




The "OUT" icon on GRAPH and DYNO Windows turns green to indicate the output is active.

Outputs (Brake and User) can be set to turn off upon exit. This ensures devices connected to the auxiliary output terminals (see chapter "Outputs- Using") can be left in a suitable state upon exiting the software.

## Output functions (cont.)

### 'Brake' Output:


The 'Brake' output terminal may be used to operate an automatic brake for slowing the flywheel down if you wish, operating a vehicle lift/jack to remove vehicle from rollers, an automatic cooling fan for friction style brakes.



**Note:** The use of the "Brake" output depends on the dyno type you have setup.



The 'Brake' output terminal can go active from after a run is stopped and remain on for the time set in 'After Run Auto Brake'. It can also be manually activated for a pre-set time ('Pulsed Brake Timeout') or toggled on/off at will.



Besides the automatic function upon ending a test, the brake output can alternatively be briefly operated (based on 'Pulsed Brake Timeout') by manually selecting the icon (visible on both GRAPH and DYNO screen) with a 'Left' click, this allows for setting up safely and also applying brief braking pulses

Alternatively a 'Right' click on the icon will hold the output on continuously until another 'Right' click is done again i.e. 'Right' click toggles the output state. If not allocated to a brake; this output would be perfect for remotely turning on a cooling fan etc.

# **Chapter 17: Losses Correction**

**DYNO Mechanical Loss Correction**

**DRIVELINE Mechanical Loss Correction**

## 'Losses' System

Any mechanical system will have Power losses - your Engine, Transmission, Tires and the Dyno itself are no exception. Within DYNertia3 we refer to these as Mechanical Losses (sometimes described elsewhere as 'Parasitic' Losses).

Every bearing, gear, chain, belt or other component of the system under test and in the Dyno itself is increasing these mechanical losses. Even with good design, it is not possible to eliminate them and of course transmission and tire losses on the system under test can be VERY significant.

### **What are the effects of Mechanical Losses?**

Put simply, your Dyno will not give you the correct Power or Torque readings, even assuming you have an appropriately sized and calibrated Inertial Mass or Brake Unit. In many applications this may not be a concern as the Dyno is used to compare modifications / tuning changes - but if you really want accurate "numbers" or work on a variety of systems then losses need to be considered.

### **What does Measured Mechanical Loss Correction do?**

'Mechanical Losses Correction' systems allows you to compensate for the measurable mechanical losses of your Dyno system and Driveline. This is not a guess as sometimes included in other systems - but actual measurement of the losses through the Dyno's operating range. These losses are then automatically corrected for and 'Loss' information is stored with each run file for later user analysis.

### **MEASURED Mechanical Loss Correction-**

Ideal for Engine Dynamometers, where the System Under Test is directly connected to the Dyno. This enables Mechanical Losses within the Dyno to be automatically and predictably corrected based on a "Correction File" (multiple files allowed) created during the one off Losses Calibration process.

### **USER ESTIMATED Mechanical Loss Correction-**

This is not a measured loss calculation, it is just an estimate. The result will depend on how well the loss percentage has been researched, many users have their own idea of the losses they expect from manual and automatic drivelines.

### **Are these "Losses" worth worrying about?**


That depends on the complexity, quality and maintenance of your system. We have tested losses from a small chassis dyno system which has a worst case power loss of 1.141kW and 12.424 NM. - it's a very basic mechanical system ( 4 bearings and a disc brake ).

However other systems use multiple belts, numerous bearings, "run in" fans etc. and are a very different matter. Vee belt losses range from 4% to 10%. Roller chain is commonly assumed to be around 98% efficient, non linear devices like fans are even more troublesome and complex..... the losses all add up. So depending on your dyno's construction and your application - losses could be significant.


# Chapter 17: Losses Correction



## Configuration Window



Losses system can be accessed from the menu "Setup/Losses Systems" or by pressing the Icon that appears on the DYNO and GRAPH Windows (a stylized Bearing Block).



Whenever losses of any type is enabled the Icon that appears on the DYNO and GRAPH Window will be green.

DYNertia3 - Setup Losses Systems

**User Estimated**

Enable % Losses Correction  
Estimated Loss  %

Percentage Losses Correction adds a **FIXED** percentage to all power readings.... it is not measured or verified in any way by DYNertia3.

Suggested Application : None, but can be used with any Dyno configuration to artificially increase the Power reading.

Users need to be aware that they are **GUESSING** the Losses Percentage and assuming it is linearly proportional to RPM / Speed.

**Measured**

Enable DYNO Loss Correction

Dyno Loss Correction compensates for measurable losses in the DYNO System, but NOT the Driveline under test. This correction is automatic after a one off rundown is performed. Multiple correction files may be created and selected as required.

Suggested Application : All Dyno types.

Upper RPM of Dyno Losses File

**Driveline Losses**

Dyno RPM	Losses - kW
0	0.000
100	10.000
200	20.000
300	30.000
400	40.000
500	50.000
600	60.000
700	70.000
800	80.000
900	90.000
1000	100.000

**Dyno Losses Files**

In Use : Select a Losses File to use

- Rundown1.DLF
- Rundown2.DLF
- Rundown3.DLF

**DYNO LOSSES PROCEDURE**  
YOU MUST HAVE already set -

An accurate Moment of Inertia.  
The appropriate ratio so that the Tacho will read your Engines RPM.

Then -

Create / Overwrite a Dyno Losses File - giving it a meaningful name.

Set the Maximum Run RPM to a value HIGHER than your testing will ever require.

Note : The Losses Rundown is NOT a Power Run.

Then perform the test in the highest gear and at the highest RPM possible by pressing the RUNDOWN button.

When the Dyno has achieved the MAXIMUM RPM REMOVE ALL LOAD and let the Dyno COAST TO STATIONARY, WITHOUT ANY LOAD or BRAKING.

..... Then press the Stop Run Button, DYNertia3 will process and save the Losses File and return you to this Setup Losses Systems Window.

**Perform Dyno Losses Rundown**

Please ensure that all the setup requirements are met and you understand the Rundown procedure.

Click "Rundown" when ready to perform a run following the Dyno Losses Procedure.

Losses Rundowns are automatically performed in RPM Mode

Maximum Run RPM

**CREATE / OVERWRITE LOSSES FILE**

**RUNDOWN**


The losses configuration Window shown allows the choice of 'Estimated' or 'Measured' dyno loss correction.

**Note:** The comments that appear during the process are very descriptive; please read them carefully as you progress.

## Configuration Window (cont.)



Pressing the "?" will reveal an information only Window, this outlines pro's and con's of each method available.



## USER ESTIMATED Mechanical Loss Correction

This is not a measured loss calculation, it is just an estimate. The result will depend on how well the loss percentage has been researched, many users have their own idea of the losses they expect from manual and automatic drivelines.

It is not designed as a tool for 'adjusting' power figures to meet expectations.

User Estimated

Enable % Losses Correction

Estimated Loss Percentage  %


Percentage Losses Correction adds a FIXED percentage to all power readings.... it is not measured or verified in any way by DYNertia3

Suggested Application : None, but can be used with any Dyno configuration to artificially increase the Power reading.

Users need to be aware that they are GUESSING the Losses Percentage and assuming it is linearly proportional to RPM / Speed.

## MEASURED Mechanical Loss Correction

This enables Mechanical Losses within the Dyno to be automatically and predictably corrected based on a "Correction File" (multiple files allowed) created during this 'one off' Losses Calibration process.



This is designed a 'One off' test usually as the losses on a given dyno won't alter greatly. The losses characteristic is then applied to all future tests as long as Losses are active. The results of your test (or selected saved files) can be viewed in the above Window.

The rotating components of the dyno need to be **SAFELY** spun to an RPM preferably higher than future runs and then let coast down to a stop without any external load. The deceleration of the dyno is then completely dependent on its losses.

**Note:** The max safe RPM should be reached, though DYNetia3 software will extrapolate the data to create a curve that extends beyond your set values.

**Tip-** Testing by leaving the vehicle on the rollers will compensate for not only dyno losses but vehicle drive losses also.

This is NOT A POWER RUN - it's all about roller RPM (speed) so it can be performed in a higher gear or with different ratios than you would normally use - and at a much gentler acceleration rate.

However, you must REMOVE or FULLY DISCONNECT whatever you are using to spin the mass once it's reached the maximum RPM. If not, the driveline friction will be considered as part of the losses (this may be even desirable in some cases).

On a bike chassis dyno this may involve lifting the bike off the roller. On an engine Dyno the over-run clutch (sometimes fitted for 2 stroke testing) will automatically disconnect the motor. A bike de-clutched has very low friction (if not excessively tensioned down and well inflated tyres) and may prove suitable for a car chassis dyno.

There's no need to do this for a specific bike/kart/car/motor, anything that can spin the dyno to your required maximum mass RPM (above normal test RPM is desired) is satisfactory.

There are indicators in 'DYNetia3 File Explorer' and attached to trace information to always show if losses were applied and what file was used. The effect of losses on the result can be viewed in the menu 'View / Losses'.

**Note:** The RPM set as a maximum is not the actual dyno shaft RPM (unless record settings is set to 'shaft RPM'). It is whatever you have set via ratios etc. i.e. generally engine RPM, so bare this in mind when testing. The RPM gauge will reflect this RPM, not the dyno shaft!

## General setup for dyno Loss testing

- Prepare the dyno and DYNertia3 for a test Run as usual
- Set DYNertia3 into DYNO Losses Correction mode (menu “Setup/Losses Systems”)
- Press “Create a new losses file” button and give the file a meaningful name for future reference (you may end up with multiple files if you are altering your dyno hardware over time!)
- Set a suitable RPM as maximum (the maximum used by default comes from your settings in the ‘Record Settings’ field on the main DYNO window).
- Press the DYNertia3 “RUNDOWN” button
- Run the dyno up to the required maximum mass RPM
- Remove the bike / disconnect the motor / de-clutch as appropriate
- Let the load coast to a stop ( go and have a cup of coffee..... )
- Press the DYNertia3’ “STOP RUN” button to stop the run when the dyno is at rest
- DYNertia3 will calculate the losses and display them in the ‘Driveline Losses’ window

**Note:** The max safe RPM should be reached, though DYNertia3 software will extrapolate the data to create a curve that extends beyond your set values, therefore testing to very high RPM is not necessary.

**Note:** The RPM set as a maximum is not the actual dyno shaft RPM (unless ‘record settings’ field is set to ‘shaft RPM’). It is whatever you have set via ratios etc i.e. generally engine RPM, so bare this in mind when testing. The RPM gauge will reflect this RPM, not the dyno shaft!

**Tip-** It may pay just to do a low speed test first to make sure everything is as you expect. It can take some time for large mass to slow down so it's best to do it right first time!

## How often should I run dyno losses correction?

Assuming your dyno is built and maintained properly, Dyno Mechanical Losses Calibration will only need to be done at first installation, and from then on depending on the frequency of dyno use.


We suggest that initially you do two calibrations a month apart, and check for change. If it's insignificant then twice a year may be sufficient. However mechanical components can deteriorate quite quickly so it's definitely not a good idea to ignore periodic re-calibrations. It's frustrating to find out that the “noisy” bearing has been affecting the outcome of your tuning for months!

# Chapter 17: Losses Correction



## Observing effect of Losses Correction

The effect of losses on the actual test result can be viewed in the menu 'View / Losses' as shown below.



Whenever losses is enabled the icon that appears on the Dyno and Graph Window will be green.

When you preview files done in this mode (In 'DYNetia3 File Explorer') the indicator icon will show if loss correction has been applied.



The Trace information will also show the loss system correction type has been applied

Max. Power :	106.2083 kW
Max Torque :	211.9372 Nm
Inertia :	1 Kg/M^2
Loss Correction :	Dyno Correction
Loss File :	test2

# **Chapter 18: Maths Channels**

**Additional data channels**

**Creating maths expressions**

**Saving and applying expressions to files**

# Chapter 18: Maths Channels



## Concept

Maths channels are universally configurable data channels that are added along with the standard measured data acquisition inputs. This provides a very powerful tool; your creativity is the limit!


Maths channels use mathematical functions to modify or manipulate existing data, display data not normally viewable along with the standard traces (like internal data from weather station, run statistics, sensor ranges etc) or to perform complex calculations based on the results of previous calculations and data.

This may be as simple as converting power and torque units, displaying volumetric efficiency or as complex as fusing data from multiple sensors and combining with performance data.


Two maths channels are available and are displayed in all of the dyno Windows where the standard input channels are displayed.



'DYNertia3 File Explorer' Window is the entry point to generate maths 'expressions' and to and control their storage and application.




From within 'DYNertia3 File Explorer', pressing the 'Maths' button will open the maths channel 'Expression Builder' seen below-



# Chapter 18: Maths Channels




The maths 'Expression' (formula for creating data to populate the maths channels) is saved as special files (.D3EXP), this file can then be 'loaded' into math channel 1 or 2 and when back in the 'DYNertia3 File Explorer' Window this can be attached to any file to add the extra channel.



When you have written a maths expression you can save it to file for later use or recall one from file to either use or to modify and re-save. Double 'Clicking' on the name of the file if it is shown in the expression list (top Left of Window) will also open it for viewing.



The displayed expression can be cleared from the Window.



When you wish to 'load' an expression so that it can be applied to a dyno test file, you will press the appropriate button here and be prompted to select the expression file you wish to apply to that particular channel (e.g. press "MATH 2" will allow selection of expression to apply as math channel 2)

Operators	Application :
+	Addition
-	Subtraction
*	Multiplication
/	Division
\	Division (Integer)
^	Power Of
{	Open Bracket
}	Close Bracket

Functions	Application :
SIN(X)	Sine of Angle X in degrees
COS(X)	Cosine of Angle X in degrees
TAN(X)	Tangent of Angle X in degrees
ATN(X)	Arctangent of Angle X in degrees
FACT(X)	Factorial of X
EXP(X)	Exponent to X
INT(X)	Integer of X
LOG(X)	Logarithm of X

Constants	Application :	Test Val
C	Temperature (C)	21
BP	Barometric Pressure (mB)	1000
RH	Relative Humidity (%)	50
CF	Correction Factor	1
DUR	Duration (Seconds)	5.4321
MAXRPM	Maximum Run RPM	10000
MAXKPH	Maximum RUN KPH	150
MAXKW	Maximum Run Power (Kw)	500

Variables	Application :	Test Val
RESULT	Result (from last line)	
KW	Power	100
NM	Torque	60
HP	Power	150
FTLB	Torque	100
RPM	RPM	2500
KPH	Kilometers per Hour	30
MPH	Miles per Hour	20

When writing an expression these '**Operators**' are the basic maths operations that can be used-

**Functions** are calculations and conversions already to use  
e.g. HP2KW (converts Horsepower into Kilowatts)

A '**Constant**' is a value that does not change over the course of a test run (or they are calculated after the actual run).

**Note:** The values shown in the Right Hand column are just there for testing that the expression works, they do not represent the actual 'constants' real value in use! They can be altered by 'Clicking' on them and typing.

**Variables** can be freely used in your expression. These actually change during the course of the test run, such as Power, Torque, Speed or data from any of the 5 input channels.

There are also unallocated variables that you can use, these will be explained in more detail next.

## Sample expressions, simple

`HP2KW(HP)'` converts HP into KW

`KW*5 '` simply multiplies power by 5

`KW*(DATA2/4)'` data from channel 2 is divided by 4, then this is multiplied by KW

## Testing an expression

Once an expression is entered it can be tested by pressing the evaluation button. Before doing this you should set the 'Test Val' fields of any of the constants or variables you have used to values that will allow you to determine if the result is correct or not (i.e. allow a test with figures so you can confirm the result matches expectations).



Any errors will show marked in red and with a description of the errors, "SYNTAX PASS" indicator will also turn red and display "SYNTAX FAIL". In the case above the expression divides something by zero, this is mathematically impossible!

## Variables in detail

- In the 'Variables' field you will find a variable named "RESULT", this is the result that came from running the expression contained in the line above-
 

line1- `KW*5` multiplies power by 5  
line2- `RESULT + 4` takes the answer from "KW\*5" and adds 4
- In the 'Variables' field you will find variables named 'Private' eg. VAR00 is called "User Variable 00 (Private)". Private means that the variable is 'dynamic' and will be altered each time the expression is applied to a particular line of the dyno run file (value doesn't carry over).
- In the 'Variables' field you will find variables named 'Public' eg. VAR11 is called "User Variable 11 (Public)". Public means that the variable is "static" and will remain fixed each time the expression is applied. These are used when you need to keep track of a value throughout the dyno run file e.g. you might be adding fuel flow data from one RPM point to the next (fuel consumption) for the whole run.

Reset  
Public  
Variables

When testing expressions it must be noted that there is a button that can clear the 'Public' variables as these will need resetting to re-test (as value will accumulate with previous tests)

# Chapter 18: Maths Channels



## Creating and saving a math's expression

**Note:** This expression below could be constructed in many simpler ways to give the same answer; we have chosen one that demonstrates the use of several concepts.

The expression is typed into the fields-

The screenshot shows the 'Expression Name and Description' section with 'Channel Name : Air mg/stroke' and 'Desc. : engine load'. Below this is the 'Mathematical Expression to apply:' section containing the following steps:

- 1 RPM \* 60' converts to RPHr
- 2 VAR00 = RESULT' variable is now RPHr
- 3 DATA3 / VAR00' kgHr (from air mass meter) / RPHr giving Kg per rev
- 4 RESULT / 2' Kg per stroke (4 stroke)
- 5 RESULT\*1000000' mg per stroke

Following each part of the expression is a comment. These can be added as after the “ ‘ “ everything is ignored.


You can notice that the expression has been given a channel name, this will appear with the data when analysing, just as you might call a conventional input channel “Lambda” if you had a Lambda meter connected!

Once created this expression would be tested by pressing the “Evaluate Expression” and the result confirmed by checking actual outcome and observing “SYNTAX PASS” indicator.




The result would be then saved for future application by using this button.

## Applying an expression to a dyno file



In this example we wish to apply an expression to ‘Maths 1’ channel, we would therefore press this “MATH 1” button in ‘Expression Builder’ and then choose the file that contained the expression we want.




When we now close down ‘Expression Builder’ and return to ‘DYNertia3 File Explorer’, we will now see the green indicator that lets us know an expression is loaded and ready to apply to a file of choice (1 in this example).

‘Clicking’ on a file of choice in ‘DYNertia3 File Explorer’ will now give you the option of applying the expression to the file, you will see the columns of previewed data change to add the new values.

A Window will then appear that gives the option of changing the names and scales of the newly created data channels. This could be handy if there are some extremely hi or low data values that would create a poorly scaled trace on the graph screen otherwise.

Re-type the scales, name and description if required.



## 'Exception' notifications

If after applying the expression in 'DYNertia3 File Explorer' a red 'cross' appears then it means that when applying the expression to the dyno file an 'exception' occurred. 'Clicking' on the red cross will open the 'Expressions exceptions' screen shown below. This will show each line were a problem occurred.

**Note:** This is just a warning, "0.00" will be entered as a value at that line but the rest of the maths channel data will be as expected.



This check is done as it is possible to apply an expression with an error in it, but more than likely it is just simply a particular input data or variable out of range (e.g. you might be dividing 2 values and one drops to 0 creating a 'divide by zero' error)

DYNertia - Expression Exceptions

**Exception(s) occured during application of your Expressions to the Math Data.**

This could be caused by :

1/ Math and / or Syntax Error(s) in your Expression  
2/ Input Data and / or Variables going outside appropriate calculation limits

Error :	Source	RPM Entry	Error Description	In Expression....	In Phrase.....
1	Maths 1	3042.63	Division by Zero	RPM / 0	RPM / 0
2	Maths 1	3075.04	Division by Zero	RPM / 0	RPM / 0
3	Maths 1	3110.33	Division by Zero	RPM / 0	RPM / 0
4	Maths 1	3148.57	Division by Zero	RPM / 0	RPM / 0
5	Maths 1	3189.83	Division by Zero	RPM / 0	RPM / 0
6	Maths 1	3234.27	Division by Zero	RPM / 0	RPM / 0
7	Maths 1	3281.82	Division by Zero	RPM / 0	RPM / 0
8	Maths 1	3332.31	Division by Zero	RPM / 0	RPM / 0
9	Maths 1	3385.76	Division by Zero	RPM / 0	RPM / 0
10	Maths 1	3442.44	Division by Zero	RPM / 0	RPM / 0
11	Maths 1	3502.02	Division by Zero	RPM / 0	RPM / 0

The Maths Data result has been set to 0.00 where Exception(s) occurred

# **Chapter 19: ‘Utilities’ Menu**

**Send an Email**

**Converter for Lambda  $\leftarrow \rightarrow$  AFR**

**Calculator for RPM/Torque/Power**

**Metric/Imperial Convertor for Torque/Power**

**Display Current Weather Data**

**Display Current Lambda/AFR**

**RPM/Speed Stability**

**OBDII**

**Speedometer Calibration**


**Data Diagnostics**

# Chapter 19: 'Utilities' Menu



## Send an email

An email service is inbuilt. After initial setting up it allows for quick emailing, this was primarily designed for the sending files required for diagnostics, sending tech enquiries, providing feedback and suggestions to DTec.



## Lambda $\leftrightarrow$ AFR Converter


A Converter tool that allows you to change Lambda to Air/Fuel ratio (AFR) and visa versa.

To deal with AFR units then the fuel being used stoichiometry ratio must be known (ratio for chemically complete combustion). If you work in Lambda units then the actual fuel used is irrelevant e.g. Lambda 1 is Lambda 1 with any fuel! This is because Lambda is simply an indicator of how far you are from ideal (0.9 = 10% rich, 1.1 = 10% lean)


We have already entered the value for most common fuels. You can enter your own value if you are using a blended fuel and then save this for use in DYNertia3 later (e.g. in the 'Lambda/AFR deviation' analyser Window).

Once the fuel has been selected then you can manually enter a Lambda value and the equivalent AFR will be displayed.

Tables of the conversions are also shown for quick reference.



# Chapter 19: 'Utilities' Menu



## RPM / Torque / Power Calculator

A calculator that allows you to enter (imperial or metric) RPM or Torque figures to show the Power that would result.

The screenshot shows a software window titled "DYNertia3 - RPM / Torque / Power Calculator". It contains two sets of conversion inputs:

**Top Set:** Power = 10.47 kW =   
Torque = 100 (Nm) x 1000 RPM = 9549

**Bottom Set:** Power = 14.04 HP =   
Torque = 73.76 (FtLb) x 1000 RPM = 5252

## Metric / Imperial convertor for Torque / Power

A calculator that allows you to enter (imperial or metric) RPM or Torque figures to show the Power that would result.

The screenshot shows a software window titled "DYNertia3 - Power / Torque Converter". It features two main conversion pairs:

**Power:** Kilowatts = 100 → Horsepower = 134.10


**Torque:** Newton Metres = 57 → Foot Pounds = 42.04

Below the inputs, a note states: "Values may be edited to perform Metric <> Imperial - Power / Torque conversions."

## Display current Weather Data

Allows the viewing of the weather data from the optional DTec 'Weather Watch' automatic weather station. ensure it is connected and configured to a PC USB port via "Setup/Communication".

You can view the live data from the optional 'Weather Watch' station including RAD (Relative Air Density).




**Note:** See chapter "Weather Corrections for more detail on how the weather data is applied during testing.

**Tip-** The Relative Air Density (RAD) is also displayed for tuning purposes and can be recorded as a reference. Please see the 'Weather Watch' documentation for more information on RAD and other 'stand alone' tuning features.


The 'RAD Reference' button saves the current RAD at the time it is pressed so any changes, and therefore air/fuel mixture changes, are easily noted.

# Chapter 19: 'Utilities' Menu



## Display Current AFR/Lambda

If a Lambda meter (Air Fuel Ratio- AFR) is connected to an input channel then it can be displayed in this indication Window for high visibility during tuning.




If the Lambda reading goes outside the acceptable 'Set Point' range then the gauge surroundings change to a very noticeable red colour to alert that a problem exists.

**Note:** See chapter "Live Data Viewing" for details on this window.

## RPM/Speed Stability

This screen monitors the dyno input speed over time. It is designed for helping check a brake type dyno's ability to maintain a constant speed but can also be used to check the speed sensors behaviour.



**Note:** It only displays speed data from the dyno speed sensor, not engine RPM etc.


# Chapter 19: 'Utilities' Menu



## Data Diagnostics

Opens the 'Data Channels' analyser Window to test that the channels are configured correctly and operating as expected. It can also be used for tuning and logging the data.

**Note:** See chapter "Inputs- Using" for full details on 'Data Channels' window.



**Note:** 'Hardware Tachometer Input' will only display if it is enabled in the menu option 'Setup/Hardware' and selected as the RPM source in menu option 'Setup/ RPM Speed Source'



You can check the naming of channels and that they function. Pressing the "In mV" button allows us to read the voltage coming into DYNertia directly ('raw' with no calibrations applied). This is what is used to gather the data for calibration i.e. you will take this reading and note it against a particular pressure, temperature, position, voltage etc. when performing a calibration.

**Note:** DYNertia internally reads mV from 0-5000, If you add resistors to divide the input voltage down to suit this range (i.e. allowing a 15V range) you are just dividing the input by 3 before it is measured. The 'raw' values will be still in the 0-5000 range eg. 9V input would be 3000mV raw.

## **Chapter 20: Trouble Shooting & FAQ's**

**Common mistakes made**

**Frequently asked questions (FAQ)**

## Trouble Shooting- Common Issues

### When connecting I am unable to 'Link'.

Please see the manual chapter on " 'Setup' Menu Options", in the 'Communications' Setup section it explains how to check the PC has recognised that DYNertia is connected to the USB.

The usual problem is that during software installation the security settings were not set correctly as stated and the USB 'driver' software failed to install correctly.

### I don't know that my sensor is working correctly.

After you first power up DYNertia controller the status LED will flash briefly twice and then remain on. After the 'Linking' process (menu "Setup/Communication") the sensor operation can be checked via the button "DYNertia3 Sensor Test". The indicator and an audible noise can be used to confirm sensor operation during slow rotation. The indicator lamp/noise triggers for a short time as the magnet approaches the sensor (only on approach).

If you use a voltmeter on the sensor input pin it should be 5V and then go close to 0V (less than 1V) when the magnet is under the sensor.

### I don't want to mount a magnet to my flywheel.


In the chapter 'Hardware Installation' is discussed alternate sensors i.e. perhaps you wish to sense form metal, rather than magnetic target. Please contact us for further information if required

### Very large and completely unreasonable spikes in the power readings (displayed on graphs as sharp spikes or "Over" text on the large run summary).

Generally huge variations in Power readings are due to poor RPM data. This can be from ignition interference, poor operation of the sensor due to mounting issues (vibration or clearances) or poor RPM input from the 'RPM Adapter' input if being used.


- Use suppressed ignition leads and resistive plugs for the testing and ensure all wiring is as far as possible from the interference source.
- Avoid using the RPM Adapter input as the primary RPM source, just use it for 'teaching' the ratio (see 'RPM Input options' chapter in this manual)

A quick test can be done by observing the RPM gauge operation before testing (press the 'Gauge' button and run the engine)



Check the filter settings are sufficient in menu option "Setup/Software/Graph Smoothness"

Only use what is needed to create suitable graphs, set correctly it will filter out some of the 'spikes' discussed here. It cannot make up for poor data from sensor faults and large amounts of interference.



Next to each data channel input ("Setup/Sensor Configuration") is a slider control for that particular input. This is particularly important for Channel 5 as a load cell will be connected here. This has a major effect on the appearance of the graphs in brake dyno mode.

## Trouble Shooting- Common Issues (cont.)

### RPM intermittently drops out or PC ceases the test run prematurely.

This can be from ignition interference, as covered in a previous FAQ, but do not overlook the PC itself as another issue. We have encountered particular laptops that will not run reliably near engines. Wireless attachments can give trouble also near interference fields.

Do not have any other programs running when DYNertia3 is operating and make sure virus programs are not inhibiting operation. If in any doubt, and after you have taken the advice in the hardware setup chapter regarding avoiding interference then please try another PC to test.

### No RPM reading on gauges but it indicates sensor is OK in sensor test ('setup/communications' menu).

Some countries use a Windows regional setting that uses a "," instead of a "." to separate numbers. If this occurs please go to Windows 'start/control panel/regional and language options' and under 'location' choose 'English (Australia)', or make your own settings.

### Test results seem good until high RPM, then erratic power readings.

If RPM is coming from the engine ignition system (RPM Adapter input being used) then at high RPM the rev limiter may be cutting in and killing the ignition pulse. Avoid using the RPM Adapter input as the primary RPM source, just use it for 'teaching' the ratio (see 'RPM Input options' chapter in this manual)

### Certain vehicles/engines coming up with error warnings when processing the data after a test run.

Make sure the start and finish speeds are reasonably set in the 'Record Settings' field on the Dyno screen. Ignition interference with the transmitted USB data is the next likely cause. Test the RPM input by observing the gauge operation (press the 'Gauge' button and run the engine)

-Use suppressed ignition leads and resistive plugs for the testing and ensure all wiring is as far as possible from the interference source.


### 'Double Click' in other programs running (i.e. not DYNertia3) does not work.

You were told not to run other programs in the 'Software installation' guide! Close DYNertia3 and function will return.

### 'Run Time' error occurs and DYNertia3 will not start.


Copy the 'DYNertia3.D3CF' file ('C/DYNertia3' by default) and email it to us with fault description. Delete the file (DYNertia3 will recreate it) and re-start. You will need to re-enter your settings (SETTINGS.txt file has them).

### Screen text appears to be out of place, the wrong size and DYNertia3 screen seems to be all 'messed up'.



Windows has been set to the wrong display properties (its magnifying the text so it won't fit on the screen).

Depending on what version windows you have you will need to search and find the 'appearance and personalisation' and then 'display' settings.



## Trouble Shooting- Common Issues (cont.)

### **Brake mode shows significantly lower power readings when ramping as oppose to steady state testing.**

Inertia of dyno provides significant losses that should be accounted for by setting an Inertia value in "Setup/Hardware" and selecting "Brake Inertia Correction" in "Setup/Hardware" also. This is particularly noticeable when testing lower powered vehicles such as bikes, the inertia of the brake dyno can be as high as many inertia dyno.

### **Low readings when using calculated inertia value.**

It is more than likely the expectations are higher than the ability. Be wary of inflated power figures that are used within the industry (unexplainable correction factors) or a lack of understanding of the test procedure used to gather the manufacturer's data. If you need to comply with a particular norm then it is known for users to 'trim' their calculated inertia value to align the test numbers with expectations (we don't suggest this but it is certainly common practice)

### **RPM gauge not displaying a reading.**

Rotation of the dyno shaft/roller/flywheel above a minimum speed is required for the data to be transmitted if the RPM source is derived from the main DYNertia sensor. Run the vehicle (drive the dyno) to confirm.

### **Certain software options are 'greyed out' and unable to activate.**

Some software features are only enabled when other choices are active. For example, the dyno may need to be in 'Brake' mode rather than 'Inertia' for certain functions (such as 'Point by Point' steady state testing mode)

### **How do I create and rename folders and files for my runs?**

Folders are created within our 'DYNertia3 File Explorer'; Windows Explorer can also be used just like with any other program.

### **When I go to view graphs a warning about not being able to load the trace appears, what does this mean?**

If there is no actual data saved in the file (Run not performed) or the file has been renamed or relocated then obviously DYNertia3 will have problems finding and opening it. If DYNertia3 can't open all of the files selected for graphing it will clear all so that you can re-select from their new location. If only some test Runs (not all) won't load then just reload the altered ones again, selecting from the new location. Moving/renaming the 'default' folder being used should be avoided.

### **The DYNertia3 screen does not fill the whole PC's screen.**

The DYNertia3 Window does not size itself to the PC screen, if you wish you can adjust your PC screen resolution to best suit (Program Window size is 1024 x 768)

### **When In DYNertia3 File explorer I cannot get a file to load into graph screen.**

The usual issue is not 'Left Clicking' on a file to highlight it and then 'Right Clicking' to actually load it into the Graph Window.

### **Gauge/ trace scaling is not ideal**

Please see the menu choices under "Scales" to set the gauges and charts to suitable scale ranges.

**Note:** When the gauges are used for analysing graphs (showing the value at the cursor) their scale is automatically selected based on the scales used in the GRAPH Window, not this setting.

Consider the start and end settings you have used in the 'Record Settings' field in the main DYNO Window. You can also see the chapter on 'Loading/Viewing Files' and 'Trim, Merge & Join Runs' for information on adjusting scales and permanently changing the tests Run start and end points.

### **Certain Screens appear on top of others**

DYNertia3 is optimal with two monitors; many Windows will be displayed across to the second monitor (if fitted). If viewing with a single monitor then please note the PC's taskbar (at bottom of screen usually) shows what Window are open and you can select between them from there.

### **After a 'crash' of my PC I lose settings**

DYNertia3 saves all of its settings when the program is shut down, not necessarily when an individual window is closed. We suggest during / after you do your initial setup you close DYNertia3 down so that it saves the settings fully.


## Troubleshooting- Assessing results

### Assessing test results- Poor settings

Most poor results are either due to electrical interference (via PC, accessories or DYNertia hardware) or from poor selection of start and end points for the test.




**OK-** It has a good start point and decisive end



**OK-** It has a good start point and decisive end.

**Note:** Personally I would set the max RPM lower to prevent the trace from dropping away and risking doubling back under.



**NOT OK-** Both these traces are running back under themselves at the test end. The trace should not run back under itself or you effectively end up with 2 power readings for every RPM point and this is confusing to calculations we run.



Both the above files have a poorly set Max RPM (set in "Record Settings" field as below).



There is nothing wrong with the data, just needs a better setup of max and min RPM/speed (start and end) at test time.

# Chapter 20: Trouble Shooting & FAQ's



## Assessing test results- Signal issues



**NOT OK-** Traces go back and forth.


This can be from ignition interference etc. but the image above is lacking any large 'spikes' that this usually creates.

Likely the engine RPM differs to roller RPM in the data so this implies an issue i.e. roller smooth, engine erratic. This could be from 'RPM adapter' (if used) was getting bad signal (poor connection, ignition missfire or even a rev-limiter cutting spark).


It is useful to realise the 'power' is calculated from the roller/flywheel mass speed sensor, not the "TAC" input (RPM adapter) which is used to derive 'torque' from the 'power' and is used for the X axis graph scale (RPM).

If you display the same data above in 'speed' mode (kph on X axis), and not 'RPM' mode it will remove the impact on the graph X axis scale, however the torque will still be erratic.


Below is same data above displayed in 'Speed' mode (kph is the X-axis), not 'RPM' mode. Nice power trace proves the theory that poor TAC signal was the issue.



**Note:** Best avoid the optional TAC input use if it's not stable or interference is impacting it, choose another RPM source option.



**NOT OK-** Power traces getting very erratic as speed rises. Mechanical issue creating variations in shaft speed (vibrations or 'snatch'). Greater filtering will help somewhat but not a fix.



**NOT OK-** Crazy data due to electrical interference from the ignition system.

## Frequently Asked Questions (FAQ's)

The answers to some commonly asked questions that may increase your understanding of DYNertia3 and your dyno.

### Q- Do I need a tachometer connected to DYNertia?

**A-** Not necessarily, engine dyno's normally don't require a tacho due to the known fixed drive ratio and for a chassis dyno it only requires that the engine RPM be known temporarily for initial 'teaching' (any RPM point can be used). Also 'Speed' mode uses Speed (kph) rather than RPM as the graphs X-scale (unlike in 'RPM' mode); this can be done if it is not practical to use a tacho even temporarily.

There is an optional secondary tacho input in DYNertia; this can be used as the sole RPM source and is useful for determining clutch slip (engagement RPM) or loss of tyre traction. It can also allow automatic determination of the drive ratio between the dyno and engine for quick 'ratio teaching' (see 'RPM Input options' chapter in this manual)

### Q- How can it get engine RPM without ignition connections (I don't have an 'RPM adapter' to connect to DYNertia)?

**A-** DYNertia3 can determine the engine RPM from dyno flywheel RPM by 'learning' their relationship (ratio). Any application that has a tacho already fitted, or can have one connected temporarily is particularly applicable. Many vehicles tested on chassis dyno's incorporate one and there are also many cheap commercial units available. Typical engine dyno's where the gear ratio is obvious (sprocket sizes known or direct drive) do not need a tacho (manually enter the ratio).



This graph shows the same vehicle 'ramp' tested at rates from 3, 10, 20 and 30 kph/sec. This is on a world class 'eddy current' dyno, not even an inertia dyno. It shows the effect of engine/vehicle inertia clearly (faster = lower readings). Unless true 'step' testing (requires 'Brake' style dyno) is used this effect always occurs. Inertia dyno's give slightly lower overall Power readings due to this acceleration. Also, manufacturers Power figures are often at the crank (no large transmission loses, tyre loses etc), they are often optimistic (marketing department!) and some dyno's add 'fudge factors' that raise readings, this can all create an expectation of a certain power level!

Try and use inertia values and test gears that don't allow the engine to accelerate too fast (please read the design guide on [www.DTec.net.au](http://www.DTec.net.au) for full discussions), 8-10 seconds is generally considered suitable for a run depending on vehicle/engine type (customers have built dyno's that span from 2-20 second runs in practice and are happy with results!)

### Q- My dyno doesn't give the same figures as the one up the road. Is it accurate?


**A-** Accuracy is not really important, repeatability is! Take your vehicle to 6 different dyno's and you'll return with 6 different readings. This doesn't matter, what you need is repeatability so that if you put the vehicle back onto the same dyno the figures are the same. Without this you can't tune and are wasting your time! Inertia dyno's are very, very, repeatable! If your customer only wishes to see 'big numbers' and not necessarily 'better numbers' then he may as well just travel around till he finds a high reading dyno (or the operator fiddles the correction factors) and not bother with tuning! If the actual reading is a concern, consider your choice of inertia mass, test gear or the inertia value entered in the setup screen or 'losses' correction.

# **Chapter 21: Specifications**

**Hardware specs and notes pages!**

## Specifications

Timer accuracy	$\pm 1$ microsecond at 21°C
Maximum RPM	Greater than 30,000 (max is PC dependent)
Minimum RPM	4 RPM approximately
Timer	
Technology	Digital, microprocessor
Operating temperature	-35°C to +65°C
Communications	USB to computer
Power supply	USB powered (5V)
Current draw	Less than 50mA (excluding additional connections for acquisition or outputs)
Sensor	Hall (magnetic sensing), optional Hall (iron sensing) or optical (infrared reflective)
Sensor air gap	1.5 mm optimally for magnet sensing (standard supplied sensor)
Auxiliary outputs	3 outputs, 20 mA can be sunk/sourced (i.e. must use a 'solid state' relay or transistor)
Input channels	5 analogue inputs, 1 digital input. Common grounding
Input digital (RPM adapter)	Active low timing input, internal pull-up. <b>Not</b> for direct connection to ignition systems!
Input voltage	0-5 Volts
Input resolution	5mV, 10 bit analogue to digital conversion
Reference	Supply sourced, software compensation (or offset) can be applied
Input impedance	Greater than 10KΩ
Dimensions	Approximately 110L x 60W x 30H (mm), excluding mounting tabs



## Notes

**Keep track of important setup information here for future reference**

#### Primary Inertia Factor of Dyno:

Inertia Factor of 2<sup>nd</sup> flywheel:

Inertia Factor of 3<sup>rd</sup> flywheel:

**Roller Circumference:**

Gear Ratio of flywheel drive:

#### General Notes:

## **Chapter 22: Additions & Changes**

**Latest software and manual amendments**

## Software V3.4.x Changes & Errata

### **Manual amendments**

This manual version 8.3 has references to hardware 'DYNertia3' changed to 'DYNertia'. DYNertia3 is software but physical hardware has been revised.

Some screen shots still depict V3.4.7 software. V3.4.8 has had some redundant functions (including their tabs) and references to no longer existing hardware removed.

'Load controller' (closed loop brake system) references and chapter has been removed as not relevant at present for this DYNertia hardware version i.e. closed loop hardware not available currently.

Sensor magnet mounting details updated to a 4mm screw to match the new magnets supplied.

### **Known issues**

V3.4.8 (current as of time of this manual review), see 'read me' file in DYNertia3 directory.